This opens the System Health overview which also displays the failed state of the drives, as shown in Figure 11-118.




Figure 11-118 System health overview with failed drives

► Failed processor node: Figure 11-119 shows the Hardware view with a failed processor node. Hovering on the node provides additional information about this component. Once again, the same information can be obtained from System Health overview, as shown in Figure 11-120.




Figure 11-119 Hardware view with a failed processor node