Loaded Rib with Directly Attached Suspension Lines Showing Suspension Line Measurements and Trim Dimensions



Measurements 1 2 3 are trim dimensions.

Measurement 4 is used to specify full flight and deployment brake setting relative to "A" line length.

Note: "A" line length +1 = "B" line length
"A" line length +1+2 = "C" line length
"A" line length +1+2+3 = "D" line length
"A" line length +4 = control line length $_{FF}$ for full-flight setting
"A" line length +4 = control line length for $_{DB}$ deployment brake settings

Note: In this view, suspension lines are not cascaded.

Figure 3A.

Loaded Rib Using Flares for Suspension Line Attachments



Note: Trim and rigging information is the same as shown in Figure 3A.

Figure 3B.