## 3.4.1 All volumes

Select **Volumes** (see Figure 3-55) to see a list of all defined volumes, which is alphabetically sorted by the volume name (by default). At any time, you can change the sort options by clicking a specific header in the table. You can directly configure a new volume by clicking **Create Volumes**, as shown in Figure 3-56.



Figure 3-56 Create a volume