- ► A valid 3270-X session (using IBM PCOM or an equivalent 3270 emulator) also needs to be connected to the OSA-ICC Session. This configuration allows a valid session to be established to the OSA-ICC for NIP messages to be delivered to that device.
- ► The example will be adding the predefined OSC devices 0700-0701 (3270-X).

To define 3270-X devices to NIP within an OSCONFIG, complete these steps:

- 1. From the main HCD panel, select option **1.1. Operating system configurations** to display the Operating System Configuration List.
- Scroll through the list of OSCONFIG definitions until you find the OSCONFIG you want to add to the 3270-X devices to the NIP console list, or in the command line enter L ITSOTEST. In our example, we use ITSOTEST.
- Enter n next to the OSCONFIG, and press Enter.
  HCD displays the currently defined devices in the NIP Console List (Figure 13-14).

Figure 13-14 OCSONFIGs: NIP Console List

In our example, there are presently no devices defined in the NIP Console List.