5.5.3 Creating iSCSI hosts

To create iSCSI hosts, complete the following steps:

1. On Hosts window, click **Add Host**. Then, click **iSCSI** and the iSCSI configuration wizard opens (see Figure 5-55).




Figure 5-55 Add an iSCSI host

2. Enter a descriptive host name (the iSCSI initiator name in the name field). Enter the iSCSI Qualified Name (IQN) information, as shown in Figure 5-56 on page 271.

If you want to add several initiator names to one host, repeat this step by clicking the plus sign (+).