
80 Infotainment Amundsen > Images

Operation

Touch operation



A Look at images

- ▶ ▷▷ Show the next image
- ▶ < < Show the previous image
- ▶ ▷ Start slideshow
- ▶ III Stop slideshow

B View image

- ▶ Turn to the left
- ▶ Turn to the right
- ▶ ≔ Display in initial size
- Guidance to GPS coordinates The functional area is displayed if the image contains information about GPS.

Gesture control



▶ Display of the next image



Display the previous image



▶ Increase the image size



▶ Reduce the image size



▶ Maximum image magnification / display of the initial image size

Settings

The following Infotainment functions are set in the MENU > \blacksquare > \varnothing menu:

- ▶ Display image size
- ▶ Display image duration during the slideshow
- ▶ Slideshow repeat

Supported sources and files

Supported sources

Source	Interface	Specifica- tion	File system
SD card	SD card reader	Standard size SD SDHC SDXC	FAT16 FAT32
USB	USB 1.x; 2.x 3.x	USB stick HDD	exFAT NTFS
	or higher with USB 2.x support	(without special software)	