Complete the following steps to create a user group with remote authentication enabled:

1. Click **Access** → **Users** and select **Create User Group**, as shown in Figure 4-29.




Figure 4-29 Option to create a user group

2. Enter the details for the new group. Select **Enable for this group** to enable remote authentication, as shown in Figure 4-30. Click **Create**.

Note: This option is not available if LDAP authentication is not enabled.




Figure 4-30 Creating a user group with remote authentication enabled