

Fasteners in the boot

Overview



- A Bag hooks Max. load 7.5 kg
- B Fasteners for securing the fixing nets and the multifunctional pocket
- C Lashing eyes for securing the fixing nets and the multifunctional pocket
- D Lashing eyes for securing the load, the fastening nets and the multifunctional pocket Max. load 350 kg

Other fasteners




- A Flexible storage compartment Max. load 8 kg
- **B** Cargo elements

Max. load 8 kg

A storage compartment for the cargo elements is located under the floor covering in the boot.

Fold up the cargo element and fasten it to the floor covering in the boot.

Bag hooks in the boot



The maximum load for the hook is 7.5 kg.

Flexible storage compartment



The maximum permissible load for the storage compartment is $8\ kg$.