## 23 TOYOTA INNOVA Air Conditioner (Rear) Power Source 3 \* 1 : Before Sep. 2008 Production \* 2 : From Sep. 2008 Production \* 3 : Before Sep. 2009 Production 2 IJ1 (\*3) 2 IJ3 (\*4) 2 IJ5 (\*5) 10 IJ6 (\*6) \* 3 : Seriore Sep. 2009 Production \* 4 : From Sep. 2009 Production until Sep. 2010 Production \* 5 : From Sep. 2010 Production until Feb. 2012 Production \* 6 : From Feb. 2012 Production J21(A) Junction Connector Connector I 9 Ignition SW Relay B10 Blower Motor (Rear) B11 Blower Resistor (Rear) -vv--vv-OFF LO M1 M2 HI B12 Blower SW (Rear) J33 Junction Battery Cowl Side Panel RH