10 TOYOTA INNOVA Power Source ABS 2 ACC B-R diiib J23(A), J24(B) Junction Connector IG2 DLC3 <3-15> ST2 7 BA1 3 BA1 I 9 Ignition SW IJ2 7 II3 IJ2 (*3) IJ4 (*4) IJ2 IJ4 JJ2 3 IJ4 IJ6 (*5) (2D) 1 112 D/G TC +BM +BS 21 A (*6) 21 C (*5) 10(A), C20(C) ombination Meter 1(1F) GND1 GND2 SFRR SFRH SFLR SFLH SRRR SRRH S 2 Skid Control ECU 24 with Actuator 36 A - - 38 A (*6) 36 C - - 38 C (*5) J 4(A), J 5(B) Connector 3 113 * 1 : Before Sep. 2008 Production * 2 : From Sep. 2008 Production Battery * 3 : Before Sep. 2009 Production * 4 : From Sep. 2009 Production until Feb. 2012 Production * 5 : From Feb. 2012 Production * 6 : Before Feb. 2012 Production Left Side of the EB Fender Apron