3

2 TOYOTA INNOVA * 1 : Before Sep. 2008 Production * 2 : From Sep. 2008 Production * 3 : Before Feb. 2012 Production Ignition Power Source 2 3 IG2 6 B Ŷ ST2 I 9 Ignition SW 5 ID1 I 1 Ignition Coil (No. 1) I 2 Ignition Coil (No. 2) I 3 Ignition Coil (No. 3) I 4 Ignition Coil (No. 4) +B +B +B +B 10 (2D) IGF GND IGT2 IGF GND IGT3 IGF GND IGT4 GND W-B G-R 30A AM2 G-R Engine ECU <3-14> Battery Rear Side of the Cylinder Block