

FRONT BODY PILLAR (CUT)

REPLACEMENT

With the cowl top side inner panel removed.



REMOVAL




F24060

30 mm (1.18 in.)


50 mm (1.97 in.)

160 mm (6.30 in.)



INSTALLATION

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.




POINT

1 Before temporarily installing the new parts, weld the [A], [B], [C] and [D] with standard points.

PART NAME

- [A] Rocker Outer Reinforce [B] Front Body Pillar Lower Reinforce
 - C] Front Body Inner Pillar [D] Outer Panel
- 10 mm (0.39 in.) 70 mm (2.76 in.) 85 mm (3.35 in.)



POINT

Inspect the fitting of the front door, front fender and windshield glass, etc., before welding, since this affects the appearance of the finish.

PART NAME

[E] Front Fender Rear Bracket 10 mm (0.39 in.)