14 TOYOTA INNOVA Power Source Power Window * 1 : Before Sep. 2008 Production * 2 : From Sep. 2008 Production 2 3 P 5 Power Window Master SW J31(A), J32(B) Junction Connector I 9 Ignition SW 1 IC1 10 IC1 5 IC1 ③ P 6 Power Window Regulator Motor (Front LH) (* 1) (* 2) 1**(**2**G**) 4 IL1 7 BB1 7 BC1 8 BC1 Power Window (Rear LH) (*2) 9 J33 Junction Connector P 8 Power Window Regulator Motor (Rear LH) P 9 Power Window Regulator Motor (Rear RH) P 7 Power Window Regulator Motor (Front RH)