

Harley-Davidson Forty-Eight Maintenance Checklist (Kilometers)

Interval (km / time)	Task
Every ride	Check tire pressure & condition, oil level, brake fluid, lights, belt tension, and leaks.
Every 8,000 km / 1 year	Change engine oil & filter; inspect brakes; check throttle/clutch free play; clean/replace air filter.
Every 16,000 km	Change primary chaincase fluid; inspect spark plugs.
Every 32,000 km	Change transmission fluid; replace spark plugs; change fork oil.
Every 2 years	Replace brake fluid.
Every 3–5 years	Replace battery if weak; replace tires if 5–7 years old regardless of tread.