PMW3610 Voltage Level Config

3.3V logic

- VIN: 3.3V
- JP1: [**1-2** 3]

1.8V logic

- VIN: (VDD + 0.2V) ~ 5.5V
- JP1: [1 **2-3**]

JP1	Description	
[**1-2** 3]	2 and 1 close, 3 NC	VIO = VIN
[1 **2-3**]	2 and 3 close, 1 NC	VIO = VDD
[**1-2-3**]	1, 2 and 3 close	VIO = VDD = VIN

See example project at **github.com/trentrand/ergonomic-keyboard**