



Technical reference manual
1.0.0

EtherBench

Programming

All along this chapter, you'll see how can the device be accessed, and a technical description of any feature that could be usefull when working with it. For more advanced topics about how the firmware is organized, you can check the **architecture** chapter, which explain choices and show software stack.

Accessing the device

The device can be controlled from different ways, over different mediums:

Interface	USB	Ethernet
File transfer	None*	FTP server
USART Bridge	VCOM 1	None**
Debugging	USB Debugger probe, CMSIS-DAP compatible	Remote debugger probe, CMSIS-DAP compatible
Terminal	VCOM 0	Telnet Shell
SCPI	VCOM 0	Dedicated SCPI port

- * The file transfer can still be done by removing the SD card from the device. But, as a limitation from the filesystem we're using, files can't be copied from the flash to the SD.
- ** This feature can be emulated by the shell terminal. Some commands can perform IO, and thus this is possible. Speed may be affected.