

# TrustNode Edge — Onboarding

*Intended audience: plant operator setting up TrustNode on a Windows machine*

# 1. What you need before you start

- A Windows 10 or 11 machine on the plant network with administrator rights.
- An activation code from your TrustNode contact.
- The IPs and ports of any PLCs / power meters you plan to read.
- Internet access for the initial license activation (the agent can run offline afterwards for up to 30 days).

## 2. Install

Run **TrustNode-Setup-0.1.0.exe**. The installer:

- Asks for administrator rights (UAC prompt).
- Creates C:\ProgramData\TrustNode\edge with restrictive permissions.
- Adds Windows Firewall rules for the backend + optional OPC UA + MQTT sidecars.
- Installs a Start Menu + Desktop shortcut.

## 3. First launch — activate

- Double-click the TrustNode icon. The tray icon appears in the system tray.
- Open the main window. Sign in as admin / admin (you will be asked to change this password immediately).
- Go to **Settings** → **Edge** and paste your activation code. Click Activate.
- The license loads. The Edge page shows your customer name + the list of licensed modules.

## 4. Add a gateway / PLC / meter

- Open **Gateway Configuration**. Click + Add.
- Pick the protocol (Allen-Bradley / Siemens / Modbus / OPC UA / Power meter).
- Enter IP + port. Click Test connection.
- Go to **Tags** and pick which tags to publish to the dashboard and/or the OPC UA / MQTT outbound feeds.
- Open **Dashboard** and drag widgets onto the canvas.

## 5. Sharing access with the team

- Go to **Users and Access Control**. Click + Add user.
- Pick which sections they can see (Module visibility) and which LAN web views they can open (LAN Web Access: Full / Lite / Client View).
- Set a starting password — they will be forced to change it on first login.
- If you want to give them a one-click URL: from the Users table → Lite Access column → click Full, Lite, or Client View to copy a token URL to clipboard. Send it to them by email or chat.

## 6. Customising save locations

Go to **Settings** → **Directories** to redirect reports, exports, logs, and backups to a network share or any other folder. Each row has an Open button (reveals in Explorer) and a Pick button (native folder dialog). Save changes applies the new paths immediately.

## 7. Troubleshooting

| Symptom                                     | Action                                                                                                           |
|---------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| Tray icon never appears                     | Check that the TrustNode-Backend service is running (services.msc). If it's stopped: right-click –> Start.       |
| License is locked / red banner              | Your license file may have been modified or expired. Re-activate from Settings → Edge using a valid license key. |
| LAN URL not reachable from another computer | Settings → Connections → LAN Sharing, confirm the status pill says Running. If it says 'Blocked', click 'Allow'. |
| A LAN user gets 'no access to <variant>'    | Find their user record and tick access_full / access_lite / access_client matching the variant they are using.   |

## 8. Getting help

Open a support ticket with your TrustNode contact. Attach:

- The boot log: %LOCALAPPDATA%\TrustNode\boot-error.log
- The last 200 lines of app\_logs from **Data History** → **Logs**
- A screenshot of **Settings** → **Edge** showing the license status