

# **ADDENDUM**

to

**INSTALLATION INSTRUCTIONS** 

for

# Grant Vortex Pro & Eco Outdoor Modules and Outdoor Combi Boilers

DOC.52 06/01 Rev.00 November 2012

## ATTENTION INSTALLERS - UPDATED INFORMATION!

Your Grant Vortex Outdoor boiler has a recent change that differs from the Installation Instructions supplied with the appliance. This change is part of our continued product improvement process.

Please read this Addendum and use the information in conjunction with the corresponding sections of the Installation Instructions supplied with the boiler.

After commissioning, please leave both the Installation Instructions and this Addendum sheet with the user for future reference.

Instructions for adjusting the position of the flue elbow are as follows:

#### General

The flue elbow is factory fitted to the boiler with the outlet of the elbow facing towards the rear of the boiler.

The elbow is secured in place using a single M8 fixing stud and nut, with the mounting flange sealed to the boiler using a circular neoprene gasket (attached to the top of the heat exchanger).

If the elbow is to be re-positioned to face towards either the left or right side of the boiler – use the following procedure.



### STEP 1

Follow the instructions in the Installation manual (supplied with the boiler) to fit either a) The small cover panel (with the black circular grommet fitted), or b) The black grommet (supplied with the boiler) into the circular hole on the required side of the casing.

#### STEP 2

Using a 13mm spanner, slacken the nut and unscrew to leave approximately 5mm gap between the nut and spacer sleeve.

#### STEP 3

Carefully lift the flue elbow upwards and off the neoprene sealing gasket.

Carefully rotate the flue elbow to face in the required direction (to align with one of the openings in the casing side panels).

#### **IMPORTANT**

Take care not to disturb the spacer or break the mastic seal between the spacer and elbow. If the seal is broken re-seal the spacer to the elbow using high temperature mastic

#### STEP 4

Follow the instructions in the Installation manual (supplied with the boiler) to fit the flue terminal through the casing panel and into the open end of the flue elbow.

#### STEP 5

Ensure the flange is correctly located onto the neoprene gasket and re-tighten the nut.

# **IMPORTANT**

Take care not to break the mastic seal between the spacer and elbow. See note in Step 3 above.





