



Toucan keycap legends — decals

Generated from config/toucan.keymap at fa72dec on 2026-09-20 · SYM number row · print at 100%, no scaling · cut on the dashed line


LEFT HALF



RIGHT HALF



SPARES



WHAT THE MARKS MEAN


- A** `⬆` `→|` `⌫` — The base layer — what the key sends on its own.
- Top-left** — The SYM legend — hold **SYM** (left middle thumb) and press the key.
- SYM / NAV** — **Hold** that thumb for the layer; tap it for the glyph above the word.
- `^` `⌘` — Ctrl and Opt, printed on the edge facing the key you press it with — `^` between S·D and K·L, `⌘` between D·F and J·K.
- `■` — The bar runs under S·D·F and J·K·L: press all three together for `^⌘`.

 50 mm — if this bar measures anything else, the printer scaled the page and the decals will not fit.


# Toucan keycap legends — stencil

Outlines of the same artwork, for tracing onto the caps or cutting a mask.


## LEFT HALF



## RIGHT HALF



## SPARES



## WHAT THE MARKS MEAN

- A — The base layer — what the key sends on its own.
- Top-left — The SYM legend — hold **SYM** (left middle thumb) and press the key.
- SYM / NAV** — Hold that thumb for the layer; tap it for the glyph above the word.
- Ctrl and Opt, printed on the edge facing the key you press it with — ^ between S·D and K·L, between D·F and J·K.
- The bar runs under S·D·F and J·K·L: press all three together for ^.

50 mm — check this before cutting.