



Toucan keycap legends — decals

Generated from config/toucan.keymap at 4f678ef on 2026-09-20 · print at 100%, no scaling · cut on the dashed line


LEFT HALF



RIGHT HALF



SPARES



WHAT THE MARKS MEAN


- A ↕ → ⊠ — The base layer — what the key sends on its own.
- 1 ... 0 — Top-left corner: hold **SYM** (left middle thumb) and press the key.
- SYM** / **NAV** — **Hold** that thumb for the layer; tap it for the glyph above the word.
- ^ ^ — Ctrl and Opt, printed on the edge facing the key you press it with — ^ between S·D and K·L, ^ between D·F and J·K.
- — The bar runs under S·D·F and J·K·L: press all three together for ^ ^.

50 mm — if this bar measures anything else, the printer scaled the page and the decals will not fit.


Toucan keycap legends — stencil

Outlines of the same artwork, for tracing onto the caps or cutting a mask.


LEFT HALF



RIGHT HALF



SPARES



WHAT THE MARKS MEAN

A — The base layer — what the key sends on its own.

1 ... 0 — Top-left corner: hold **SYM** (left middle thumb) and press the key.

SYM / NAV — **Hold** that thumb for the layer; tap it for the glyph above the word.

50 mm — check this before cutting.

— Ctrl and Opt, printed on the edge facing the key you press it with — between S·D and K·L, between D·F and J·K.
 — The bar runs under S·D·F and J·K·L: press all three together for .