Robin DL7F Wash - DMX protocol

Version: 1.5 Mode 1-CMY/RGB, Mode 2 -CMY/RGB reduced, Mode 3 -Seven colours, Mode 4 -Seven colours reduced

Mode/channel		DMX	F attan	Type of		
1	2	3	4	Value	Function	control
1	1	1	1		Pan	
				0 - 255	Pan movement by 540° (128=default)	proportional
2	2	2	2		Pan Fine	
				0 - 255	Fine control of pan movement (0=default)	proportional
3	3	3	3		Tilt	
				0 - 255	Tilt movement by 240° (128=default)	proportional
4	4	4	4		Tilt fine	
				0 - 255	Fine control of tilt movement (0=default)	proportional
5	5	5	5		Pan/Tilt speed , Pan/Tilt time	
				0	Max. speed - tracking mode (0=default)	step
					Pan/Tilt speed	
				1 - 255	Speed from max. to min. (vector mode)	proportional
					Pan/Tilt time	
				1 - 255	Time from 0.1 s to 25.5 sec.	proportional
6	6	6	6		Power/Special functions	
				0 -9	Reserved (0=default)	
					To activate following functions, stop in DMX value for at least 3 s and	
					shutter must be closed at least 3 sec. ("Shutter,Strobe" channel 32/28/40/32 must be at range: 0-31 DMX). Corresponding menu items are	
					temporarily overriden.	
				10-14	DMX input: Wired DMX *	step
				15-19	DMX input: Wireless DMX *	step
					* function is active only 10 seconds after switching the fixture on	200
				20-24	Graphic display On	step
				25-29	Graphic display Off	step
				30-39	Reserved	step
				40-44	Pan/Tilt speed mode	step
				45-49	Pan/Tilt time mode	step
				50-54	Blackout while pan/tilt moving	step
				55-59	Disabled blackout while pan/tilt moving	step
				60-69	Reserved	step
				70-74	Fans mode: Auto	step
				75-79	Fans mode: High	step
				80-84	Dimmer curve: Square law	step
				85-89	Dimmer curve: Linear	step
				90-129	Reserved	
					To activate following functions, stop in DMX value for at least 3 seconds.	
					Fixture reset (except pan/tilt)	
					Pan/Tilt reset	step
				150 - 169		step
				170 - 179		
					Zoom/frost reset	step
					Barndoors/scrim reset	step
					Total fixture reset	step
				210 - 239	Reserved	

	Mode/	channel		DMX	Function	Type of
1	2	3	4	Value	- unction	control
				240	Disable "Theatre mode"	step
				241 - 255	"Theatre mode" - fan noise control from min. to max.	proportiona
7	7	7	7		Colour functions	
				0	No function (0=default)	
					To activate following functions, stop in DMX value for at least 3 seconds.	
					Corresponding menu items are temporarily overriden	
				1-4	Clear extended Special/Color settings* *	step
				5-9	Reserved	
				10-14	UV stability On	step
				15-19 20-24	UV stability Off Wavelenght correction On	step
					-	step
				25-29	Wavelenght correction Off Colour calibration mode On	step
				30-34	Colour calibration mode Off	step
				35-39 40-44	Colour mixing mode: CMY	step
				45-49	Colour mixing mode: RGB	step
				50-54	Colour mixing mode: RGB Colour mixing mode: 7 colours On (mode 3 and 4 only)	step
				55-59	Colour mixing mode 7 colours Off (mode 3 and 4 only)	step
				60-64	Output uniformity On (at selected CRI - (DMX values 151-155))	step
				65-69	Output uniformity Off (at selected CKI - (DIVIX values 131-133))	step
				70-74	Output mode: CRI	step
				75-79	Output mode: Intensity	step
				73-79	Output mode. Intensity	step
					The Tungsten effects influence whites 2700K - 4200K at CTC channel.	
				80-84	Tungsten effect simulation (750W) On	step
				85-89	Tungsten effect simulation (1000W) On	step
				90-94	Tungsten effect simulation (1200W) On	step
				95-99	Tungsten effect simulation (2000W) On	step
				100-104	Tungsten effect simulation (2500W) On	step
				105-109	Tungsten effect simulation Off	step
				110-114	Save user colour	step
					Output consistency (CRI output mode only) up to:	
				115	30°C	step
				116	31°C	step
				117	32°C	step
				118	33°C	step
				119	34°C	step
				120	35°C	step
				121	36°C	step
				122	37°C	step
				123	38°C	step
				124	39°C	step
				125	40°C	step
				126	41°C	step
				127	42°C	step
				128	43°C	step
				129	44°C	step
				130	45°C	step
				131	46°C	step

	Mode/	channel		DMX	F4!	Type of
1	2	3	4	Value	Function	control
				132	47°C	step
				133	48°C	step
				134	49°C	step
				135	50°C	step
				136	51°C	step
				137	52°C	step
				138	53°C	step
				139	54°C	step
				140	55°C	step
				141	56°C	step
				142	57°C	step
				143	58°C	step
				144	59°C	step
				145	60°C	step
				146	61°C	step
				147	62°C	step
				148	63°C	step
				149	64°C	step
				150	65°C	step
				150	CRI selection (CRI output mode only)	зіср
				151	CRI=70	step
				152	CRI=75	step
				153	CRI=80	
				154	CRI=85	step
				155	CRI=90+	step
						step
				156-159	Reserved Chromatic white On	
				160-164		step
				165-169 170-255	Chromatic white Off Reserved	step
		8		170-255	Virtual colour wheel	
8	8	8	8			
				0	No function (0=default)	step .
				1-2	Filter 4 (Medium Bastard Amber)	step
				3-4	Filter 10 (Medium Yellow)	step
				5-6	Filter 19 (Fire)	step
				7-8	Filter 26 (Bright Red)	step
				9-10	Filter 58 (Lavender)	step
				11-12	Filter 68 (Sky Blue)	step
				13-14	Filter 71 (Tokyo Blue)	step
				15-16	Filter 79 (Just Blue)	step
				17-18	Filter 88 (Lime Green)	step
				19-20	Filter 90 (Dark Yellow Green)	step
				21-22	Filter 100 (Spring Yellow)	step
				23-24	Filter 101 (Yellow)	step
				25-26	Filter 102 (Light Amber)	step
				27-28	Filter 103 (Straw)	step
				29-30	Filter 104 (Deep Amber)	step
				31-32	Filter 105 (Orange)	step
				33-34	Filter 106 (Primary Red)	step

	Mode/channel			DMX	Function	Type of
1	2	3	4	Value	Function	control
				35-36	Filter 111 (Dark Pink)	step
				37-38	Filter 115 (Peacock Blue)	step
				39-40	Filter 116 (Medium Blue-Green)	step
				41-42	Filter 117 (Steel Blue)	step
				43-44	Filter 118 (Light Blue)	step
				45-46	Filter 119 (Dark Blue)	step
				47-48	Filter 120 (Deep Blue)	step
				49-50	Filter 121 (Filter Green)	step
				51-52	Filter 128 (Bright Pink)	step
				53-54	Filter 131 (Marine Blue)	step
				55-56	Filter 132 (Medium Blue)	step
				57-58	Filter 134 (Golden Amber)	step
				59-60	Filter 135 (Deep Golden Amber)	step
				61-62	Filter 136 (Pale Lavender)	step
				63-64	Filter 137 (Special Lavender)	step
				65-66	Filter 138 (Pale Green)	step
				67-68	Filter 139 (Primary Green)	step
				69-70	Filter 141 (Bright Blue)	step
				71-72	Filter 147 (Apricot)	step
				73-74	Filter 148 (Bright Rose)	step
				75-76	Filter 152 (Pale Gold)	step
				77-78	Filter 154 (Pale Rose)	step
				79-80	Filter 157 (Pink)	step
				81-82	Filter 158 (Deep Orange)	step
				83-84	Filter 162 (Bastard Amber)	step
				85-86	Filter 164 (Flame Red)	step
				87-88	Filter 165 (Daylight Blue)	step
				89-90	Filter 169 (Lilac Tint)	step
				91-92	Filter 170 (Deep Lavender)	step
				93-94	Filter 172 (Lagoon Blue)	step
				95-96	Filter 179 (Chrome Orange)	step
				97-98	Filter 180 (Dark Lavender)	step
				99-100	Filter 181 (Congo Blue)	step
				101-102	Filter 197 (Alice Blue)	step
				103-104	Filter 201 (Full C.T. Blue)	step
				105-106	Filter 202 (Half C.T. Blue)	step
				107-108	Filter 203 (Quarter C.T. Blue)	step
				109-110	Filter 204 (Full C.T. Orange)	step
				111-112	Filter 205 (Half C.T. Orange)	step
				113-114	Filter 206 (Quarter C.T. Orange)	step
				115-116	Filter 247 (Filter Minus Green)	step
				117-118	Filter 248 (Half Minus Green)	step
				119-120	Filter 281 (Three Quarter C.T. Blue)	step
				121-122	Filter 285 (Three Quarter C.T. Orange)	step
				123-124	Filter 352 (Glacier Blue)	step
				125-126	Filter 353 (Lighter Blue)	step
				127-128	Filter 715 (Cabana Blue)	step
				129-130	Filter 778 (Millennium Gold)	step

	Mode/	channel		DMX	Formalian	Type of
1	2	3	4	Value	Function	control
				131-132	Filter 793 (Vanity Fair)	step
				133-191	Reserved	step
				192-193	Deep Red	step
				194-195	Deep Blue	step
				196-197	Orange	step
				198-199	Green	step
				200-201	Magenta	step
				202-203	Congo Blue	step
				204-205	Pink	step
				206-207	Lavender	step
				208-209	Laser Green	step
				210-211	СТВ	step
				212-213	Minus 1/1 Green	step
				214-215	Minus 1/2 Green	step
				216-217	User colour 1	step
				218-219	User colour 2	step
				220-221	User colour 3	step
				222-223	User colour 4	step
				224-225	User colour 5	step
				226-227	User colour 6	step
				228-229	User colour 7	step
				230-231	User colour 8	step
				232-233	User colour 9	•
				234-235	User colour 10	step
				236-245	Rainbow effect (with fade time) from slow-> fast	step proportiona
				246-255	, , , , , , , , , , , , , , , , , , , ,	
	9	*	*	240-255	Rainbow effect (without fade time) from slow-> fast	proportiona
9	9	T	T	0.255	Cyan/Red(8 bit)	
40	*	*	*	0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportiona
10	,		*	0.255	Cyan/Red(16 bit)	
	10	*	*	0 - 255	Colour saturation control - fine (255=default)	proportiona
11	10	т	т		Magenta/Green (8 bit)	
	*	*	*	0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportiona
12	*	*	*		Magenta/Green (16 bit)	
	<u> </u>			0 - 255	Colour saturation control - fine (255=default)	proportiona
13	11	*	*		Yellow/Blue (8 bit)	
				0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportiona
14	*	*	*		Yellow/Blue (16 bit)	
				0 - 255	Colour saturation control - fine (255=default)	proportiona
*	*	9	9		Red (8 bit)	
	<u> </u>			0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportiona
*	*	10	*	_	Red (16bit)	
				0 - 255	Colour saturation control - fine (255=default)	proportiona
*	*	11	10		Green (8 bit)	
				0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportiona
*	*	12	*		Green (16bit)	
				0 - 255	Colour saturation control - fine (255=default)	proportiona
*	*	13	11		Blue (8 bit)	
	1			0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportiona

	Mode/	channel		DMX	Franchicus	Type of		
1	2	3	4	Value	Function	control		
*	*	14	*		Blue(16bit)			
				0 - 255	Colour saturation control - fine (255=default)	proportional		
*	*	15	12		Amber (8 bit)			
				0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportional		
*	*	16	*		Amber (16bit)	<u> </u>		
				0 - 255	Colour saturation control - fine (255=default)	proportional		
*	*	17	13		Cyan (8 bit)	1		
				0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportional		
*	*	18	*		Cyan (16bit)			
				0 - 255	Colour saturation control - fine (255=default)	proportiona		
*	*	19	14		Congo blue (8 bit)			
				0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportional		
*	*	20	*		Congo blue (16bit)			
				0 - 255	Colour saturation control - fine (255=default)	proportional		
*	*	21	15		Light green (8 bit)	1		
				0 - 255	Colour saturation control - coarse 0-100% (255=default)	proportiona		
*	*	22	*		Light green (16bit)	<u> </u>		
				0 - 255	colour saturation control - fine (255=default)	proportiona		
15	12	23	16		Colour temperature correction (CTC)	1 '		
				0-4	8000K	step		
				5-64	Colour temperature changing 7978K ->6622K (22K /1 DMX)	proportiona		
				65	6600K	step		
				66-109	Colour temperature changing 6578K ->5622K (22K/1 DMX)	proportiona		
				110	5600K (default)	step		
				111-179	Colour temperature changing 5580K ->4220K (20K/1 DMX)	proportiona		
				180	4200K	step		
				181-229	Colour temperature changing 4180K ->3220K (20K/1 DMX)	proportiona		
				230	3200K	step		
				231-254	Colour temperature changing 3180K ->2720K (20K /1 DMX)	proportiona		
				255	2700K	step		
16	13	24	17	233	Green correction	эсер		
				0	Uncorrected white	step		
				1-127	Minus green> uncorrected white	proportiona		
				128	Uncorrected white (default)	step		
				129-254	Uncorrected white> Plus green	proportiona		
				255	Uncorrected white	step		
17	14	25	18	233	Colour mix control	зієр		
			10		Defines relation between colour channels			
					"Virtual" = Virtual Colours (Virtual Colour Wheel)			
					"Colour mix" = Colour channels (RGB/CMY/R,G,B,A,C,Congo Blue,Light			
					green/CTC/ Green Correction)			
					Range 0-69 DMX - only for Output mode: CRI			
				0-9	Virtual colours ("Virtual" has priority)	step		
				10-19	Maximum mode (highest values have priority)	step		
				20-29	Minimum mode (lowest values have priority)	step		
				30-39	Multiply mode (multiply Virtual and Colour mix)	step		
				40-49	Addition mode (Virtual + Colour mix) /45=default/	step		
				50-59				

	Mode/	channel		DMX	F attau	Type of
1	2	3 4		Value	Function	control
				60-69	Inverted Subtraction mode (Virtual –Colour mix)	step
				70-79	White Point Off (CTC+Green Cor.+Virtual Col.Wheel deactivated)	step
				80-128	Reserved	
					Range 129-255 DMX - for both Output modes: CRI and Intensity	
				129	Virtual colours ("Virtual" has priority)	step
				130-254	Crossfade (crossfade between Virtual and Colour mix)	proportiona
				255	Colour channels ("Colour mix" has priority)	step
18	15	26	19		Barndoors + Zoom + Frost time	
				0	Function is off (default)	step
				1 - 255	Time of barndoors, zoom and frost movement (0.1 sec>25.5 sec.)	proportiona
19	16	27	20		Scrim positioning	
		0 No function (default)		step		
				1-255	Scrim inserting (0.5%>100%)	proportiona
20	17	28	21		Scrim indexing	p. operation
				0-255	Scrim indexing 0°-360° /1.4° per 1 DMX/ (128=default)	
				0 233	(0 DMX=0°, 64DMX=90°, 128DMX=180°, 192DMX=270°, 255DMX=360°)	proportiona
21	18	29	22		Frost	proportiona
21	10	23		0 - 255	Frost from 0% to 100% (0=default)	proportiona
22	19	30	23	0 - 233	Zoom	proportiona
22	19	30	25	0 - 255	Zoom from max. to min.beam angle (128=default)	proportiona
23	*	31	*	0-233	Zoom - fine	proportiona
23		31		0-255	Fine zooming (0=default)	proportiona
24	20	32	24	0-233	Edge colour correction	proportiona
	20	- 52		0-255	Fine correction of the colour of the image edge (0=default)	proportiona
25	21	33	25	0 233	Barndoors rotation	proportiona
		- 55		0-255	Rotation 0°> 180° (128=default)	proportiona
26	22	34	26	0 233	Barndoor 1 - momement	proportiona
				0-255	Movement from Outward to Inward (0=default)	proportiona
27	23	35	27	0 200	Barndoor 2 - momement	рторогана
				0-255	Movement from Outward to Inward (0=default)	proportiona
28	24	36	28	0 233	Barndoor 3 - momement	proportiona
				0-255	Movement from Outward to Inward (0=default)	proportiona
29	25	37	29	0 200	Barndoor 4 - momement	p. oportiona
				0-255	Movement from Outward to Inward (0=default)	proportiona
30	26	38	30		Barndoors macros	proportion
				0-3	No function (0=default)	
				4-7	Macro 1	step
				8-11	Macro 2	step
				12-15	Macro 3	step
				16-19	Macro 4	step
				20-23	Macro 5	step
				24-27	Macro 6	step
				28-31	Macro 7	step
				32-35	Macro 8	step
				36-39	Macro 9	step
				40-43	Macro 10	step
				44-47	Macro 11	step

	e/channel		DMX	Function	Type of
2	3	4	Value	1 4.101.01.	control
			48-51	Macro 12	step
			52-55	Macro 13	step
			56-59	Macro 14	step
			60-63	Macro 15	step
			64-67	Macro 16	step
			68-71	Macro 17	step
			72-75	Macro 18	step
			76-79	Macro 19	step
			80-83	Macro 20	step
			84-87	Macro 21	step
			88-91	Macro 22	step
			92-95	Macro 23	step
			96-99	Macro 24	step
			100-103	Macro 25	step
			104-107	Macro 26	step
			108-111	Macro 27	step
			112-115	Macro 28	step
			116-119	Macro 29	step
			120-123	Macro 30	step
				Macro 31	step
			128-131	Macro 32	step
			132-135	Macro 33	step
			136-139	Macro 34	step
			140-143	Macro 35	step
			-	Macro 36	step
			148-151	Macro 37	step
				Macro 38	step
			156-159	Macro 39	step
				Macro 40	step
				Macro 41	step
				Reserved	эсер
L 27	39	31	100 233	Barndoors macro speed	
		31	0- 255	Speed from slow to fast. (128=default)	proportiona
2 28	40	32	0 200	Shutter/ strobe	proportional
			0 - 31	Shutter closed	step
			32 - 63	Shutter open (32=default)	step
			64 - 95	Strobe-effect from slow to fast	proportiona
				Shutter open	step
				Opening pulse in sequences from slow to fast	proportiona
				Closing pulse in sequences from fast to slow	proportiona
				Shutter open	step
				Random strobe-effect from slow to fast	proportiona
				Shutter open	step
3 29	41	33	224 233	Dimmer intensity	31EP
		- 33	0 - 255	Dimmer intensity from 0% to 100% (0=default)	proportiona
*	42	*	0 - 233	Dimmer intensity - fine	proportiona
·	72		0 - 255		proportiona
* *	42	*	0 - 255	Fine dimming (0=default)	

	Mode/d	hannel		DMX	Function	Type of
1	2	3	4	Value	Function	control
**	Resets f	ollowin	g items to	their men	u values:	
	Dimmer	curve				
	Colour calibration mode		n mode			
	Colour m	nixing m	ode			
	Colour mixing mode 7 co			ours		
	Output u	ıniformi	ity On			
	Output u	ıniformi	ity			
	Output n	node				
	Output c	onsiste	ncy			
	CRI selec	tion				
	UV stabil	ity				
	Wavelength correction					
Copyr	ight © 20	16-201	.7 Robe L	ighting s.r.	o All rights reserved	
All Spe	ecification	ıs subje	ect to cha	ange witho	ut notice	

	Colour m	acros on V	irtual Colou	r Wheel			
Colour name	Red DMX	Green DMX	Blue DMX	Amber DMX	Cyan DMX	Congo Blue DMX	Light Green DMX
Filter 4 (Medium Bastard Amber)	255	125	27	255	0	0	88
Filter 10 (Medium Yellow)	255	65	0	255	0	0	170
Filter 19 (Fire)	255	0	0	255	0	0	5
Filter 26 (Bright Red)	255	0	0	16	0	0	0
Filter 58 (Lavender)	255	0	168	255	0	0	47
Filter 68 (Sky Blue)	111	0	255	0	255	0	0
Filter 71 (Tokyo Blue)	0	0	255	0	10	0	0
Filter 79 (Just Blue)	108	0	255	0	255	0	0
Filter 88 (Lime Green)	255	0	0	174	255	0	255
Filter 90 (Dark Yellow Green)	0	128	0	0	255	0	255
Filter 100 (Spring Yellow)	255	0	0	255	0	0	255
Filter 101 (Yellow)	255	0	0	255	0	0	189
Filter 102 (Light Amber)	255	0	16	255	0	0	206
Filter 103 (Straw)	255	255	16	255	0	0	90
Filter 104 (Deep Amber)	255	0	0	255	0	0	151
Filter 105 (Orange)	255	0	0	255	0	0	77
Filter 106 (Primary Red)	255	0	0	141	0	0	0
Filter 111 (Dark Pink)	255	0	28	255	0	0	82
Filter 115 (Peacock Blue)	0	255	133	0	255	0	194
Filter 116 (Medium Blue-Green)	0	255	68	0	255	0	116
Filter 117 (Steel Blue)	131	200	114	154	255	0	169
Filter 118 (Light Blue)	39	255	115	0	255	0	91
Filter 119 (Dark Blue)	0	43	255	0	255	0	0
Filter 120 (Deep Blue)	26	0	255	0	255	0	0
Filter 121 (Filter Green)	111	255	0	255	0	0	255
Filter 128 (Bright Pink)	255	0	26	156	0	0	0
Filter 131 (Marine Blue)	27	0	143	49	255	0	134
Filter 132 (Medium Blue)	27	255	255	0	255	0	0
Filter 134 (Golden Amber)	255	200	0	255	0	0	0
Filter 135 (Deep Golden Amber)	255	0	0	255	0	0	30
Filter 136 (Pale Lavender)	255	0	122	255	255	0	0
Filter 137 (Special Lavender)	255	0	122	255	255	0	99
Filter 138 (Pale Green)	255	255	22	255	0	0	255
Filter 139 (Primary Green)	0	255	0	0	0	0	60
Filter 141 (Bright Blue)	0	255	255	0	255	0	116
Filter 147 (Apricot)	255	0	7	255	0	0	138
Filter 148 (Bright Rose)	255	0	13	255	0	0	24
Filter 152 (Pale Gold)	255	0	28	255	0	0	133
Filter 154 (Pale Rose)	255	0	36	255	0	0	133
Filter 157 (Pink)	255	0	13	255	0	0	39
Filter 158 (Deep Orange)	255	0	0	255	0	0	46
Filter 162 (Bastard Amber)	255	255	26	255	0	0	66
Filter 164 (Flame Red)	255	0	0	255	0	0	0
Filter 165 (Daylight Blue)	71	255	255	0	255	0	0
Filter 169 (Lilac Tint)	255	0	62	255	255	0	0
Filter 170 (Deep Lavender)	255	0	129	255	255	0	0
inter 170 (Deep Lavender)	255	U	173	255	255	U	U

Colour name	Red DMX	Green DMX	Blue DMX	Amber DMX	Cyan DMX	Congo Blue DMX	Light Green DMX
Filter 172 (Lagoon Blue)	0	0	255	0	255	0	255
Filter 179 (Chrome Orange)	255	0	0	255	0	0	135
Filter 180 (Dark Lavender)	100	0	255	47	120	0	0
Filter 181 (Congo Blue)	6	0	16	0	0	255	0
Filter 197 (Alice Blue)	36	36	255	36	255	0	0
Filter 201 (Full C.T. Blue)	118	36	255	36	255	0	255
Filter 202 (Half C.T. Blue)	146	133	255	130	255	0	141
Filter 203 (Quarter C.T. Blue)	255	255	202	255	255	0	255
Filter 204 (Full C.T. Orange)	255	125	0	255	0	0	49
Filter 205 (Half C.T. Orange)	255	125	21	255	31	0	111
Filter 206 (Quarter C.T. Orange)	255	125	64	255	31	0	111
Filter 247 (Filter Minus Green)	255	0	107	255	141	0	70
Filter 248 (Half Minus Green)	255	0	107	255	255	0	136
Filter 281 (Three Quarter C.T. Blue)	112	0	219	95	255	0	255
Filter 285 (Three Quarter C.T. Orange)	255	0	0	255	0	0	152
Filter 352 (Glacier Blue)	51	90	255	0	255	0	164
Filter 353 (Lighter Blue)	51	255	255	0	255	0	255
Filter 715 (Cabana Blue)	21	0	255	0	255	0	0
Filter 778 (Millennium Gold)	255	0	0	255	0	0	50
Filter 793 (Vanity Fair)	255	0	84	255	0	0	0
Deep Red	255	0	0	0	0	0	0
Deep Blue	0	0	255	0	0	15	0
Orange	44	18	0	255	0	0	0
Green	0	255	0	0	66	0	18
Magenta	255	0	209	299	0	0	5
Congo Blue	4	0	5	0	0	255	0
Pink	255	0	175	255	0	0	89
Lavender	255	172	255	100	255	0	254
Laser Green	122	255	0	255	140	0	254
СТВ	229	255	156	255	255	0	255
Minus 1/1 Green	255	247	151	255	0	0	255
Minus 1/2 Green	255	255	128	255	124	0	255