ELATION | PLATINUM SEVENTM |

dmx traits

Supports Software Versions: ≥ 1.1.3 Features are subject to change without any prior written notice.

*Rotation direction (Clockwise or Counterclockwise) of effects depends on orientation of the fixture head and Pan/Tilt settings.

DMX Channel Values / Functions Version 1 - (40 DMX Channels)

| MODE / CHANNEL | | | VALUE | FUNCTION |
|----------------|--|----------|--------|---|
| BASIC | STAND | EXTEND | V ALUE | FUNCTION |
| 1 | 1 | 1 | | PAN MOVEMENT [8 BIT] |
| 1 | 1 | ' [| 0-255 | PAN Movement |
| 2 | 2 | 2 | | PAN FINE MOVEMENT [16 BIT] |
| | | | 0-255 | Fine Control of PAN Movement |
| 3 4 5 | 2 | 2 | | TILT MOVEMENT [8 BIT] |
| | 3 | 3 | 0-255 | TILT Movement |
| | | | | TILT MOVEMENT [16 BIT] |
| | 4 | 4 | 0-255 | Fine Control of TILT Movement |
| | _ | | | RED [ALL LEDs] |
| | 5 | | 0-255 | Red (0-Black - 255-100%) |
| | , | | | RED FINE [ALL LEDs] |
| | 6 | | 0-255 | Red FINE Adjustment |
| | | | | GREEN [ALL LEDs] |
| 6 | 7 | | 0-255 | Green (0-Black - 255-100%) |
| | | 1 | | GREEN FINE [ALL LEDs] |
| | 8 | | 0-255 | Green FINE Adjustment |
| | | | | BLUE [ALL LEDs] |
| 7 | 9 | | 0-255 | Blue (0-Black - 255-100%) |
| | | | 0 200 | BLUE FINE [ALL LEDs] |
| | 10 | | 0-255 | Blue FINE Adjustment |
| | | + | 0 200 | WHITE [ALL LEDs] |
| 8 | 11 | <u> </u> | 0-255 | White (0-Black - 255-100%) |
| | | | 0-200 | WHITE FINE [ALL LEDS] |
| | 12 | l ⊦ | 0-255 | White FINE Adjustment |
| | | | 0-200 | AMBER [ALL LEDs] |
| 9 | 13 | I ⊢ | 0-255 | Amber (0-Black - 255-100%) |
| | | | 0-233 | |
| | 14 | <u> </u> | 0-255 | AMBER FINE [ALL LEDs] Amber FINE Adjustment |
| | | - | 0-233 | CYAN [ALL LEDs] |
| 10 | 15 | | 0-255 | Cyan (0-Black - 255-100%) |
| | | | 0-233 | CYAN FINE [ALL LEDs] |
| | 16 | | 0-255 | Cyan FINE (ALL LEDS) Cyan FINE Adjustment |
| | | | 0-233 | VIOLET [ALL LEDs] |
| 11 | 17 | l ⊦ | 0-255 | Violet (0-Black - 255-100%) |
| | | - | 0-255 | VIOLET FINE [ALL LEDs] |
| | 18 | <u> </u> | 0.055 | Violet FINE Adjustment |
| | | | 0-255 | RED [LED GROUP 1] |
| | | 5 | 0-255 | Red (0-Black - 255-100%) |
| | | | 0-200 | , |
| | | 6 - | 0.055 | GREEN [LED GROUP 1] |
| | | | 0-255 | Green (0-Black - 255-100%) |
| | | 7 - | 0.055 | BLUE [LED GROUP 1] |
| | | | 0-255 | Blue (0-Black - 255-100%) |
| | | 8 - | 0.055 | WHITE [LED GROUP 1] |
| | | | 0-255 | White (0-Black - 255-100%) |
| | | 9 | 0.0 | AMBER [LED GROUP 1] |
| | | | 0-255 | Amber (0-Black - 255-100%) |
| | | 10 | | CYAN [LED GROUP 1] |
| | | | 0-255 | Cyan (0-Black - 255-100%) |
| | | 11 | | VIOLET [LED GROUP 1] |
| | | I '' | 0-255 | Violet (0-Black - 255-100%) |

©ELATION Professional 1 www.elationlighting.com

ELATION© PLATINUM SEVEN™ DMX Channel Values / Functions Version 1 - (40 DMX Channels)

Supports Software Versions: ≥ 1.1.3

Features are subject to change without any prior written notice.

| MODE / CHANNEL | | | FUNCTION | |
|----------------|-------|--------|----------|--------------------------------------|
| BASIC | STAND | EXTEND | VALUE | FUNCTION |
| | | 10 | | RED [LED GROUP 2] |
| | | 12 | 0-255 | Red (0-Black - 255-100%) |
| | | 13 | | GREEN [LED GROUP 2] |
| | | 13 | 0-255 | Green (0-Black - 255-100%) |
| | | 14 | | BLUE [LED GROUP 2] |
| | | 14 | 0-255 | Blue (0-Black - 255-100%) |
| | | 15 | | WHITE [LED GROUP 2] |
| | | 15 | 0-255 | White (0-Black - 255-100%) |
| | | 16 | | AMBER [LED GROUP 2] |
| | | 10 | 0-255 | Amber (0-Black - 255-100%) |
| | | 17 | | CYAN [LED GROUP 2] |
| | | 17 | 0-255 | Cyan (0-Black - 255-100%) |
| | | 18 | | VIOLET [LED GROUP 2] |
| | | 10 | 0-255 | Violet (0-Black - 255-100%) |
| | | 19 | | RED [LED GROUP 3] |
| | | 19 | 0-255 | Red (0-Black - 255-100%) |
| | | 20 | | GREEN [LED GROUP 3] |
| | | 20 | 0-255 | Green (0-Black - 255-100%) |
| | | 21 | | BLUE [LED GROUP 3] |
| | | 21 | 0-255 | Blue (0-Black - 255-100%) |
| | | 22 | | WHITE [LED GROUP 3] |
| | | 22 | 0-255 | White (0-Black - 255-100%) |
| | | 23 | | AMBER [LED GROUP 3] |
| | | 20 | 0-255 | Amber (0-Black - 255-100%) |
| | | 24 | | CYAN [LED GROUP 3] |
| | | 24 | 0-255 | Cyan (0-Black - 255-100%) |
| | | 25 | | VIOLET [LED GROUP 3] |
| | | 20 | 0-255 | Violet (0-Black - 255-100%) |
| | 19 | 26 | | COLOR MACROS |
| | | | 0-7 | NO FUNCTION |
| | | | 8-39 | From RED to YELLOW |
| | | | 40-71 | From YELLOW to GREEN |
| 12 | | | 72-103 | From GREEN to CYAN |
| 12 | | | 104-135 | From CYAN to BLUE |
| | | | 136-167 | From BLUE to MAGENA |
| | | | 168-199 | From MAGENTA to RED |
| | | | 200-231 | From RED to WHITE |
| | | | 232-255 | Corssfading Colors from SLOW to FAST |

ELATION© PLATINUM SEVEN™ DMX Channel Values / Functions Version 1 - (40 DMX Channels)

Supports Software Versions: ≥ 1.1.3

Features are subject to change without any prior written notice.
*Rotation direction (Clockwise or Counterclockwise) of effects depends on orientation of the fixture head and Pan/Tilt settings.

| BASIC | DE / CHAN | EXTEND | VALUE | FUNCTION |
|-------|-----------|---------|---------|-----------------------------------|
| DAGIO | VIAILE | EXILITE | | COLOR PRESETS |
| | | | 0-4 | NO FUNCTION |
| | | | 5-9 | WHITE 2700K |
| | | | 10-14 | WHITE 3200K |
| | | | 15-19 | WHITE 4300K |
| | | | 20-24 | WHITE 5600K |
| | | | 25-29 | WHITE 6500K |
| | | | 30-34 | WHITE 8000K |
| | | | 35-39 | RED |
| | | | 40-44 | GREEN |
| | | | 45-49 | BLUE |
| | | | 50-54 | NATURAL WHITE |
| | | | 55-59 | FULL WHITE |
| | | | 60-64 | YELLOW |
| | | | 65-69 | MAGENTA |
| | | | 70-74 | CYAN |
| | 20 | | 75-79 | SALMON |
| 13 | | 27 | 80-84 | TURQUOISE |
| | | | 85-89 | LIGHT GREEN |
| | | | 90-94 | STEEL BLUE |
| | | | 95-99 | ORANGE |
| | | | 100-104 | STRAW |
| | | | 105-109 | PALE LAVANDER |
| | | l - | 110-114 | PINK |
| | | - | 115-119 | RED/WHITE |
| | | | 120-124 | GREEN/RED |
| | | | 125-129 | BLUE/RED |
| | | - | 130-134 | WHITE/RED |
| | | l - | 135-139 | WHITE/PINK |
| | | - | 140-144 | WHITE/TURQUOISE |
| | | l ⊢ | 145-149 | SMALL RED/WHITE |
| | | - | 150-154 | CRI=85 |
| | | - | | |
| | | - | 155-159 | CRI=90 |
| | | | 160-164 | CRI=95 |
| | | | 165-255 | RESERVED |
| 14 | 21 | 28 | 0.055 | COLOR PRESETS DIMMER |
| | | | 0-255 | Dimmer 0 to 100% |
| | | | 0.01 | SHUTTER, STROBE |
| | | | 0-31 | Shutter CLOSED |
| | | I - | 32-63 | Shutter OPEN (LEDs ON) |
| 1.5 | 00 | | 64-95 | Strobe Effect SLOW to FAST |
| 15 | 22 | 29 | 96-127 | Shutter OPEN (LEDs ON) |
| | | | 128-159 | Pulse Effect In Sequences |
| | | | 160-191 | Shutter OPEN (LEDs ON) |
| | | | 192-223 | Random Strobe Effect SLOW to FAST |
| | | | 224-255 | Shutter OPEN (LEDs ON) |
| 16 | 23 | 30 | | DIMMER INTENSITY |
| | | | 0-255 | Dimmer 0 to 100% |
| | | 31 | | DIMMER INTENSITY FINE |
| | | , , , | 0-255 | Dimmer FINE Adjustment |
| | | | | DIMMER MODES |
| | | | 0-20 | Standard |
| | 24 | 32 | 21-40 | Stage |
| 17 | | | 41-60 | TV |
| | | Γ | 61-80 | Architectural |
| | | | 81-100 | Theatre |
| | | ı F | 101-255 | Default to Setting on Fixture |

ELATION© PLATINUM SEVEN™ DMX Channel Values / Functions Version 1 - (40 DMX Channels)

Supports Software Versions: ≥ 1.1.3

Features are subject to change without any prior written notice. *Rotation direction (Clockwise or Counterclockwise) of effects depends on orientation of the fixture head and Pan/Tilt settings.

| MODE / CHANNEL | | | | e) of effects depends on orientation of the fixture head and Pan/Tilt settings. |
|----------------|-------|------------|---------|---|
| BASIC | STAND | EXTEND | VALUE | FUNCTION |
| 10 | 25 | 33 | | MOTORIZED ZOOM |
| 18 | 20 | 33 | 0-255 | ZOOM Adjustment from SMALL to BIG |
| | | 2.4 | | MOTORIZED ZOOM FINE |
| | | 34 | 0-255 | ZOOM FINE Adjustment |
| | | | | CHASE PATTERNS |
| | | l l | 0-14 | NO FUNCTION (LEDs OFF) |
| | | l F | 15-30 | Chase 1 |
| | | | 31-46 | Chase 2 |
| | | | 47-62 | Chase 3 |
| | | - | 63-78 | Chase 4 |
| | | | 79-94 | Chase 5 |
| | | 35 | 95-110 | Chase 6 |
| 19 | 26 | | 111-126 | Chase 7 |
| | | | 127-142 | Chase 8 |
| | | | 143-158 | Chase 9 |
| | | l | 159-174 | Chase 10 |
| | | l - | 175-190 | Chase 11 |
| | | | 191-206 | Chase 12 |
| | | | 207-222 | Chase 13 |
| | | l ⊦ | 223-238 | Chase 14 |
| | | I ⊢ | 239-255 | Chase 15 |
| | | | 239-233 | |
| | | ⊦ | 0.105 | CHASE PATTERN SPEED |
| 20 | 27 | 36 | 0-125 | *Counterclockwise Chase Speed FAST to SLOW |
| | | _ | 126-130 | STOP (Speed = 0) |
| | | | 131-255 | *Clockwise Chase Speed SLOW to FAST |
| 21 | 28 | 37 | | CHASE FADE |
| | | | 0-255 | Chase FADE |
| | | l | | COLOR MODE - WHITE BALANCE |
| | 29 | | 0-189 | NO FUNCTION |
| 22 | | 38 | 190-254 | EDIT a New WHITE BALANCE Setting |
| | | | 255 | SAVE New WHITE BALANCE Setting to Fixture(s) |
| | | | | *NOTE: DMX Value 91-93 must first be selected on |
| | | | | CH24 (Basic), CH31 (Stand), or CH40 (Extend) to enable feature. |
| | | l <u>L</u> | | PAN / TILT MOVEMENT SPEED |
| 23 | 30 | 39 | 0-225 | MAX to MIN Speed |
| 20 | | | 226-235 | Blackout by Movement |
| | | | 236-255 | NO FUNCTION |
| | | | | SPECIAL FUNCTIONS / INTERNAL PROGRAMS |
| | | | 0-79 | Color Change Normal |
| | | | 80-84 | ALL MOTOR RESET |
| | | | 85-87 | SCAN MOTOR RESET |
| | | | 88-90 | SILENT MODE ON |
| | | Ι Γ | 91-93 | EDIT and SAVE WHITE BALANCE ENABLED |
| | 31 | 40 | 94-96 | SILENT MODE OFF |
| 24 | | | 97-99 | OTHER MOTORS RESET |
| | | | 100-119 | Internal Program 1 (Scene 1-8) |
| | | | 120-139 | Internal Program 2 (Scene 9-16) |
| | | | 140-159 | Internal Program 3 (Scene 17-24) |
| | | | 160-179 | Internal Program 4 (Scene 25-32) |
| | | | 180-199 | Internal Program 5 (Scene 33-40) |
| | | | 200-219 | Internal Program 6 (Scene 41-48) |
| | 1 | I ⊢ | 220-239 | Internal Program 7 (Scene 49-56) |

Elation Professional USA | 6122 S. Eastern Ave. | Los Angeles, CA. 90040 323-582-3322 | 323-832-9142 fax | www.elationlighting.com | info@elationlighting.com

Elation Professional B.V. | Junostraat 2 | 6468 EW Kerkrade, The Netherlands +31 45 546 85 66 | +31 45 546 85 96 fax | www.elationlighting.eu | info@elationlighting.eu

LED GROUPS

