## SERVICE SCHEDULE

SR. NO.	OPERATION	FREQUENCY (In km)	PDI	1500	15000	30000	45000	00009	75000	00006	105000
13	Replace air cleaner element	45000km					•			•	
14	Inspect vacuum hose connection and rectify if necessary	15000 km			•	•	•	•	•	•	•
15	Replace EVRV filters	15000 km			•	•	•	•	•	•	•
16	Vacuum hoses for EVR, EGR, Turbo charger, Throttle (if applicable) to be replaced	60000km						•			П
	ENGINE ( 4 SP TURBO)										
1.	Check service indicator red band as per recommended procedure & replace element if necessary.	Every Service		•	•	•	•	•	•	•	•
2.	Change engine Oil and Oil filter. Use APICF4+MB228.3 or Higher grade Engine Oil.  Every 15000 km OR 1 Year whichever is earlier	15000 km			•	•	•	•	•	•	•
3.	Check All accessory Drive belts, adjust tension if required, change if damaged Replace every 2 year OR 45000 kms whichever is earlier	Every Service		•	•	•	•	•	•	•	•
4.	Drain water from fuel pre filter	Every Service		•	•	•	•	•	•	•	•
5.	Change fuel pre filter (cartridge)	15000 km			•	•	•	•	•	•	•
6.	Change secondary fuel filter (cartridge)	30000km				•		•		•	
7.	Check & adjust valve clearance	15000 km			•	•	•	•	•	•	•
8.	Replace air filter element (OR if RED band appears on Service Indicator)	45000km					•			•	
9.	Clean breather	30000km				•		•		•	
10.	Change vacuum hoses of Vacuum Modulator, Turbocharger, EGR valve & throttle valve OR 4 Years whichever is earlier	60000km						•			
	GEAR BOX										
1	Change oil in gear box (First at 45000 km)	90000 km					•				
2	Clean breather in gear box	Every Oil Change					•				