Power Socket:

A power socket is provided on the central console below music system. This can be used connecting loads upto 10A maximum. To use this socket, remove the cap first.

/!\ CAUTION

Always keep this socket covered with the cap when not in use.



Power Socket

Mobile Holder:

A mobile holder is provided on the central console below music system and beside of power socket. Place your mobile inside the mobile holder for charging purpose while driving.



Mobile Holder