

WIPER CONTROL LEVER - LEFT



- A. Wiper 'OFF' position
- **Slow Wipe**
- Fast Wipe
- Intermittent wipe *
- E. Pull up for windshield wipe (Flick Wipe Spring Return)
- F. Press side knob for wash
- Rotate selector to set delay timing for intermittent wipe

LIGHTS CONTROL LEVER - RIGHT



- B. Position lamp 'ON'
- C. Position lamp & head lamp 'ON'
- D. Push down the lever for high beam
- E. Pull up the lever (spring return) for high beam flash
- F. Lane change left (self cancelling)
- G. Side Indicator LH
- H. Lane change right (self cancelling)
- I. Side Indicator RH