
VEHICLE JACK & TOOLS HANDLING

Vehicle Jack & Tools

Vehicle tool bag, jack and handle is kept below driver's seat. Jack is mounted on floor over studs by wing nuts screwed on them.



Jack & tools location (Below driver's seat)



Locking Wing Nuts