ZLT M36 Frequency Configuration Guide

1. Connect to router from compatible device
2. Type in IP address **192.168.0.1** into Google chrome to access the router login page

For Samsung users, alternatively you can also get shortcut through **Manage router** as seen below





3. Enter username and password which by default will be **admin**



4. Click on options icon (Top left corner) and navigate to **Wi-Fi settings**



5. Select **Advanced settings**



6. Change current frequency band from **5GHz** to **2.4GHz**





7. Click **Apply** then setting will be saved



//FINISH//