oDesktop

GetDistributedAnalysisMachines

AddMessageClearMessagesCloseAllWindowsCloseProjectCloseProjectNoForceDeleteProjectDeleteRegistryEntryDoesRegistryValueExistDownloadJobResultsEnableAutoSaveExportOptionsFilesGetActiveProjectGetAutoSaveEnabledGetBuildDateTimeStringGetDefaultUnit

GetGDIObjectCountGetLibraryDirectoryGetLocalizationHelperGetMessagesGetPersonalLibDirectoryGetProcessIDGetProjectDirectoryGetProjectListGetProjects

GetRegistryInt GetRegistryString GetRunningInstancesMgr GetScriptingToolsHelper GetSysLibDirectory GetTempDirectory

GetDistributedAnalysisMachinesForDesignType

GetExeDir

GetTool GetUserLibDirectory GetVersion

LaunchJobMonitorNewProjectOpenAndConvertProjectOpenMultipleProjectsOpenProjectOpenProjectWithConversionPageSetupPauseRecordingPauseScript

RefreshJobMonitor Print QuitApplication RestoreWindow ResetLogging RestoreProjectArchive ResumeRecording RunACTWizardScript RunProgram RunScript RunScriptWithArguments SelectScheduler SetActiveProjectByPath SetLibraryDirectory SetActiveProject SetProjectDirectory SetRegistryFromFile SetRegistryInt

SetRegistryString SetTempDirectory ShowDockingWindow

Sleep SubmitJob TileWindows

oProject

AddDatasetAddMaterialAnalyzeAllChangePropertyClearMessagesCloneMaterialCloseCopyDesignCutDesign

DeleteDataset DeleteDesign DeleteToolObject EditDataset EditMaterial ExportDataset ExportMaterial GetActiveDesign GetArrayVariables GetChildNames GetChildObject GetChildTypes GetConfigurableData GetDefinitionManager GetDependentFiles GetEDBHandle GetDesign GetDesigns GetLegacyName GetName GetObjPath GetPath GetPropNames GetPropValue **GetProperties** GetPropertyValue GetTopDesignList GetVariableValue GetVariables ImportDataset InsertDesign InsertDesignWithWorkflow InsertToolObject

Paste PasteDesignBlock Redo

RemoveAllUnusedDefinitions RemoveMaterial RemoveUnusedDefinitions

Rename Save SaveAs

SaveAsStandAloneProject SaveProjectArchive SetActiveDefinitionEditor

SetPropValue SetPropertyValue

SetVariableValue SimulateAll Undo

UpdateDefinitions

SetActiveDesign

oDefinitionManager

AddComponentAddDatasetAddFootprintAddMaterialAddPadstackAddScriptAddSurfaceMaterialAddSymbolChangePropertyCloneMaterialCreateComponentDataDeleteDataset

DoesMaterialExist DoesSurfaceMaterialExist EditComponent

EditDataset EditFootprint EditMaterial

EditPadstackEditScriptEditSurfaceMaterialEditSymbolExportComponentExportDatasetExportFootprintExportMaterialExportPadstackExportScriptExportSurfaceMaterialExportSymbol

GetInUseProjectMaterialNames GetManager GetMaterialNamesInConfiguredLibraries

GetProjectMaterialNamesGetPropertiesGetPropertyValueImportDatasetModifyLibrariesRemoveComponentRemoveFootprintRemoveMaterialRemovePadstackRemoveScriptRemoveSurfaceMaterialRemoveSymbol

SetPropertyValue UpdateDefinition UpdateDefinitionFromLib

oDesign

AddDatasetAnalyzeAnalyzeAllAnalyzeAllNominalApplyMeshOpsChangePropertyClearLinkedDataConstructVariationStringCreate2DDesignCreateParametricCircuitDeleteDatasetDeleteFieldVariationDeleteFullVariationDeleteLinkedDataVariationDeleteVariation

EditDataset EditNotes EnableHarmonicForceCalculation

ExportConvergence ExportDataset ExportMeshStats ExportProfile GenerateMesh GetArrayVariables GetChildNames GetChildObject GetChildTypes GetConfigurableData GetData GetDesignType GetDesignValidationInfo GetManagedFilesPath GetModule GetName GetNominalVariation GetNoteText GetObjPath GetPostProcessingVariables GetPropNames GetPropValue GetProperties GetPropertyValue GetSolutionType GetVariableValue GetVariables

GetVariationVariableValue ImportDataset InitializeSystemCoupling

Is2D Is3D Paste

RedoRenameDesignInstanceSetActiveEditorSetConductivityThresholdSetDesignSettingsSetObjectDeformationSetObjectTemperatureSetPropValueSetPropertyValueSetSolutionTypeSetVariableValueSimulateLinkSolveStopSimLinkUndo

ValidateDesign ValidateLink

Editor

AddViewOrientation AlignFaces AssignMaterial
AssignSurfaceMaterial BreakUDMConnection Chamfer

ChangeProperty CleanUpModel CloseAllWindows Connect Copy CoverLines CoverSurfaces Create3DComponent CreateBondwire CreateCircle CreateBox CreateComponent CreateCone CreateCutplane CreateCylinder CreateEllipse CreateEntityList CreateEquationCurve

CreateEquationSurface CreateFaceCS CreateGroup

CreateHelix CreateObjectCS CreateObjectFromEdges

CreateObjectFromFaceCreateObjectFromFacesCreatePointCreatePolylineCreateRectangleCreateRegionCreateRegularPolygonCreateRegularPolyhedronCreateRelativeCSCreateSphereCreateSpiralCreateTorus

CreateUserDefinedModel CreateUserDefinedPart CustomGeometryOperation

Defeature DeletPolylinePoint Delete

DeleteEmptyGroupsDeleteLastOperationDeleteOperationDeletePolylinePointDetachEdgeDetachEdges

DetachFaceDetachFacesDoModalValidationForTestDoesGeometryMatchForTestDuplicateAlongLineDuplicateAroundAxisDuplicateMirrorEdit3DComponentEdit3DComponentDefinitionEditEntityListEditFaceCSEditNativeComponentDefinition

EditObjectCS EditPolyline EditRelativeCS

Export ExportGDSII ExportModelImageToFile

Fillet FitAll FlattenGroup
GenerateAllUserDefinedModels GenerateFacetDataForModel GenerateHistory

GenerateUserDefinedModel Get3DComponentDefinitionNames Get3DComponentInstanceNames
Get3DComponentMaterialNames Get3DComponentMaterialProperties Get3DComponentParameters
Get3DComponentPartNames GetActiveCoordinateSystem GetBodyNamesByPosition

GetChildNames GetChildObject GetChildTypes

GetCoordinateSystems GetEdgeByPosition GetEdgeIDFromNameForFirstOperation

GetEdgeIDsFromFace GetEdgeIDsFromObject GetEdgeLength
GetEdgePositionAtNormalizedParameter GetEntityListIDByName GetFaceArea

GetFaceByPosition GetFaceCenter GetFaceIDFromNameForFirstOperation

GetFaceIDs GetFaceIDsOfSheet GetFullGeometry

GetGeometryModelerMode GetGroupSubmodelNames GetMatchedObjectName

GetModelProvedtributes GetModelUnits

GetModelBoundingBox GetModelDrawAttributes GetModelUnits
GetName GetNumObjects GetObjPath

GetObjectIDByName GetObjectName GetObjectNameByEdgeID
GetObjectNameByFaceID GetObjectNameByID GetObjectNameByVertexID

GetObjectsByMaterial GetObjectsInGroup

GetOperationIndex GetPartsForUserDefinedModel GetPoints
GetPropNames GetPropValue GetRelativeCoordinateSystems GetSelections

GetSubGroupsInGroup GetUserPosition GetVertexIDFromNameForFirstOperation

GetVertexIDsFromEdge GetVertexIDsFromFace GetVertexIDsFromObject

GetVertexPosition GetWireBodyNames HealObject

ImportImportDXFImportFromClipboardImportGDSIIImprintImprintProjectionInsert3DComponentInsertComponentInsertNativeComponent

InsertPolylineSegment Intersect Make3DComponentIndenpendent

MirrorMoveMoveCSToEndMoveEdgesMoveEntityToGroupMoveFaces

ObjectExists OffsetFaces OpenExternalEditor

PageSetup Paste PerformExplicitSubtractions

ProjectSheet ProjectUDPParametersToValidPlane ProjectUDPParametersToValidPlane2

PurgeHistory RefreshAllUserDefinedModelFrom RefreshUserDefinedModelFrom

RefreshUserDefinedModelTo RemoveBadEdges RemoveBadFaces

RemoveBadVertices RenamePart ReplaceWith3DComponent

Rotate Scale Section
SendParametersAndGenerateUserDefineModel SeparateBody SetModelUnits
SetModelValidationSettings SetPropValue SetPropertyValue

SetTopDownViewDirectionForActiveView SetTopDownViewDirectionForAllViews SetWCS ShowWindow Simplify Split

Stitch Subtract SweepAlongPath

SweepAlongVector SweepAroundAxis SweepFacesAlongNormal

SweepFacesAlongNormalWithAttributes ThickenSheet UncoverFaces

Ungroup Unite UpdateComponentDefinition UpdatePriorityList UpgradeVersion Update3DComponent

WrapSheet WriteAttributesBlockForTest WriteHistoryTreeLayoutForTest

oTool-NdExplorer

CheckCausality ExportFullWaveSpice ExportNMFData

ExportNetworkData ExtractImpulseResponse SetExportTouchstoneOptions

oTool-ImportExport

ImportANF ImportANFV2 ImportAWRMicrowaveOffice

ImportAutoCADImportEDBImportExtractaImportGDSIIImportGerberImportIDFImportIDFandMergeImportIPCImportODB

ImportXFL

oModule-BoundarySetup

AddAssignmentToBoundary AddTerminalstoWinding AddWindingTerminals
AssignCharge AssignCoilTerminal AssignCoilTerminalGroup
AssignCurrent AssignCurrentDensity AssignCurrentDensityGroup

AssignCurrentDensityTerminal AssignCurrentDensityTerminalGroup AssignCurrentGroup
AssignCylindricalHField AssignFloating AssignFluxTangential

AssignImpedance AssignInsulating AssignIntegratedZeroTangentialHField

AssignMaster AssignPermanentMagnetField AssignRadiation
AssignResistiveSheet AssignSink AssignSlave
AssignSymmetry AssignTangentialHField AssignVoltage
AssignVoltageAPhi AssignVoltageAPhiGroup AssignVoltageDrop

AssignVoltageDropGroup AssignVoltageGroup AssignVolumeChargeDensity
AssignWindingGroup AssignZeroTangentialHField ComputeOperatingPoints
DeleteAllBoundaries DeleteAllExcitations DeleteBoundaries

EditCharge EditCoilTerminal EditCurrent
EditCurrentDensity EditCurrentDensityTerminal EditCylindricalHField

EditExternalCircuit EditExternalSimulinkCircuit EditFloating
EditFluxTangential EditImpedance EditInsulating

EditIntegratedZeroTangentialHField EditMaster EditPermanentMagnetField

EditRadiation EditResistiveSheet EditSink

EditSlave EditSymmetry EditTangentialHField
EditVoltage EditVoltageAPhi EditVoltageDrop
EditVolumeChargeDensity EditWindingGroup EditZeroTangentialHFie

EditVolumeChargeDensity EditWindingGroup EditZeroTangentialHField
GetAssignment GetBoundaries GetBoundaries
GetCoreLossEffect GetCoreLossEffectOnField GetDisplacementCurrent
GetEddyEffect GetExcitations GetExcitationsOfType
GetNumBoundaries
GetNumBoundariesOfType GetNumExcitations

GetNumExcitationsOfType ReassignBoundary RemoveAssignmentFromBoundary

RemoveTerminalFromWinding RenameBoundary ReprioritizeBoundaries
SetCoreLoss SetEddyEffect SetMagnetizationCompute

SetMinimumTimeStep SetupYConnection

oModule-MeshSetup

AssignApplyCurvlinearElementsOp AssignCloneOp AssignCurvatureExtractionOp
AssignCylindricalGapOp AssignDefeatureOp AssignDensityControlOp
AssignEdgeCutLayerOp AssignLengthOp AssignModelResolutionOp
AssignRotationalLayerOp AssignSkinDepthOp AssignSurfPriorityForTauOp
AssignTrueSurfOp DeleteOp EditApplyCurvlinearElementsOp

EditCloneOp EditCurvatureExtractionOp EditCylindricalGapOp
EditDefeatureOp EditDensityControlOp EditEdgeCutLayerOp
EditLengthOp EditModelResolutionOp EditRotationalLayerOp

EditSkinDepthOp GetOperationNames

RenameOp

EditSurfPriorityOp InitialMeshSettings EditTrueSurfOp ReassignOp

oModule-AnalysisSetup

ClearLinkedDataConfigureFluentConductivityCouplingCopySetupDeleteSetupsEditSetupExportCircuitExportECEDataExportSolnDataGetSetupsInsertMeshLinkedSetupInsertSetupPasteSetup

RenameSetup ResetAllToTimeZero ResetSetupToTimeZero
RevertAllToInitial RevertAllToInitialTemperature RevertSetupToInitial RevertSetupToInitialTemperature RevertSetupToZeroDisplacement

oModule-Optimetrics

CopySetup DeleteSetups DistributedAnalyzeSetup ExportDOELocalSensitivity EditSetup EnableSetup ExportDOELocalSensitivityCurve ExportDOEResponseCurve ExportDOEResponseCurveSlices ExportDOEResponseSurface ExportDXConfigFile ExportOptimetricsProfile ExportOptimetricsResult ExportParametricResults ExportParametricSetupTable ExportRespSurfaceMinMaxTableExportRespSurfacePlotToFile **ExportRespSurfaceRefinePoints**

ExportRespSurfaceResponsePoints ExportRespSurfaceVerificationPoints GenerateVariationData

GetChildNames GetChildObject GetChildTypes

GetName GetObjPath GetOptimetricResult
GetOptimetricResultRowCount GetPropNames GetSetupNames GetSetupNamesByType ImportSetup
InsertSetup PasteSetup RenameSetup
SetPropValue SolveAllSetup SolveSetup

oModule-Solutions

DeleteSolutionVariation FFTOnReport GetAvailableVariations

GetValidISolutionList TDROnReport

oModule-FieldsReporter

AddMarkerAddMarkerToPlotAddNamedExprAddNamedExpressionCalcOpCalcReadCalcStackCalcWriteCalculatorReadCalculatorWriteChangeGeomSettingsClcEval

ClcMaterialClcMaterialValueClearAllMarkersClearAllNamedExprCopyNamedExprToStackCreateFieldPlotDeleteFieldPlotDeleteMarkerDeleteNamedExprDeleteUneditablePlotDoesNamedExpressionExistsDumpCalculatorStack

EnterComplex EnterComplexVector EnterCoord EnterEdge EnterLine EnterOutputVar EnterPoint EnterQty EnterScalar EnterScalarFunc EnterSurf EnterVector EnterVectorFunc EnterVol ExportFieldPlot ExportMarkerTable ExportOnGrid ExportPlotImageToFile

ExportToFile GetFieldFolderNames GetFieldPlotNames

GetMeshPlotNames GetTopEntryValue HideAntennaParameterOverlay

HidePolarPlot HideRadiatedPlotOverlay LoadNamedExpressions

HidePolarPlotHideRadiatedPlotOverlayLoadNamedExpressionsModifyFieldPlotReassignFieldPlotRenameFieldPlotRenamePlotFolderSaveFieldsPlotsSaveNamedExpressionsSetFieldPlotSettingsSetFieldTypeSettingsSetPlotFolderSettings

SetPlotsSolutionContext SetPlotsViewSolutionContext ShowAntennaParameterOverlay

ShowPolarPlot ShowRadiatedPlotOverlay Test
UpdateAllFieldsPlots UpdateQuantityFieldsPlots XForm

oModule-ReportSetup

ExportUniformPointsToFile

AddAllEyeMeasurements AddCartesianLimitLine AddCartesianLimitLineFromCurve

AddCartesianLimitLineFromEquation AddCartesianXMarker AddCartesianYMarker

AddCartesianYMarkerToStackAddDeltaMarkerAddMarkerAddNoteAddTraceCharacteristicsAddTracesApplyReportTemplateChangePropertyClearAllMarkers

ClearAllTraceCharacteristics CloneReportsFromDatasetSolution CompareReportDataForRegressionTesting CompareReportDataForRegressionTesting CompareTracesForRegressionTesting CompareTracesForRegressionTesting CompareTracesForRegressionTesting2

CopyPlotSettingsCopyReportDefinitionsCopyReportsDataCopyTraceDefinitionsCopyTracesDataCreateReport

CreateReportFromFileCreateReportFromTemplateCreateReportOfAllQuantitiesDeleteAllReportsDeleteReportsDeleteTraceCharacteristicsDeleteTracesDoesSupportTraceCharacteristicsDumpAllReportsData

DumpReportDataForRegressionTestingEditCartesianXMarkerEditCartesianYMarkerEditMarkerExportEyeMaskViolationExportImageToFileExportReportDataToFileExportTableToFileExportToFile

GetAllReportNames GetAvailableDisplayTypes GetAvailableReportTypes

GetAllCategories

GetAvailableSolutions GetChildNames GetChildObject
GetChildTypes GetCurvePropServerName GetDisplayType

GetDynLinkIntrinsicVariables GetDynLinkQtyData GetDynLinkQtyValueState

GetDynLinkTraces GetDynLinkVariableValues GetName
GetObjPath GetPropNames GetPropValue

 $Get Property Value \\ Get Qty Expressions For Source Trace \\ Get Report Summary For Regression Testing$

GetAllQuantities

GetReportTraceNames GetSolutionContexts GetSolutionDataPerVariation
GroupPlotCurvesByGroupingStrategy ImportIntoReport ImportReportDataIntoReport
MovePlotCurvesToGroup MovePlotCurvesToNewGroup OpenWindowForAllReports

OpenWindowForReports PastePlotSettings PasteReports

PasteReportsWithLegacyNames PasteTraces PasteTracesWithLegacyNames

RenameReport RenameTrace ResetPlotSettings
SavePlotSettingsAsDefault SetLinkOutputTraces SetPropValue
UngroupPlotCurvesInGroup UpdateAllReports UpdateReports

UpdateTracesContextAndSweeps

oModule-OutputVariable

CreateOutputVariable DeleteOutputVariable DoesOutputVariableExist EditOutputVariable ExportOutputVariables GetOutputVariableValue

GetOutputVariables ImportOutputVariables

oModule-UserDefinedSolutionModule

CreateUserDefinedSolution DeleteUserDefinedSolution EditUserDefinedSolution

GetUserDefinedSolutionNames GetUserDefinedSolutionProperties