oDesktop

GetDistributedAnalysisMachines

AddMessageClearMessagesCloseAllWindowsCloseProjectCloseProjectNoForceDeleteProjectDeleteRegistryEntryDoesRegistryValueExistDownloadJobResultsEnableAutoSaveExportOptionsFilesGetActiveProjectGetAutoSaveEnabledGetBuildDateTimeStringGetDefaultUnit

GetGDIObjectCountGetLibraryDirectoryGetLocalizationHelperGetMessagesGetPersonalLibDirectoryGetProcessIDGetProjectDirectoryGetProjectListGetProjects

GetRegistryInt GetRegistryString GetRunningInstancesMgr
GetScriptingToolsHelper GetSysLibDirectory GetTempDirectory
GetTool GetUserLibDirectory GetVersion

GetDistributedAnalysisMachinesForDesignType

GetExeDir

LaunchJobMonitorNewProjectOpenAndConvertProjectOpenMultipleProjectsOpenProjectOpenProjectWithConversion

PauseScript PageSetup PauseRecording RefreshJobMonitor Print QuitApplication RestoreWindow ResetLogging RestoreProjectArchive ResumeRecording RunACTWizardScript RunProgram RunScript RunScriptWithArguments SelectScheduler SetActiveProjectByPath SetLibraryDirectory SetActiveProject SetProjectDirectory SetRegistryFromFile SetRegistryInt

SetRegistryString SetTempDirectory ShowDockingWindow

Sleep SubmitJob TileWindows

oProject

AddDatasetAddMaterialAnalyzeAllChangePropertyClearMessagesCloneMaterialCloseCopyDesignCutDesignDeleteDesignDeleteToolObi

DeleteDataset DeleteDesign DeleteToolObject EditDataset EditMaterial ExportDataset **ExportMaterial** GetActiveDesign GetArrayVariables GetChildNames GetChildObject GetChildTypes GetConfigurableData GetDefinitionManager GetDependentFiles GetEDBHandle GetDesign GetDesigns GetLegacyName GetName GetObjPath GetPath GetPropNames GetPropValue GetProperties GetPropertyValue GetTopDesignList GetVariableValue GetVariables ImportDataset InsertDesign InsertDesignWithWorkflow InsertToolObject

Paste PasteDesignBlock Redo

RemoveAllUnusedDefinitions RemoveMaterial RemoveUnusedDefinitions

Rename Save SaveAs

SaveAsStandAloneProject SaveProjectArchive SetActiveDefinitionEditor

SetActiveDesign SetPropValue SetPropertyValue

SetVariableValue SimulateAll Undo

UpdateDefinitions

oDefinitionManager

AddComponentAddDatasetAddFootprintAddMaterialAddPadstackAddScriptAddSurfaceMaterialAddSymbolChangePropertyCloneMaterialCreateComponentDataDeleteDataset

DoesMaterialExist DoesSurfaceMaterialExist EditComponent

EditDataset EditFootprint EditMaterial

EditPadstackEditScriptEditSurfaceMaterialEditSymbolExportComponentExportDatasetExportFootprintExportMaterialExportPadstackExportScriptExportSurfaceMaterialExportSymbol

GetInUseProjectMaterialNames GetManager GetMaterialNamesInConfiguredLibraries

GetProjectMaterialNamesGetPropertiesGetPropertyValueImportDatasetModifyLibrariesRemoveComponentRemoveFootprintRemoveMaterialRemovePadstackRemoveScriptRemoveSurfaceMaterialRemoveSymbol

SetPropertyValue UpdateDefinition UpdateDefinitionFromLib

oDesign

AddDatasetAnalyzeAnalyzeAllAnalyzeAllNominalApplyMeshOpsChangePropertyConstructVariationStringCreate2DDesignDeleteDataset

DeleteFieldVariation DeleteFullVariation DeleteLinkedDataVariation

DeleteVariation EditDataset EditNotes

ExportConvergence ExportDataset ExportMatrixData ExportMeshStats ExportNMFData ExportNetworkData ExportProfile GenerateMesh GetArrayVariables GetChildNames GetChildObject GetChildTypes GetConfigurableData GetData GetDataVersion GetDesignType GetDesignValidationInfo GetModule GetName **GetNominalVariation** GetNoteText GetPostProcessingVariables GetObjPath GetPropNames GetPropValue GetProperties GetPropertyValue

GetVariableValue GetVariables GetVariationVariableValue

ImportDataset Paste Redo

RenameDesignInstance RunToolkit SetActiveEditor
SetAllowMaterialOverride SetBackgroundMaterial SetDesignSettings
SetObjectTemperature SetPropValue SetPropertyValue

SetVariableValue SimulateLink Solve

StopSimLink Undo ValidateDesign

ValidateLink

Editor

AddViewOrientation AlignFaces AssignMaterial
AssignSurfaceMaterial BreakUDMConnection Chamfer

CloseAllWindows ChangeProperty CleanUpModel Connect Copy CoverLines CoverSurfaces Create3DComponent CreateBondwire CreateBox CreateCircle CreateComponent CreateCone CreateCutplane CreateCylinder CreateEllipse CreateEntityList CreateEquationCurve

CreateEquationSurface CreateFaceCS CreateGroup

CreateHelix CreateObjectCS CreateObjectFromEdges

CreateObjectFromFaceCreateObjectFromFacesCreatePointCreatePolylineCreateRectangleCreateRegionCreateRegularPolygonCreateRegularPolyhedronCreateRelativeCSCreateSphereCreateSpiralCreateTorus

CreateUserDefinedModel CreateUserDefinedPart CustomGeometryOperation

Defeature DeletPolylinePoint Delete

DeleteEmptyGroups DeleteLastOperation DeleteOperation

DeletePolylinePoint DetachEdge DetachEdges

DetachFaceDetachFacesDoModalValidationForTestDoesGeometryMatchForTestDuplicateAlongLineDuplicateAroundAxisDuplicateMirrorEdit3DComponentEdit3DComponentDefinitionEditEntityListEditFaceCSEditNativeComponentDefinition

EditObjectCS EditPolyline EditRelativeCS

Export ExportGDSII ExportModelImageToFile

Fillet FitAll FlattenGroup
GenerateAllUserDefinedModels GenerateFacetDataForModel GenerateHistory

GenerateUserDefinedModel Get3DComponentDefinitionNames Get3DComponentInstanceNames
Get3DComponentMaterialNames Get3DComponentMaterialProperties Get3DComponentParameters
Get3DComponentPartNames GetActiveCoordinateSystem GetBodyNamesByPosition

GetChildNames GetChildObject GetChildTypes

GetCoordinateSystems GetEdgeByPosition GetEdgeIDFromNameForFirstOperation

GetEdgeIDsFromFace GetEdgeIDsFromObject GetEdgeLength
GetEdgePositionAtNormalizedParameter GetEntityListIDByName GetFaceArea

GetFaceByPosition GetFaceCenter GetFaceIDFromNameForFirstOperation

GetFaceIDs GetFaceIDsOfSheet GetFullGeometry
GetGeometryModelerMode GetGroupSubmodelNames GetMatchedObjectName

GetModelBoundingBox GetModelDrawAttributes GetModelUnits
GetName GetNumObjects GetObjPath

GetObjectIDByName GetObjectName GetObjectNameByEdgeID
GetObjectNameByFaceID GetObjectNameByID GetObjectNameByVertexID

GetObjectShapeType GetObjectsByMaterial GetObjectsInGroup

GetOperationIndexGetPartsForUserDefinedModelGetPointsGetPropNamesGetPropValueGetPropertiesGetPropertyValueGetRelativeCoordinateSystemsGetSelections

GetSubGroupsInGroup GetUserPosition GetVertexIDFromNameForFirstOperation

GetVertexIDsFromEdge GetVertexIDsFromFace GetVertexIDsFromObject

GetVertexPosition GetWireBodyNames HealObject

 Import
 ImportDXF
 ImportFromClipboard

 ImportGDSII
 Imprint
 ImprintProjection

 Insert3DComponent
 InsertComponent
 InsertNativeComponent

InsertPolylineSegment Intersect Make3DComponentIndenpendent

MirrorMoveMoveCSToEndMoveEdgesMoveEntityToGroupMoveFacesObjectExistsOffsetFacesOpenExternalEditor

PageSetup Paste PerformExplicitSubtractions

ProjectSheet ProjectUDPParametersToValidPlane ProjectUDPParametersToValidPlane2

PurgeHistory RefreshAllUserDefinedModelFrom RefreshUserDefinedModelFrom

RefreshUserDefinedModelTo RemoveBadEdges RemoveBadFaces

RemoveBadVertices RenamePart ReplaceWith3DComponent

RotateScaleSectionSendParametersAndGenerateUserDefineModelSeparateBodySetModelUnitsSetModelValidationSettingsSetPropValueSetPropertyValue

SetTopDownViewDirectionForActiveView SetTopDownViewDirectionForAllViews SetWCS ShowWindow Simplify Split

Stitch Subtract SweepAlongPath

SweepAlongVector SweepAroundAxis SweepFacesAlongNormal

SweepFacesAlongNormalWithAttributes ThickenSheet UncoverFaces

Ungroup Unite UpdateComponentDefinition
UpdatePriorityList UpgradeVersion Validate3DComponent

WrapSheet WriteAttributesBlockForTest WriteHistoryTreeLayoutForTest

CheckCausality
ExportNetworkData

ExportFullWaveSpice ExtractImpulseResponse ExportNMFData
SetExportTouchstoneOptions

oTool-ImportExport

ImportANF
ImportAutoCAD
ImportGDSII
ImportIDFandMerge

ImportXFL

ImportANFV2
ImportEDB
ImportGerber
ImportIPC

ImportAWRMicrowaveOffice ImportExtracta ImportIDF ImportODB

oModule-BoundarySetup

AddAssignmentToBoundary
AssignGroundNet
AssignSignalNet
AssignTerminals
DeleteAllBoundaries
EditInfiniteGround
EditThinConductor
GetNumExcitations
RenameBoundary
SetMaterialThresholds

Assign2DTerminals
AssignInfiniteGround
AssignNet
AssignSink
AssignSource
AssignThinConductor
DeleteAllExcitations
EditNet
GetExcitationAssignment

ReassignBoundary

AssignFloatingNet
AssignFloatingNet

DeleteBource

AutoIdentifyNets
DeleteBoundaries
EditTerminal
GetExcitationAssignment

RemoveAssignment

RemoveAssignment

ReassignBoundary RemoveAssignmentFromBoundary ReprioritizeNetTypes SetConductivityThreshold

ToggleNet ToggleTerminal

oModule-MeshSetup

AssignApplyCurvlinearElementsOp
AssignCylindricalGapOp
AssignEdgeCutLayerOp
AssignRotationalLayerOp
AssignTrueSurfOp
EditCloneOp
EditDefeatureOp
EditLengthOp
EditSkinDepthOp
GetOperationNames
RenameOp

AssignCloneOp AssignDefeatureOp AssignLengthOp AssignSkinDepthOp DeleteOp

EditCurvatureExtractionOp EditDensityControlOp EditModelResolutionOp EditSurfPriorityOp InitialMeshSettings AssignCurvatureExtractionOp AssignDensityControlOp AssignModelResolutionOp AssignSurfPriorityForTauOp EditApplyCurvlinearElementsOp

EditCylindricalGapOp
EditEdgeCutLayerOp
EditRotationalLayerOp
EditTrueSurfOp
ReassignOp

oModule-AnalysisSetup

CopySetup
DeleteSweep
EditSweep
GetSetups
InsertSetup
PasteSweep
RevertAllToInitial
RevertSetupToInitialTemperature

CopySweep
EditCircuitSettings
ExportCircuit
GetSweepCount
InsertSweep
RenameSetup
RevertAllToInitialTemperature

DeleteSetups
EditSetup
GetProblemTypes
GetSweeps
PasteSetup
RenameSweep
RevertSetupToInitial

oModule-Optimetrics

CopySetup
EditSetup
ExportDOELocalSensitivityCurve
ExportDOEResponseSurface
ExportOptimetricsResult
ExportRespSurfaceMinMaxTable

DeleteSetups
EnableSetup
ExportDOEResponseCurve
ExportDXConfigFile
ExportParametricResults
ExportRespSurfacePlotToFile

DistributedAnalyzeSetup
ExportDOELocalSensitivity
ExportDOEResponseCurveSlices
ExportOptimetricsProfile
ExportParametricSetupTable
ExportRespSurfaceRefinePoints

ExportRespSurfaceResponsePoints ExportRespSurfaceVerificationPoints GenerateVariationData

GetChildNamesGetChildObjectGetChildTypesGetNameGetObjPathGetOptimetricResultGetOptimetricResultRowCountGetPropNamesGetPropValueGetSetupNamesGetSetupNamesByTypeImportSetupInsertSetupPasteSetupRenameSetup

oModule-Solutions

SetPropValue

TDROnReport

ExportToFile

DeleteSolutionVariation EditSources FFTOnReport

SolveAllSetup

GetAvailableVariations GetEditSourcesCount GetNetworkDataSolution

SolveSetup

GetFieldPlotNames

GetNetworkDataSolutionDefinition GetValidISolutionList HasFields
HasMatrixData HasMesh ListVariations

oModule-FieldsReporter

AddMarkerAddMarkerToPlotAddNamedExprAddNamedExpressionCalcOpCalcReadCalcStackCalcWriteCalculatorReadCalculatorWriteChangeGeomSettingsClcEval

 ClcMaterial
 ClcMaterialValue
 ClearAllMarkers

 ClearAllNamedExpr
 CopyNamedExprToStack
 CreateFieldPlot

 DeleteFieldPlot
 DeleteMarker
 DeleteNamedExpr

 DeleteUneditablePlot
 DoesNamedExpressionExists
 DumpCalculatorStack

EnterComplex EnterComplexVector EnterCoord EnterEdge EnterLine EnterOutputVar EnterScalar EnterPoint EnterQty EnterScalarFunc EnterSurf EnterVector EnterVectorFunc EnterVol ExportFieldPlot ExportPlotImageToFile ExportMarkerTableExportOnGrid

GetFieldFolderNames

GetMeshPlotNamesGetTopEntryValueHideAntennaParameterOverlayHidePolarPlotHideRadiatedPlotOverlayLoadNamedExpressionsModifyFieldPlotReassignFieldPlotRenameFieldPlotRenamePlotFolderSaveFieldsPlotsSaveNamedExpressionsSetFieldPlotSettingsSetPlotFolderSettings

SetPlotsSolutionContext SetPlotsViewSolutionContext ShowAntennaParameterOverlay

ShowPolarPlot ShowRadiatedPlotOverlay Test
UpdateAllFieldsPlots UpdateQuantityFieldsPlots XForm

oModule-RadField

AddAntennaOverlay AddRadFieldSourceGroup CopyRadFieldSetup DeleteNearFieldSetup CopySetup DeleteFarFieldSetup DeleteSetup EditAntennaArraySetup EditAntennaOverlay EditBoxSetup EditFarFieldSphereSetup EditInfiniteSphereSetup EditNearFieldBoxSetup EditNearFieldLineSetup EditLineSetup EditNearFieldRectangleSetup EditNearFieldSphereSetup EditRadFieldSourceGroup

EditNearFieldRectangleSetup EditNearFieldSphereSetup EditRadFieldSourceGroup EditRadiatedPowerCalculationMethod EditRectangleSetup EditSphereSetup

ExportFieldsToFile ExportParametersToFile ExportRadarRom

 $Export Radiation Fields To File \\ Export Radiation Parameters To File \\ Export Radiation Surface Mesh And Fields \\ Export Radiation Fields \\ Expor$

GetChildNamesGetChildObjectGetChildTypesGetInfiniteGroundPlaneCoordSystemGetNameGetObjPathGetPropNamesGetPropValueGetSetupNames

InsertBoxSetupInsertFarFieldSphereSetupInsertInfiniteSphereSetupInsertLineSetupInsertNearFieldBoxSetupInsertNearFieldLineSetupInsertNearFieldRectangleSetupInsertNearFieldSphereSetupInsertRectangleSetupInsertSphereSetupPasteRadFieldSetupPasteSetup

RenameSetup SetPropValue

oModule-ReduceMatrix

AlphaNumericMatrix DeleteRM DeleteRMO
DupRM DupRMAddOp EditRM
InsertRM RMAddOp RenameRM

RenameRMO ReorderMatrix

oModule-ReportSetup

AddAllEyeMeasurements AddCartesianLimitLine AddCartesianLimitLineFromCurve

AddCartesianLimitLineFromEquation AddCartesianXMarker AddCartesianYMarker

AddCartesianYMarkerToStackAddDeltaMarkerAddMarkerAddNoteAddTraceCharacteristicsAddTracesApplyReportTemplateChangePropertyClearAllMarkers

ClearAllTraceCharacteristics CloneReportsFromDatasetSolution CompareReportDataForRegressionTesting CompareReportDataForRegressionTesting CompareTracesForRegressionTesting Compa

CopyPlotSettings CopyReportDefinitions CopyReportsData

CopyTraceDefinitionsCopyTracesDataCreateReportCreateReportFromFileCreateReportFromTemplateCreateReportOfAllQuantitiesDeleteAllReportsDeleteReportsDeleteTraceCharacteristics

DeleteTraces
DoesSupportTraceCharacteristics
DumpAllReportsData
DumpReportDataForRegressionTesting
EditCartesianXMarker
EditMarker
ExportEyeMaskViolation
ExportImageToFile
ExportToFile
ExportToFile
ExportToFile

ExportReportDataToFile ExportTableToFile ExportToFile ExportUniformPointsToFile GetAllCategories GetAllQuantities

GetAllReportNames GetAvailableDisplayTypes GetAvailableReportTypes

GetAvailableSolutions GetChildNames GetChildObject
GetChildTypes GetCurvePropServerName GetDisplayType

GetDynLinkIntrinsicVariables GetDynLinkQtyData GetDynLinkQtyValueState

GetDynLinkTraces GetDynLinkVariableValues GetName
GetObjPath GetPropNames GetPropValue

GetPropertyValue GetQtyExpressionsForSourceTrace GetReportSummaryForRegressionTesting

GetReportTraceNamesGetSolutionContextsGetSolutionDataPerVariationGroupPlotCurvesByGroupingStrategyImportIntoReportImportReportDataIntoReportMovePlotCurvesToGroupMovePlotCurvesToNewGroupOpenWindowForAllReports

OpenWindowForReports PastePlotSettings PasteReports

PasteReportsWithLegacyNames PasteTraces PasteTracesWithLegacyNames

RenameReport RenameTrace ResetPlotSettings
SavePlotSettingsAsDefault SetLinkOutputTraces SetPropValue
UngroupPlotCurvesInGroup UpdateAllReports UpdateReports

oModule-OutputVariable

CreateOutputVariable DeleteOutputVariable DoesOutputVariableExist
EditOutputVariable ExportOutputVariables GetOutputVariableValue
GetOutputVariables ImportOutputVariables

oModule-UserDefinedSolutionModule

CreateUserDefinedSolution GetUserDefinedSolutionNames DeleteUserDefinedSolutions GetUserDefinedSolutionProperties EditUserDefinedSolution