

Z-Stack/Z-Tool Serial Port Interface

Document Number: F8W-2003-0001

Texas Instruments, Inc. San Diego, California USA (619) 542-1200

Version	Description	Date
1.0	Initial ZigBee v1.0 release.	04/08/2005
1.1	Removed references to previously removed Table 1.	06/22/2005
1.2	Changed the MAC callback IDs.	07/22/2005
	Changed definition of device address in NLME_LEAVE_INDICATION.	
1.3	Added new commands for NV parameters. Minor formatting changes.	10/04/2005
1.4	Clarified "Len" parameter in sections 2.8.2 and 2.9.3	11/08/2005
1.5	Updated MAC interface to match ZMAC.	1/10/2006
1.6	Changed the length field in the ZDO Node and Power descriptors	07/27/2006
1.7	Removed the Sequence commands	09/01/2006
1.8	Updated ZDO message for ZigBee 1.1. Also changed cluster ID to 2 bytes	09/11/2006
1.9	Added new changes to support new MAC updates	10/09/2006
1.10	Added new command ZDO_SYSTEM_SERVER_DISC_REQ/RSP	10/16/2006
1.11	Added new command ZDO_NETWORK_START. Update for 1.4.0 release.	12/05/2006

TABLE OF CONTENTS

1. IN	NTRODUCTION	1
1.1	Purpose	
1.2	SCOPE	1
1.3	ACRONYMS	1
1.4	APPLICABLE DOCUMENTS	1
1.5	Overview	1
1.6	Interface Mechanism	2
2. S	YSTEM COMMANDS	5
2.1	Introduction	5
2.2	SYS PING	
2.3	SYS VERSION	
2.4	SYS_SET_EXTENDED_ADDRESS	
2.5	SYS_GET_EXTENDED ADDRESS	
2.6	SYS_RAM_READ	
2.7	SYS_RAM_WRITE	
2.8	SYS SET NV	
2.9	SYS_GET_NV	
2.10		
2.11		
2.12		
2.13		
2.14		
2.15		
2.16		
2.17		
2.18	-	
2.19		
2.20		
2.21		
2.22		
3. M	MAC INTERFACE	19
3.1	Introduction	19
3.2	ZMAC_INIT_REQUEST	19
3.3	ZMAC_DATA_REQUEST	19
3.4	ZMAC_ASSOCIATE_REQUEST	21
3.5	ZMAC_ASSOCIATE_RESPOND	23
3.6	ZMAC_DISASSOCIATE_REQUEST	24
3.7	ZMAC_GET_REQUEST	26
3.8	ZMAC_ORPHAN_RESPOND	27
3.9	ZMAC_POLL_REQUEST	28
3.10) ZMAC_RESET_REQUEST	30
3.11	I ZMAC_RX_ENABLE_REQUEST	30
3.12	ZMAC_SCAN_REQUEST	31
3.13	`	
3.14	4 ZMAC_START_REQUEST	34
3.15	`	
3.16	5 ZMAC_PURGE_REQUEST	37

4.	\mathbf{M}^{A}	AC CALLBACK INTERFACE	38
2	4.1	Introduction	38
2	4.2	NWK ASSOCIATE INDICATION	
	4.3	NWK_ASSOCIATE_CONFIRMATION	
	4.4	NWK_DISASSOCIATE_INDICATION	
	4.5	NWK DISASSOCIATE CONFIRMATION	
2	4.6	NWK_BEACON_NOTIFY_INDICATION	41
2	4.7	NWK_ORPHAN_INDICATION	
2	4.8	NWK_SCAN_CONFIRMATION	44
2	4.9	NWK_START_CONFIRMATION	45
2	4.10	NWK_SYNCHRONIZATION_LOSS_INDICATION	45
2	4.11	NWK_POLL_CONFIRMATION	46
2	4.12	NWK_COMM_STATUS_INDICATION	46
4	4.13	NWK_DATA_CONFIRMATION	48
4	4.14	NWK_DATA_INDICATION	48
4	4.15	NWK_RX_ENABLE_CONFIRMATION	50
2	4.16	NWK_PURGE_CONFIRMATION	51
5.	NV	WK INTERFACE	52
4	5.1	Introduction	52
	5.2	NLDE_DATA_REQUEST	
4	5.3	NLME_NETWORK_FORMATION_REQUEST	
4	5.4	NLME_PERMITJOINING_REQUEST	
	5.5	NLME_JOIN_REQUEST	
4	5.6	NLME_LEAVE_REQUEST	
4	5.7	NLME_RESET_REQUEST	
4	5.8	NLME_SYNC_REQUEST	57
4	5.9	NLME_GET_REQUEST	57
4	5.10	NLME_SET_REQUEST	58
4	5.11	NLME_NETWORKDISCOVERY_REQUEST	58
4	5.12	NLME_ROUTEDISCOVERY_REQUEST	59
4	5.13	NLME_DIRECTJOIN_REQUEST	60
4	5.14	NLME_ORPHANJOIN_REQUEST	60
4	5.15	NLME_STARTROUTER_REQUEST	61
6.	NV	WK CALLBACK INTERFACE	62
(5.1	Introduction	62
(5.2	NLDE_DATA_CONFIRMATION	62
(5.3	NLDE_DATA_INDICATION	62
(5.4	NLME_NETWORKFORMATION_CONFIRMATION	63
(5.5	NLME_JOIN_CONFIRMATION	63
(6.6	NLME_JOIN_INDICATION	63
(5.7	NLME_LEAVE_CONFIRMATION	64
(5.8	NLME_LEAVE_INDICATION	64
(5.9	NLME_SYNC_INDICATION	
(5.10	NLME_NETWORKDISCOVERY_CONFIRMATION	65
(5.11	NLME_STARTROUTER_CONFIRMATION	66
7.	AF	FINTERFACE	67
-	7.1	Introduction	67
	7.2	AF_INIT_REQUEST	
	7.3	AF_REGISTER_REQUEST	
	7.4	AF_SENDMSG_REQUEST	
8.	ΔF	CALLBACK INTERFACE	70

8.1	AF_INCOMINGDATA_INDICATION	70
9. ZD	O INTERFACE	71
9.1	Introduction	
9.2	ZDO_AUTOAPPENDENDDEVICEBIND_REQUEST	71
9.3	ZDO_AUTOFINDDESTINATION_REQUEST	71
9.4	ZDO_NETWORKADDRESS_REQUEST	72
9.5	ZDO_IEEEADDRESS_REQUEST	
9.6	ZDO_NODEDESCRIPTOR_REQUEST	73
9.7	ZDO_POWERDESCRIPTOR_REQUEST	
9.8	ZDO_SIMPLEDESCRIPTOR_REQUEST	
9.9	ZDO_ACTIVEENDPOINT_REQUEST	
9.10	ZDO_MATCHDESCRIPTOR_REQUEST	
9.11	ZDO_COMPLEXDESCRIPTOR_REQUEST	
9.12	ZDO_USERDESCRIPTOR_REQUEST	
9.13	ZDO_ENDDEVICEBIND_REQUEST	
9.14	ZDO_BIND_REQUEST	
9.15	ZDO_UNBIND_REQUEST	
9.16	ZDO_MGMT_NWKDISC_REQUEST	
9.17	ZDO_MGMT_LQI_REQUEST	
9.18	ZDO_MGMT_RTG_REQUEST	
9.19	ZDO_MGMT_BIND_REQUEST	
9.20	ZDO_MGMT_DIRECT_JOIN_REQUEST	
9.21	ZDO_USERDESCRIPTOR_SET_REQUEST	
9.22	ZDO_END_DEVICE_ANNCE	
9.23	ZDO_MGMT_LEAVE_REQUEST	
9.24	ZDO_MGMT_PERMIT_JOIN_REQUEST	
9.25	ZDO_SYSTEM_SERVER_DISC_REQUEST	
9.26	ZDO_NETWORK_START_REQUEST	
10. Z	ZDO CALLBACK INTERFACE	
10.1	Introduction	
10.2	ZDO_NETWORKADDRESS_RESPONSECB	
10.3	ZDO_IEEEADDRESS_RESPONSECB	
10.4	ZDO_NODEDESCRIPTOR_RESPONSECB	
10.5	ZDO_POWERDESCRIPTOR_RESPONSECB	
10.6	ZDO_SIMPLEDESCRIPTOR_RESPONSECB	
10.7	ZDO_ACTIVEENDPOINT_RESPONSECB	
10.8	ZDO_MATCHDESCRIPTOR_RESPONSECB	
10.9	ZDO_USERDESCRIPTOR_RESPONSECB	
10.10		
10.11	ZDO_BIND_RESPONSECB	
10.12	ZDO_UNBIND_RESPONSECB	
10.13	ZDO_MGMT_NWKDISC_RESPONSECB	
10.14	ZDO_MGMT_LQI_RESPONSECB	
10.15	ZDO_MGMT_RTG_RESPONSECB	
10.16		
10.17	ZDO_MGMT_DIRECT_JOIN_RESPONSECB	
10.18	ZDO_USERDESCRIPTOR_SET_RESPONSECB	
10.19		
10.20		
10.21	ZDO_SYSTEM_SERVER_DISC_RESPONSECB	
11. A	APPLICATION INTERFACE	100
11 1	INTRODUCTION	100

Z-Stack/Z-1001 Serial Port Interface	<u> </u>
11.2 USERTEST_REQUEST	100
LIST OF FIGURES	

1. Introduction

1.1 Purpose

This document defines the Serial Port Interface (SPI) that is used for communication between the Z-Tool test program and the target. The Z-Tool test program issues commands to the target and receives appropriate responses. The communication occurs over a RS-232 serial port.

1.2 Scope

This document defines

- The link layer protocol used to exchange packets over the RS-232 serial link
- A set of commands that can be issued by the Z-Tool test program to the target
- Appropriate responses for each of those commands
- The format of each of the command and the response messages

1.3 Acronyms

BB	Baseband
CCA	Clear Channel Assessment
MAC	Media Access Control
NHLE	Next Higher Layer Entity
NWK	Network
PHY	Physical Layer
PIB	Personal Information Base
SPI	Serial Port Interface

1.4 Applicable Documents

1. Wireless Medium Access Control (MAC) and Physical Layer (PHY) Specifications for Low-Rate Wireless Personal Area Networks (LR-WPANs), IEEE Standard 802.15.4, May 12, 2003.

1.5 Overview

The serial port interface enables the Z-Tool test program to issue commands to and receive responses from the target. The following functionalities are enabled by these messages.

- 1. System commands: These messages allow the tester to control device configuration, access memory location, set the debug message filter, control message tracing in each software component, and reset the target.
- 2. MAC interface commands: The test can issue MAC commands to access the MAC layer functions of the target.

- 3. NWK interface commands: The tester can issue NWK commands to control NWK layer functionalities of the target.
- 4. AF interface commands: The tester can issue AF commands to call AF layer functions of the target.
- 5. ZDO interface commands: The test can issue ZDO commands to access the ZDO functionalities of the target.
- 6. Application-specific commands: The tester can issue application-specific commands paired with programmed message interfaces from the Test Tool and capabilities within MonitorTest on the target.

In Z-Stack, each of the above functionalities can be enabled or disabled using compiler flags. One benefit of compiling out unnecessary functionalities is saving the code space which plays a significant role in embedded system development. The details of how to use these compiler flags in preprocessor can be found in the Z-Stack Compiler Options document.

1.6 Interface Mechanism

A link layer protocol is necessary so that messages can be exchanged between the tester and target over an RS-232 serial link. The purpose of the link layer protocol is to frame the messages in packets for proper transmission and reception and to ensure message integrity.

The physical transmission uses: no Parity; 8 data bits and 1 stop bits for each byte.

The transmission rate will be 38.4 kbps.

The Z-Tool program must send one message at a time and wait for either the expected response message to a timeout before sending the next message or resending the current message.

Fields that are multi-byte fields are transmitted Most Significant byte first.

There is no provision for retransmission of lost packets

The link layer packet has the following format.



Figure 1 Z-Stack Message Format

SOP (Start of Packet): This is a one byte field with value equal to 0x02 that defines the start of each link level packet.

CMD (Command ID): This is a two byte field (MSByte transmitted first) with a value denoting the Command Identification (ID) for this message. This field is described in detail below.

LEN (Length): This one byte field is the number of bytes in the Data field. If the Data field contains no information this LEN field has a value of 0 and the total length of the command is 5 bytes (0 data message).

Data: This field contains the actual data to be transmitted. This is a field which varies in size according to the command.

FCS (Frame check sequence): This is a one byte field that is used to ensure packet integrity. This field is computed as an XOR of all the bytes in the message starting with CMD and through the last byte of data. The receiver XORs all the received data bytes as indicated above and then XORs the received FCS field. If the sum is not equal to zero, the received packet is in error.


The CMD, LEN and data fields are application message dependant but shown here to fully illustrate the link level protocol. The CMD, LEN and data fields are separately described in the succeeding sections of this document.

In terms of packet error handling, the procedure is as follows:

- Assuming the start of message indicator is unknown and there is a buffer containing received data bytes to be processed, the first element of the procedure is SOP detection:
 - Parse the buffer until a SOP is detected and return the buffer location of that indicator
- Next, the SOP must be validated (since other data elements in the buffer may match the SOP). The SOP validation procedure is as follows:
 - The field after the SOP is the CMD and the one following is the LEN. Use the LEN field to parse the prospective message to the location of the FCS. Use the FCS to check the potential message and validate the SOP location. If validated, message parsing continues with the next SOP (immediately after the FCS just processed).
 - Otherwise, the SOP is not validated and the procedure continues with SOP detection.
- Once the SOP is detected and validated, message processing continues with successive message sequences as denoted in Figure 1.
- Computation of invalid FCS on a message shall result in invocation of the SOP detection procedure beginning with the field after the failed FCS since failed FCS could have resulted from an erroneous LEN field.

1.6.1 Command ID (CMD)

The Command ID field is a 16 bit field broken up in to the following 2 sub fields:



Command Type is a most significant 4 bits of the CMD field and is used to route messages. Each bit (3-0) of this sub field is defined as:

- Bit 0 Response Bit if set, this bit indicates a response message (each response message is described below).
- Bit 1 Subscription Bit if set, this bit indicates that this message was the result of a subscription to a callback service.
- Bit 2 Debug/Trace Bit if set, this bit indicates that this message is either a Debug or Trace message.
- Bit 3 Reserved

Command Number is the least significant 12 bits of the CMD field. The unique number range of this field is broken down into the following:

0x000 – 0x07F System Commands (RAM R/W, Debug, Trace, etc.) 0x080 – 0x0FF MAC Interface Commands 0x100 – 0x3FF NWK Interface Commands 0x400 – 0x4FF PHY Interface Commands 0x500 – 0x5FF SPI Interface Commands 0x600 – 0x6FF Sequence Interface Commands 0x800 – 0x8FF APS Interface Commands 0x900 – 0x9FF AF Interface Commands 0xA00 – 0xAFF ZDO Interface Commands 0xB00 – 0xBFF Device Interface Commands

Remember that the *Command Number* and *Command Type* sub fields are combined to make a unique *Command ID*. That means the messages can share *Command Numbers* as long as the *Command Types* are different. For example, a MAC Command, its response, and a MAC subscription (callback) message can all have the same *Command Number*, but the *Command Type* for each is different.

2. System Commands

2.1 Introduction

These messages are used to issue system related commands.

2.2 SYS_PING

2.2.1 Description

This command issues PING requests to verify if a device is active and check the capability of the device.

2.2.2 Usage

The command message format is as follows

Cmd=0x0007	Len=0x00
------------	----------

2.2.3 SYS_PING_RESPONSE

The response to this command has the following format.

Cmd=0x1007	Len=0x02	Capabilities
------------	----------	--------------

Capabilities – 16 bit field. This field represents the interfaces that this device can handle (compiled into the device). Bit weighted and defined as:

MT_CAP_MAC	0x0001
MT_CAP_NWK	0x0002
MT_CAP_AF	0x0004
MT_CAP_ZDO	0x0008
MT_CAP_USER_TEST	0x0010
MT_CAP_SEQ	0x0020
MT_CAP_BOOTLOAD	0x8000

2.3 SYS_VERSION

2.3.1 Description

This command is used to request for the device's version string.

2.3.2 Usage

The command message format is as follows

Cmd=0x0008	Len=0x00
------------	----------

2.3.3 SYS_VERSION_RESPONSE

The response to this command has the following format.

Cmd=0x1008	Len	Version
------------	-----	---------

Len – length of VersionString in bytes. This is the number of characters not including the null termination.

Version – device defined ASCII string (NOT null terminated).

2.4 SYS_SET_EXTENDED_ADDRESS

2.4.1 Description

This command is used to set the 64-bit extended address.

2.4.2 Usage

The command message format is as follows

Cmd=0x0010	Len = 8	ExtAddress
------------	---------	------------

ExtAddress – 8 bytes – The device's extended address.

2.4.3 SYS_SET_EXTENDED_ADDRESS_RESPONSE

The response to this command has the following format.

Cmd=0x1010	Len=0x01	Status
------------	----------	--------

The status is a success (0) or fail (1).

2.5 SYS_GET_EXTENDED ADDRESS

2.5.1 Description

This command is used to read the extended address from the device.

2.5.2 Usage

The command message format is as follows

Cmd=0x0011	Len = 0x00
Cina oncorr	2011 01100

2.5.3 SYS GET EXTENDED ADDRESS RESPONSE

The response to this command has the following format.

Cmd=0x1011	Len=0x08	ExtAddress
------------	----------	------------

ExtAddress – 8 bytes – The device's extended address.

2.6 SYS_RAM_READ

2.6.1 Description

This command is used by the tester to read a single memory location in the target RAM. The command accepts an address value and returns the memory value present in the target RAM at that address.

2.6.2 Usage

The command message format is as follows

Cmd=0x0001	Len=0x02	Address
------------	----------	---------

Address is a 2 byte field and contains the address of the memory location that needs to be read.

2.6.3 SYS_RAM_READ_RESPONSE

The response to this command has the following format.

Cmd=0x1001 Len=0x03	Status	Value
---------------------	--------	-------

Status is a one byte field and is either success(0) or fail(1). The fail status is returned if the address value in the command message was not within the valid range.

Value is a byte field that contains the data read from the target RAM.

2.7 SYS RAM WRITE

2.7.1 Description

This command is used by the tester to write to a particular location in the target RAM. The command accepts an address location and a memory value. The memory value is written to the address location in the target RAM.

2.7.2 Usage

The command message format is as follows

Cmd=0x0002 Len=0x04	Address	Value
---------------------	---------	-------

Address is a 2 byte field that indicates the address of the memory location that is to be written.

Value is a byte field that contains the data value that is to be written to the memory location.

2.7.3 SYS_RAM_WRITE_RESPONSE

The response has the following format.

Cmd=0x1002	Len=0x01	Status
------------	----------	--------

Status is a success (0) or fail (1). The fail status is returned if the address location in the command message was not within the valid range.

2.8 SYS_SET_NV

2.8.1 Description

This command is used by the tester to write to a particular item in non-volatile memory. The command accepts an attribute ID and an attribute value. The attribute value is written to the location specified for the attribute ID in the target.

2.8.2 Usage

The command message format is as follows

Cmd=0x0012 Len=variable	Attribute	Value
-------------------------	-----------	-------

Len is a 1 byte field that indicates the total length of the Attribute and Value fields that follow.

Attribute is a 1 byte field that indicates the ID of the location that is to be written.

Value is a byte array that contains the data value that is to be written.

2.8.3 SYS_SET_NV_RESPONSE

The response has the following format.

Cmd=0x1012	Len=0x01	Status
------------	----------	--------

Status is a success (0) or fail (1). The fail status is returned if the address location in the command message was not within the valid range.

2.9 SYS_GET_NV

2.9.1 Description

This command is used by the tester to read a single memory item in the target non-volatile memory. The command accepts an attribute ID value and returns the memory value present in the target for the specified attribute ID.

2.9.2 Usage

The command message format is as follows

Cmd=0x0013 Len=0x02 Attribute

Attribute is a 1byte field and contains the location that needs to be read.

2.9.3 SYS NV GET RESPONSE

The response to this command has the following format.

Cmd=0x1013	Len=variable	Status	Attribute	Value
------------	--------------	--------	-----------	-------

Len is a 1 byte field that indicates the total length of the Status, Attribute, and Value fields that follow.

Status is a one byte field that indicates either success(0) or fail(1). Failure status is returned if the attribute ID in the command message was not within the valid range.

Attribute is a 1 byte field that indicates the ID of the data value that is being returned.

Value is a byte array that contains the data returned from the target.

2.10 SYS_GET_DEVICE_INFO

2.10.1 Description

This command is used by the tester to read a block of active parameters for the target device.

2.10.2 Usage

The command message format is as follows

Cmd=0x0014	Len=0x00
------------	----------

2.10.3 SYS_GET_DEVICE_INFO_RESPONSE

The response to this command has the following format.

Cmd=0x1014	Len=0x03	Status	IEEEAddress	ShortAddress	Device	Device	NumAssoc	AssocDevices
					Type	State	Devices	List

Status is a one byte field and is either success(0) or fail(1). The fail status is returned if the address value in the command message was not within the valid range.

IEEEAddress is an 8 byte field.

ShortAddress is a 2 byte field.

DeviceType is a 1 byte field indicating device type, where bits 0 to 2 indicate the capability for the device to operate as a coordinator, router, or end device, respectively.

DeviceState is a 1 byte field indicating the state of the device with different possible states as shown below:

Description	Value	
Initialized - not started automatically		
Initialized - not connected to anything	0x01	
Discovering PAN's to join	0x02	
Joining a PAN	0x03	
ReJoining a PAN, only for end devices	0x04	
Joined but not yet authenticated by trust center	0x05	
Started as device after authentication	0x06	
Device joined, authenticated and is a router	0x07	
Starting as Zigbee Coordinator	0x08	
Started as Zigbee Coordinator	0x09	
Device has lost information about its parent	0x0A	

NumAssocDevices is a 1 byte field specifying the number of devices being associated to the target device.

AssocDevicesList is a variable length array of 16-bits specifying the network address(es) of device(s) associated to the target device.

2.11 SYS_GET_NV_INFO

2.11.1 Description

This command is used by the tester to read a block of parameters from Non-Volatile storage of the target device.

2.11.2 Usage

The command message format is as follows

0x00

2.11.3 SYS GET NV INFO RESPONSE

The response to this command has the following format.

Cmd=0x101F Len=0x1F Status IEEEAddress	ScanChannels	PanID	SecurityLevel	PreConfigKey
--	--------------	-------	---------------	--------------

Status is a one byte field. A value of zero indicates success. Failure is indicated by a non-zero value, representaing a bit mask of each item that failed to be retrieved from NV memory. Bit0 is used for the first item (IEEEAddress), bit1 for the second item (ScanChannels), and so forth. Data values for failed items are returned as one or more bytes of 0xFF, the typical value read from erased NV memory.

IEEEAddress is an 8 byte field. This is the device's unique 64-bit extended address.

ScanChannels is a 4 byte field. This represents a bit-mask of channels to be scanned when starting the device.

PanID is a 1 byte field. Specifies the Pan ID to start or join. Set to 0xFFFF to select a PAN after scanning.

SecurityLevel is a 1 byte field. This specifies the network messaging security level, zero disables security.

PreConfigKey is a 16-byte field. This specifies the pre-configured security key.

2.12 SYS_SET_PANID

2.12.1 Description

Store a PanID value into Non-Volatile memory to be used the next time the target device resets.

2.12.2 Usage

The command message format is as follows

Cmd=0x001B	Len = 0x01	PanID
------------	------------	-------

PanID – 1 byte – The device's PanID.

2.12.3 SYS_SET_PANID_RESPONSE

The response to this command has the following format.

Cmd=0x101B	Len=0x01	Status
------------	----------	--------

The status is a success (0) or fail (non-zero NV error code).

2.13 SYS_SET_CHANNELS

2.13.1 Description

This command is used to store a channel select bit-mask into Non-Volatile memory to be used the next time the target device resets.

2.13.2 Usage

The command message format is as follows

Cmd=0x001C	Len = 0x04	Channels
------------	------------	----------

Channels – 4 bytes – A bit-mask representing the channel(s) to scan the next time the target device resets.

2.13.3 SYS_SET_CHANNELS_RESPONSE

The response to this command has the following format.

Cmd=0x101C	Len=0x01	Status
------------	----------	--------

The status is a success (0) or fail (non-zero NV error code).

2.14 SYS_SET_SECURITY_LEVEL

2.14.1 Description

This command is used to store a security level value into Non-Volatile memory to be used the next time the target device resets.

2.14.2 Usage

The command message format is as follows

Cmd=0x001D Le	n = 0x01	SecLevel
---------------	----------	----------

SecLevel – 1 byte – Security level to use the next time the target device resets. Zero is used to disable security.

2.14.3 SYS SET SECURITY LEVEL RESPONSE

The response to this command has the following format.

Cmd=0x101D	Len=0x01	Status
------------	----------	--------

The status is a success (0) or fail (non-zero NV error code).

2.15 SYS_SET_PRECONFIG_KEY

2.15.1 Description

This command is used to store a pre-configured key array into Non-Volatile memory to be used the next time the target device resets.

2.15.2 Usage

The command message format is as follows

Cmd=0x001E	Len = $0x10$	PreCfgKey
Cilid=0x001E	Len = $0x10$	riecigkey

PreCfgKey – 16 bytes – An array representing the pre-configured key to use the next time the target device resets.

2.15.3 SYS SET PRECONFIG KEY RESPONSE

The response to this command has the following format.

Cmd=0x101E	Len=0x01	Status
------------	----------	--------

The status is a success (0) or fail (non-zero NV error code).

2.16 Debug Messages

These messages are used by the tester to set debug threshold level for each software component in the target and receive debug messages from them. The tester uses the Set Debug Threshold command to set the threshold value for debug messages from each software component. The target sends asynchronous debug messages that exceed the threshold value to the tester.

2.16.1 SYS_SET_DEBUG_THRESHOLD

2.16.1.1 Description

This command is used by the tester to set the debug threshold level for a particular software component in the target.

2.16.1.2 Usage

The command message format is as follows

Cmd=0x0003	Len=0x02	ComponentID	Threshold
------------	----------	-------------	-----------

ComponentID is a 1 byte field that uniquely identifies a particular software component on the target. The list of software components and their identifiers is listed in Appendix A.

Threshold is a 1 byte field that specifies the threshold value for reporting debug messages by that software component. Its value can be set to CRITICAL (0x01), ERROR(0x02), INFORMATION(0x03) or TRACE(0x04). The software component will report all debug messages whose value exceeds the threshold. The current implementation only supports two levels of differentiation, either ON(>0x00) or OFF(0x00)

2.16.1.3 SYS SET DEBUG THRESHOLD RESPONSE

The response message has the following format

Cmd=0x1003	Len=0x01	Status
------------	----------	--------

The status field is 1 byte and indicates success(0) or fail(1). The fail status is returned if the component identifier in the command message was not valid.

2.16.2 SYS DEBUG MESSAGE

This message is sent by the tester to the target.

Cmd = 0x4003 Len=5+2n ComponentID	Value ParameterCount	Parameter1	Parameter2	Parameter3	Time	1
-----------------------------------	----------------------	------------	------------	------------	------	---

ComponentID is a 1 byte field that identifies the software component within the target that produced the debug message. The list of components and their identifiers is listed in Appendix A.

Value is a 1 byte field that indicates the severity of the debug message. It takes values of CRITICAL(0x01), ERROR(0x02), INFORMATION(0x03) or TRACE(0x04).

ParameterCount is a 1 byte field and indicates the number of parameters included in the message

TimeStamp is a 2 byte field and indicates the time of occurrence of the debug.

The debug message can have up to 3 parameters. The number of parameters is contained in the ParameterCount field (1 byte, ranges from 0-3) and the parameters themselves are contained (if present) in the parameter1, parameter2 and parameter3 fields (2 bytes each).

The length field has a value of 5+2n where n refers to the number of parameters included in the message.

2.17 SYS_RESET

2.17.1 Description

This command is sent by the tester to reset the target device.

2.17.2 Usage

The command message format is as follows

Cmd=0x0005	Len=0x01	Type
------------	----------	------

The type field is 1 byte and requests a target device reset (0) or serial bootloader reset (1). If the target device does not support serial bootloading, bootloader reset commands are ignored and no response is sent from the target.

2.17.3 SYS_RESET_RESPONSE

The response has the following format.

Cmd=0x1005	Len=0x01	Type
------------	----------	------

The type field indicates which reset operation is being reported – target device (0) or serial bootloader (1). This response is sent from the target device or serial bootloader after the requested reset is complete.

2.18 Callback Messages

Each of the following layer interfaces consists of 2 parts (command and callback). The commands are followed by an immediate response message, but the callbacks are asynchronous and can occur at unexpected times. With this command the tester can subscribe or unsubscribe from these callbacks.

2.18.1 SYS_CALLBACK_SUBSCRIBE

2.18.1.1 Description

This command subscribes/unsubscribes to layer callbacks.

2.18.1.2 Usage

The command message format is as follows.

Cmd=0x0006 Len=0x03	CommandID	Action
---------------------	-----------	--------

SubCommandID is a 2 byte field that contains the Command ID field of the expected callback message. Refer to Appendix A or the following callback sections for valid command IDs. A value of 0xFFFF indicates all callbacks.

Action is a 1 byte field that contains the action of the command (0 – unsubscribe, 1 – subscribe).

2.18.2 SYS_CALLBACK_SUBSCRIBE_RESPONSE

Cmd=0x1006	Len=0x01	Status
------------	----------	--------

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for failure codes).

2.19 SYS KEY EVENT

2.19.1 Description

Sends a key event to the device registered application. The device register application means that the application registered for key events with OnBoard. Not all applications support all keys, so you must know what keys the application supports.

2.19.2 Usage

The command message format is as follows.

Cmd=0x0016	Len=0x02	Shift	Key
------------	----------	-------	-----

Shift is a byte field with a Boolean value. True (0x01) means that the shift was enabled.

Key is a byte field with bit values for the keys. The following table has the key types:

Key Event	Bit
Key 1	0
Key 2	1
Key 3	2
Key 4	3
Key 5	4
Key 6	5
Key 7	6
Key 8	7

2.19.3 SYS_KEY_EVENT_RESPONSE

Cmd=0x1016	Len=0x01	Status
------------	----------	--------

Status is a 1 byte field that indicates SUCCESS(0) or FAILURE (see appendix for failure codes). Failure means that an application was registered to receive the key event.

2.20 SYS APP MSG

2.20.1 Description

Use this message to send raw data to an application. The request message may or may not get a response message. There could also be multiple and/or asynchronous response messages.

2.20.2 Usage

The command message format is as follows.

Cmd=0x0018	Len=0x01 + data length	Endpoint	Data
------------	------------------------	----------	------

Endpoint is a byte field – this represents the application endpoint to send the data to. Don't use this field to send ZDO messages (endpoint 0).

Data – a variable length field – raw data packet to send to the application.

2.20.3 SYS_APP_MSG_RESPONSE

G 1 0 1010	T	E 1 1 4	D.
Cmd=0x1018	Len=var	Endpoint	Data

Endpoint is a byte field – this represents the application endpoint the data is from.

Data is a variable length field – raw data packet from an application endpoint.

2.21 SYS LED CONTROL

2.21.1 Description

Use this message to control LEDs on the target board.

2.21.2 Usage

The command message format is as follows.

Cmd=0x0019 Len=2	LED	Mode
------------------	-----	------

LED is a byte field with the following possible values:

Value	Description
1	LED 1
2	LED 2
3	LED 3
4	LED 4
0xFF	All LEDs

Mode is a byte field with the following possible values:

Value	Description
0	LED Off
1	LED On
2	Blink
3	Flash
4	Toggle

2.21.3 SYS_LED_CONTROL_RESPONSE

Cmd=0x1019	Len=0x01	Status
------------	----------	--------

Status is a 1 byte field that will be SUCCESS(0) or FAILURE(1).

2.22 SYS_GET_TIME_ALIVE

2.22.1 Description

This command is used to request the length of the time period since the device's last reset in unit of second.

2.22.2 Usage

The command message format is as follows.

G 1 0 001 A	1 0 00
Cmd=0x001A	Len=0x00

2.22.3 SYS_GET_TIME_ALIVE_RESPONSE

Cmd=0x101A	Len=0x04	Seconds
------------	----------	---------

Second is a 4 byte field that will indicate the time duration in seconds.

3. MAC Interface

3.1 Introduction

These commands allow the tester to issue commands to the MAC layer in the target and receive responses. Each of these messages has a corresponding message that is returned by the target. The response message only indicates that the command message was received and executed. The result of the command execution will be conveyed to the tester via a callback message interface (defined in the next section), if applicable.

3.2 ZMAC_INIT_REQUEST

3.2.1 Description

This command is used to initialize the ZMAC on the current device (on behalf of the next higher layer).

3.2.2 Usage

Cmd	Length
0x0082	0x00

3.2.3 ZMAC_INIT_RESPONSE

Cmd	Length	Status
0x108	2 0x01	1byte

Status indicates SUCCESS or FAILURE

3.3 ZMAC_DATA_REQUEST

3.3.1 Description

This command is used to send (on behalf of the next higher layer) MAC Data Frame packet.

3.3.2 Usage

Cmd	Length	DestAddressMode	DestAddress	DestPanID	SrcAddressMode
0x0083	0x1C - 0x82	1 byte	8 bytes	2 bytes	1 byte

Handle	TxOptions	LogicalChannel	Power	KeySource	Security Level
1 byte	1 byte	1 byte	1byte	8 bytes	1 byte

KeyIdMode	KeyIndex	MSDULength	MSDU
1 byte	1 byte	1 byte	0-102 bytes

DestAddressMode: Specifies the format of the destination address.

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

DestAddress: Address of the destination. **DestPanID**: PAN ID of the destination.

SrcAddressMode: Specifies the format of the source address.

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

Handle: Handle of the packet.TxOption: Transmitting options

Description	Value
Acknowledged transmission	0x01
GTS transmission (unused)	
Indirect transmission	0x04
No retransmit transmission	0x10
No confirm transmission	
Use PIB value MAC_ALT_BE for the minimum backoff exponent transmission	0x40

LogicalChannel: Channel that data frame will be transmitted.

Power: Power level that data frame will be transmitted.

KeySource: Key Source of this data frame.

SecurityLevel: Security Level of this data frame.

Description	Value
No security is used	0x00

20

MIC-32 authentication is used	0x01
MIC-64 authentication is used	
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

KeyIdMode: Key Id Mode of this data frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this data frame.

MSDULength: Length of the data

MSDU: Actual data.

3.3.3 ZMAC_DATA_RESPONSE

Cmd	Length	Status
0x1083	1 byte	1byte

Status indicates SUCCESS or FAILURE

3.4 ZMAC_ASSOCIATE_REQUEST

3.4.1 Description

This command is used to request (on behalf of the next higher layer) an association with a coordinator

3.4.2 Usage

Cmd	Length	LogicalChannel	ChannelPage	CoordAddressMode	CoordAddress	CoordPanID
0x0084	0x19	1 byte	1 byte	1 byte	8 bytes	2 bytes

Capability Information	KeySource	SecurityLevel	KeyIdMode	KeyIndex
1 byte	8 bytes	1 bytes	1 bytes	1 byte

LogicalChannel: The channel that the device will associate.

ChannelPage: The channel page that the device will associate.

CoordAddressMode: Specifies the format of the coordinator device address.

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

CoordAddress: Address of the Coordinator **CoordPanID**: PAN ID of the coordinator.

CapabilityInformation: Bit map which specifies the operational capabilities of the device.

KeySource: Key Source of this data frame.

SecurityLevel: Security Level of this data frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	0x02
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

KeyIdMode: Key Id Mode of this data frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this data frame.

3.4.3 ZMAC_ASSOCIATE_RESPONSE

Cmd	Length	Status
0x1084	0x01	1 byte

Status indicates SUCCESS or FAILURE

3.5 ZMAC_ASSOCIATE_RESPOND

3.5.1 Description

This command is used to send (on behalf of the next higher layer) an association response message.

3.5.2 Usage

Cmd	Length	DeviceExtendedAddress	AssocShortAddress	Status
0x0085	0x16	8 bytes	2 bytes	1 byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

DeviceExtendedAddress: Extended Address of the device requesting association.

AssocShortAddress: The short address allocated to the device.

Status: Indicates success or failure

Description	Value
SUCCESS	0x00
FAILURE	0x01

KeySource: Key Source of this data frame.

SecurityLevel: Security Level of this data frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	
MIC-128 authentication is used	
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06

AES encryption and MIC-128 authentication are used	0x07

KeyIdMode: Key Id Mode of this data frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this data frame.

3.5.3 ZMAC_ASSOCIATE_RESPOND_RESPONSE

Cmd	Length	Status
0x1085	0x01	1 byte

Status indicates SUCCESS or FAILURE

3.6 ZMAC_DISASSOCIATE_REQUEST

3.6.1 Description

This command is used to request (on behalf of the next higher layer) a disassociation of the device from the coordinator.

3.6.2 Usage

Cmd	Length	DeviceAddressMode	DeviceAddress	DevicePanID	DisassociateReason	TxIndirect
0x0086	0x18	1 byte	8 bytes	2 bytes	1 byte	1 byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

DeviceAddressMode: Specifies the format of the device address.

Description	Value
Address Not Present	0x00

Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

DeviceAddress: The address of the device (specified by the mode above)

DevicePanID: Pan ID of the device.

DisassociateReason: Reason of disassociation.

TxIndirect: Transmit indirect.

KeySource: Key Source of this data frame.

SecurityLevel: Security Level of this data frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	
MIC-128 authentication is used	
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

KeyIdMode: Key Id Mode of this data frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this data frame.

3.6.3 ZMAC_DISASSOCIATE_RESPONSE

Cmd	Length	Status
0x1086	0x01	1byte

Status indicates SUCCESS or FAILURE

3.7 ZMAC_GET_REQUEST

3.7.1 Description

This command is used to read (on behalf of the next higher layer) a MAC PIB attribute.

3.7.2 Usage

Cmd	Length	Attribute
0x0087	0x01	1 byte

Attribute: Speicifies the MAC PID Attributes

Description	Value
ZMacAckWaitDuration	0x40
ZMacAssociationPermit	0x41
ZMacAutoRequest	0x42
ZMacBattLifeExt	0x43
ZMacBattLeftExtPeriods	0x44
ZMacBeaconMSDU	0x45
ZMacBeaconMSDULength	0x46
ZMacBeaconOrder	0x47
ZMacBeaconTxTime	0x48
ZMacBSN	0x49
ZMacCoordExtendedAddress	0x4A
ZMacCoordShortAddress	0x4B
ZMacDSN	0x4C
ZMacGTSPermit	0x4D
ZMacMaxCSMABackoffs	0x4E
ZMacMinBE	0x4F
ZMacPanId	0x50
ZMacPromiscuousMode	0x51
ZMacRxOnIdle	0x52
ZMacShortAddress	0x53
ZMacSuperframeOrder	0x54
ZMacTransactionPersistenceTime	0x55
ZMacAssociatedPanCoord	0x56

ZMacMaxBE	0x57
ZMacMaxFrameTotalWaitTime	0x58
ZMacMaxFrameRetries	0x59
ZMacResponseWaitTime	0x5A
ZMacSyncSymbolOffset	0x5B
ZMacTimestampSupported	0x5C
ZMacSecurityEnabled	0x5D
ZMacPhyTransmitPower	0xE0
ZMacLogicalChannel	0xE1
ZMacExtendedAddress	0xE2
ZMacAltBe	0xE3

3.7.3 ZMAC_GET_RESPONSE

Cmd	Length	Status
0x1087	0x01	1byte

Status indicates SUCCESS or FAILURE

3.8 ZMAC_ORPHAN_RESPOND

3.8.1 Description

This command is used to send a response to the Orphan Indication message.

3.8.2 Usage

Cmd	Length	OrphanExtendedAddress	OrphanShortAddress	AssociatedMember
0x0089	0x16	8 bytes	2 bytes	1 byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

OrphanExtendedAddress: Extended address of the device sending the orphan notification.

OrphanShortAddress: Allocated short address of the orphaned device.

AssociatedMember: TRUE if the orphaned device is associated with this coordinator.

KeySource: Key Source of this frame.

SecurityLevel: Security Level of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	0x02
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

KeyIdMode: Key Id Mode of this frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

3.8.3 ZMAC_ORPHAN_RESPOND_RESPONSE

Cmd	Length	Status
0x1089	0x01	1byte

Status indicates SUCCESS or FAILURE

3.9 ZMAC_POLL_REQUEST

3.9.1 Description

This command is used to send a MAC data request poll

3.9.2 Usage

Cmd	Length	CoordAddressMode	CoordAddress	CoordPanID
0x008F	0x16	1 byte	8 bytes	2 bytes

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

CoordAddressMode: Specified the format of the coordinator address

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

CoordAddress: Coordinator address
CoordPanID: PAN Id of the coordinator
KeySource: Key Source of this frame.

SecurityLevel: Security Level of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	0x02
MIC-128 authentication is used	
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	

KeyIdMode: Key Id Mode of this frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

3.9.3 ZMAC_POLL_RESPONSE

Cmd	Length	Status
0x108F	0x01	1byte

Status indicates SUCCESS or FAILURE

3.10 ZMAC_RESET_REQUEST

3.10.1 Description

This command is used to send a MAC Reset command to reset MAC state machine.

3.10.2 Usage

Cmd	Length	Set Default
0x0081	0x01	1 byte

Set Default:

3.10.3 ZMAC_RESET_RESPONSE

Cmd	Length	Status
0x1081	0x01	1byte

Status indicates SUCCESS or FAILURE

3.11 ZMAC_RX_ENABLE_REQUEST

3.11.1 Description

This command contains timing information that tells the device when to enable or disable its receiver, in order to schedule a data transfer between itself and another device. The information is sent from the upper layers directly to the MAC sub-layer.

3.11.2 Usage

Cmd	Length	DeferPermit	RxOnTime	RxOnDuration
0x008A	0x09	1 byte	4 bytes	4 bytes

Defer	Per	mit:
-------	-----	------

RxOnTime:

RxOnDuration:

3.11.3 ZMAC_RX_ENABLE_RESPONSE

Cmd	Length	Status
0x108A	0x01	1byte

Status indicates SUCCESS or FAILURE

3.12 ZMAC_SCAN_REQUEST

3.12.1 Description

This command is used to send a request to the device to perform a network scan.

3.12.2 Usage

Cmd	Length	ScanChannels	ScanType	ScanDuration	ChannelPage	MaxResults
0x008B	0x13	4 bytes	1 byte	1 byte	1 byte	1 byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

ScanChannels: Channels to be scanned.

ScanType: Type of the scan.

Description	Value
Energy detect scan	0x00
Active scan	0x01
Passive scan	0x02
Orphan Scan	0x03

ScanDuration: Duration of the scan.

Channel Page: Channel Page of this frame.

MaxResults: Maximum number of PAN descriptor results.

KeySource: Key Source of this frame.

Description	Value
No security is used	0x00

MIC-32 authentication is used	0x01
MIC-64 authentication is used	
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

3.12.3 ZMAC_SCAN_RESPONSE

Cmd	Length	Status
0x108B	0x01	1byte

Status indicates SUCCESS or FAILURE

3.13 ZMAC_SET_REQUEST

3.13.1 Description

This command is used to request the device to write a MAC PIB value.

3.13.2 Usage

Cmd	Length	Attribute	AttributeValue
0x008C	0x02-0x10	1 byte	1-15 bytes

Attribute: MAC PID

Description	Value

ZMacAckWaitDuration ZMacAssociationPermit ZMacAutoRequest ZMacBattLifeExt 0x43 ZMacBattLeftExtPeriods ZMacBatconMSDU ZMacBeaconMSDU ZMacBeaconMSDULength ZMacBeaconTxTime 0x48 ZMacBeaconTxTime 0x48 ZMacBascondExtendedAddress ZMacCoordExtendedAddress ZMacDSN ZMacCSMABackoffs ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacSuperframeOrder 0x52 ZMacSuperframeOrder 0x54 ZMacMaxBE ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacCSymbolOffset ZMacSyncSymbolOffset 0x50 ZMacPromiscuousWode 0x51 ZMacMaxFrameRetries 0x55 ZMacMaxFrameTotalWaitTime 0x56 ZMacCSyncSymbolOffset 0x50 ZMacPyransmitPower 0x50 ZMacPyTransmitPower 0x50 ZMacPyTransmitPower 0x50 ZMacCSuperframeOrder 0x51 ZMacCSuperframeOrder 0x56 ZMacCSyncSymbolOffset 0x57 ZMacCondExtendedAddress 0x59 ZMacCPyTransmitPower 0x50 ZMacCSuperframeOrder 0x51 ZMacCSuperframeRetries 0x59 ZMacCSuperframeRetries 0x59 ZMacCondExtendedAddress 0x50 ZMacCondExtendedAddress 0x50 ZMacCondExtendedAddress 0x50 ZMacCondExtendedAddress 0x50 ZMacCondExtendedAddress 0x60 ZMacCondExtendedAddr		
ZMacBattLifeExt 0x43 ZMacBattLeftExtPeriods 0x44 ZMacBaconMSDU 0x45 ZMacBeaconMSDULength 0x46 ZMacBeaconMSDULength 0x46 ZMacBeaconTxTime 0x48 ZMacBeaconTxTime 0x48 ZMacCoordExtendedAddress 0x4A ZMacCoordExtendedAddress 0x4A ZMacCoordShortAddress 0x4B ZMacCoordShortAddress 0x4C ZMacGTSPermit 0x4D ZMacGTSPermit 0x4D ZMacGTSPermit 0x50 ZMacMaxCSMABackoffs 0x4E ZMacMandacCoord 0x50 ZMacPromiscuousMode 0x51 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacSuperframeOrder 0x54 ZMacSuperframeOrder 0x55 ZMacAssociatedPanCoord 0x56 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameTotalWaitTime 0x58 ZMacCoordShortAddress 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5C ZMacScourityEnabled 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacAckWaitDuration	0x40
ZMacBattLeftExt 0x43 ZMacBattLeftExtPeriods 0x44 ZMacBeaconMSDU 0x45 ZMacBeaconMSDULength 0x46 ZMacBeaconTxTime 0x47 ZMacBeaconTxTime 0x48 ZMacBSN 0x49 ZMacCoordExtendedAddress 0x4A ZMacCoordShortAddress 0x4B ZMacDSN 0x4C ZMacGTSPermit 0x4D ZMacGTSPermit 0x4D ZMacMancESMABackoffs 0x4E ZMacMandE 0x4F ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacSuperframeOrder 0x54 ZMacSuperframeTotalWaitTime 0x55 ZMacMaxBE 0x57 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacPhyTransmitPower 0xE0 <t< td=""><td>ZMacAssociationPermit</td><td>0x41</td></t<>	ZMacAssociationPermit	0x41
ZMacBattLeftExtPeriods ZMacBeaconMSDU 0x45 ZMacBeaconMSDULength 0x46 ZMacBeaconMSDULength 0x47 ZMacBeaconTxTime 0x48 ZMacBsN 0x49 ZMacCoordExtendedAddress 0x4A ZMacCoordShortAddress 0x4B ZMacCSN 2MacCSNABackoffs 0x4C ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacCTransactionPersistenceTime 0x55 ZMacMaxFameTotalWaitTime 0x58 ZMacCSyncSymbolOffset 0x5B ZMacSyncSymbolOffset 0x5D ZMacPonseive 0x5D ZMacSecurityEnabled 0x5D ZMacPonseive 0x5D ZMacSecurityEnabled 0x5D ZMacPonseive 0x5D ZMacSported 0x5D ZMacSported 0x56 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameTotalWaitTime 0x5A ZMacSyncSymbolOffset 0x5D ZMacSported 0x5D ZMacPhyTransmitPower 0xE0 ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1	ZMacAutoRequest	0x42
ZMacBeaconMSDU	ZMacBattLifeExt	0x43
ZMacBeaconMSDULength ZMacBeaconOrder ZMacBeaconTxTime ZMacBSN ZMacCoordExtendedAddress ZMacCoordShortAddress ZMacDSN ZMacGTSPermit ZMacGTSPermit ZMacMaxCSMABackoffs ZMacPanId ZMacPanId ZMacPromiscuousMode ZMacShortAddress ZMacSuperframeOrder ZMacSuperframeOrder ZMacAssociatedPanCoord ZMacMaxFrameTotalWaitTime ZMacSyncSymbolOffset ZMacSyncSymbolOffset ZMacSiperlingsupported ZMacSiperlingsupported ZMacSiperlingsupported ZMacSiperlingsupported ZMacSyncSymbolOffset ZMacSyncSymbolOffset ZMacSiperlingsupported ZMacSiperlingsupported	ZMacBattLeftExtPeriods	0x44
ZMacBeaconOrder 0x47 ZMacBeaconTxTime 0x48 ZMacBSN 0x49 ZMacCoordExtendedAddress 0x4A ZMacCoordShortAddress 0x4B ZMacDSN 0x4C ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacMaxCSMABackoffs 0x4E ZMacMinBE 0x4F ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacResponseWaitTime 0x58 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2<	ZMacBeaconMSDU	0x45
ZMacBeaconTxTime 0x48 ZMacBSN 0x49 ZMacCoordExtendedAddress 0x4A ZMacCoordShortAddress 0x4B ZMacDSN 0x4C ZMacDSN 0x4C ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacManBE 0x4F ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacFhyTransmitPower 0x5D ZMacPhyTransmitPower 0xE0 ZMacExtendedAddress 0xE2	ZMacBeaconMSDULength	0x46
ZMacBSN 0x49 ZMacCoordExtendedAddress 0x4A ZMacCoordShortAddress 0x4B ZMacDSN 0x4C ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacMinBE 0x4F ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacBeaconOrder	0x47
ZMacCoordExtendedAddress 0x4A ZMacCoordShortAddress 0x4B ZMacDSN 0x4C ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacMinBE 0x4F ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacSuperframeOrder 0x54 ZMacAssociatedPanCoord 0x55 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacExtendedAddress 0xE2	ZMacBeaconTxTime	0x48
ZMacCoordShortAddress 0x4B ZMacDSN 0x4C ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacMinBE 0x4F ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacBSN	0x49
ZMacDSN 0x4C ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacMinBE 0x4F ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacPhyTransmitPower 0x5D ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacCoordExtendedAddress	0x4A
ZMacGTSPermit 0x4D ZMacMaxCSMABackoffs 0x4E ZMacMinBE 0x4F ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0x52	ZMacCoordShortAddress	0x4B
ZMacMaxCSMABackoffs ZMacMinBE ZMacPanId 0x50 ZMacPromiscuousMode ZMacRxOnIdle ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5C ZMacSecurityEnabled 0x5D ZMacPoscaledPanCoord 0x5C ZMacCDanabled 0x5D ZMacSyncSymbolOffset 0x5D ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0x50	ZMacDSN	0x4C
ZMacPanId 0x50 ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacResponseWaitTime 0x58 ZMacSyncSymbolOffset 0x58 ZMacTimestampSupported 0x5C ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0x52	ZMacGTSPermit	0x4D
ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0x52	ZMacMaxCSMABackoffs	0x4E
ZMacPromiscuousMode 0x51 ZMacRxOnIdle 0x52 ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0x52	ZMacMinBE	0x4F
ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0x52	ZMacPanId	0x50
ZMacShortAddress 0x53 ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacPromiscuousMode	0x51
ZMacSuperframeOrder 0x54 ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacRxOnIdle	0x52
ZMacTransactionPersistenceTime 0x55 ZMacAssociatedPanCoord 0x56 ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacShortAddress	0x53
ZMacAssociatedPanCoord ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0x57	ZMacSuperframeOrder	0x54
ZMacMaxBE 0x57 ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacTransactionPersistenceTime	0x55
ZMacMaxFrameTotalWaitTime 0x58 ZMacMaxFrameRetries 0x59 ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacAssociatedPanCoord	0x56
ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacMaxBE	0x57
ZMacResponseWaitTime 0x5A ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacMaxFrameTotalWaitTime	0x58
ZMacSyncSymbolOffset 0x5B ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacMaxFrameRetries	0x59
ZMacTimestampSupported 0x5C ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacResponseWaitTime	0x5A
ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacSyncSymbolOffset	0x5B
ZMacSecurityEnabled 0x5D ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	ZMacTimestampSupported	0x5C
ZMacPhyTransmitPower 0xE0 ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2		0x5D
ZMacLogicalChannel 0xE1 ZMacExtendedAddress 0xE2	•	0xE0
ZMacExtendedAddress 0xE2	ZMacLogicalChannel	
		0xE2
	ZMacAltBe	0xE3

AttributeValue: 1-16 bytes value of the attribute

3.13.3 ZMAC_SET_RESPONSE

Cmd	Length	Status
0x108C	0x01	1byte

Status indicates SUCCESS or FAILURE

3.14 ZMAC_START_REQUEST

3.14.1 Description

This command is used to request the MAC to transmit beacons and become a coordinator

3.14.2 Usage

Cmd	Length	StartTime	PanID	LogicalChannel	ChannelPage	BeaconOrder
0x008D	0x23	4 bytes	2 bytes	1 byte	1 byte	1 byte

SuperFrameOrder	PanCoordinator	BatteryLifeExt	CoordRealignment
1 byte	1 byte	1 byte	1 byte

RealignKeySource	RealignSecurityLevel	RealignKeyIdMode	RealignKeyIndex
8 bytes	1 bytes	1 bytes	1 byte

BeaconKeySource	BeaconSecurityLevel	BeaconKeyIdMode	BeaconKeyIndex
8 bytes	1 bytes	1 bytes	1 byte

StartTime: The time to begin transmitting beacons relative to the received beacon.

PanID: The PAN ID to use. This parameter is ignored if Pan Coordinator is FALSE.

Logical Channel: The logical channel to use. This parameter is ignored if Pan Coordinator is FALSE.

ChannelPage: The channel page to use. This parameter is ignored if Pan Coordinator is FALSE.

BeaconOrder: The exponent used to calculate the beacon interval.

SuperFrameOrder: The exponent used to calculate the superframe duration.

PanCoordinator: Set to TRUE to start a network as PAN coordinator.

BatteryLifeExt: If this value is TRUE, the receiver is disabled after MAC_BATT_LIFE_EXT_PERIODS full

backoff periods following the interframe spacing period of the beacon frame

CoordRealignment: Set to TRUE to transmit a coordinator realignment prior to changing the superframe configuration.

RealignKeySource: Key Source of this frame.

RealignSecurityLevel: Security Level of this frame.

Description	Value	
No security is used	0x00	
MIC-32 authentication is used	0x01	
MIC-64 authentication is used		
MIC-128 authentication is used	0x03	
AES encryption is used	0x04	
AES encryption and MIC-32 authentication are used	0x05	
AES encryption and MIC-64 authentication are used		
AES encryption and MIC-128 authentication are used	0x07	

RealignKeyIdMode: Key Id Mode of this frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

RealignKeyIndex: Key Index of this frame. **BeaconKeySource**: Key Source of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	0x02
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05

AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

BeaconKeyIndex: Key Index of this data frame.

3.14.3 ZMAC_START_RESPONSE

Cmd	Length	Status
0x108D	0x01	1byte

Status indicates SUCCESS or FAILURE

3.15 ZMAC_SYNCHRONIZE_REQUEST

3.15.1 Description

This command is used to request synchronization to the current network beacon

3.15.2 Usage

Cmd	Length	LogicalChannel	ChannelPage	TrackBeacon
0x008E	0x03	1 byte	1 byte	1 byte

LogicalChannnel: The logical channel to use.

Channel Page: The channel page to use.

TrackBeacon: Set to TRUE to continue tracking beacons after synchronizing with the first beacon. Set to FALSE to only synchronize with the first beacon.

3.15.3 ZMAC_SYNCHRONIZE_RESPONSE

Cmd	Length	Status
0x108E	0x01	1byte

Status indicates SUCCESS or FAILURE.

3.16 ZMAC_PURGE_REQUEST

3.16.1 Description

This command is used to send a request to the device to purge a data frame.

3.16.2 Usage

Cmd	Length	msduHandle
0x0090	0x01	1 byte

msduHandle: Handle of this frame

3.16.3 ZMAC_PURGE_RESPONSE

Cmd	Length	Status
0x1090	0x01	1byte

Status indicates SUCCESS or FAILURE

4. MAC CALLBACK INTERFACE

4.1 Introduction

This message interface enables the target MAC to issue callbacks to the tester. Each message has a response to a message that is sent by the tester to the target. The response message only indicates successful reception of the callback message. These messages are subscription messages. Refer to SYS_CALLBACK_SUBSCRIBE for a description of the subscription mechanism.

4.2 NWK_ASSOCIATE_INDICATION

4.2.1 Description

This function is used to indicate the reception of an association request command.

4.2.2 Usage

Cmd	Length	DeviceAddress	CapabilityInformation
0x2081	0x14	8 bytes	1 byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

DeviceAddress: Address of the associated device

CapabilityInformation: capability of the associated device

KeySource: Key Source of this frame.

SecurityLevel: Security Level of this frame.

Description		
No security is used		
MIC-32 authentication is used	0x01	
MIC-64 authentication is used	0x02	
MIC-128 authentication is used	0x03	
AES encryption is used	0x04	
AES encryption and MIC-32 authentication are used	0x05	
AES encryption and MIC-64 authentication are used		
AES encryption and MIC-128 authentication are used	0x07	

KeyIdMode: Key Id Mode of this frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

4.3 NWK_ASSOCIATE_CONFIRMATION

4.3.1 Description

This function is used to inform the upper layers of the initiating device whether its request to associate was successful or unsuccessful.

4.3.2 Usage

Cmd	Length	Status	AllocatedAddress
0x2082	0x0E	1 byte	2 bytes

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

Status: Status of the association

AllocatedAddress: Allocated address **KeySource**: Key Source of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	
MIC-128 authentication is used	
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	
AES encryption and MIC-128 authentication are used	0x07

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

4.4 NWK_DISASSOCIATE_INDICATION

4.4.1 Description

This function is used to indicate the reception of a disassociation notification command.

4.4.2 Usage

I	Cmd	Length	DeviceAddress	DisassociateReason
	0x2086	0x14	8 bytes	1 byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

DeviceAddress: Address of the initiating device **DisassociateReason**: Reason of the disassociation

KeySource: Key Source of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	0x02
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06

AES encryption and MIC-128 authentication a	are used 0x07

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

4.5 NWK_DISASSOCIATE_CONFIRMATION

4.5.1 Description

This function is sent as the result of a disassociation request.

4.5.2 Usage

Cmd	Length	Status	DeviceAddressMode	DeviceAddress	PanID
0x2087	0x0c	1 byte	1 byte	8 bytes	2 byte

Device Address:

Status: SUCCESS of FAILURE

4.6 NWK_BEACON_NOTIFY_INDICATION

4.6.1 Description

This function is used to send parameters contained within a beacon frame received by the MAC sub-layer to the next higher layer. The function also sends a measure of the link quality and the time the beacon was received.

4.6.2 Usage

Cmd	Length	BSN	TimeStamp	CoordAddressMode	CoordAddress	CoordPanID
0x2083	0x23 - 0x63	1 byte	4 bytes	1 byte	8 bytes	2 bytes

SuperFrameSpec	LogicalChannel	GTSPermit	LinkQuality	SecurityFailure
2 bytes	1 byte	1 byte	1 byte	1 byte

TZ C	G : T 1	77 7 13 7 1	TZ T 1
KeySource	SecurityLevel	KeyIdMode	KeyIndex

8 bytes	1 bytes	1 bytes	1 byte

PendingAddrSpec	AddrList	SDULength	SDU
1 byte	0-32 bytes	1 byte	0-32 bytes

BSN: Beacon sequence number.

TimeStamp: Time stamp when the beacon is received.

CoordAddressMode:

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

CoordAddress: Address of the coordinator. **CoordPanID**: PAN ID of the coordinator.

SuperFrameSpec: The superframe specification of the network.

LogicalChannel: The logical channel of the network.

GTSPermit: TRUE if coordinator accepts GTS requests. **LinkQuality**: The link quality of the received beacon.

SecurityFailure: Set to TRUE if there was an error in the security processing.

KeySource: Key Source of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	0x02
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05

AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

PendingAddrSpec: The beacon pending address specification.

AddrList: The list of device addresses for which the sender of the beacon has data.

SDULength: Length of the SDU data.

SDU: Actual SDU data. Can be 0-32 bytes

4.7 NWK_ORPHAN_INDICATION

4.7.1 Description

This function allows the MLME to notify the next higher layer of an orphaned device.

4.7.2 Usage

Cmd	Length	OrphanAddress
0x208a	0x13	8 bytes

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

OrphanAddress:

KeySource: Key Source of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01

MIC-64 authentication is used	0x02
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

4.8 NWK_SCAN_CONFIRMATION

4.8.1 Description

This function reports the results of a channel scan request.

4.8.2 Usage

Cmd	Length	Status	EDMaxEnergy	ScanType
0x208c	0x09 - 0x29	1 byte	1 byte	1 byte

ChannelPage	UnscannedChannels	ResultCount	Results
1byte	4 bytes	1 byte	0-32 bytes

Status: Status of the scan request

EDMaxEnergy: Maximum possible energy detect value

ScanType: Type of scan request

Description	Value
Energy detect scan	0x00

Active scan	0x01
Passive scan	0x02
Orphan Scan	0x03

ChannelPage: The channel page of the scan

UnscannedChannels: Bit mask of channels that were not scanned

ResultListSize: The number of PAN descriptors returned in the results list

Results: List of energy measurements or PAN descriptors (depends on the scan type)

4.9 NWK_START_CONFIRMATION

4.9.1 Description

This function reports the success of the start request.

4.9.2 Usage

Cmd	Length	Status
0x208e	0x01	1 byte

Status: SUCCESS or FAILURE

4.10 NWK_SYNCHRONIZATION_LOSS_INDICATION

4.10.1 Description

This function indicates the loss of synchronization of a network beacon

4.10.2 Usage

Cmd	Length	Reason	PANId	LogicalChannel	ChannelPage
0x2080	0x10	1 byte	2bytes	1byte	1byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

Reason: Reason that synchronization was lost

Logical Channel: Logical channel for this frame.

ChannelPage: Channel page for this frame.

KeySource: Key Source of this frame.

Description				
No security is used	0x00			
MIC-32 authentication is used	0x01			
MIC-64 authentication is used				
MIC-128 authentication is used				
AES encryption is used	0x04			
AES encryption and MIC-32 authentication are used	0x05			
AES encryption and MIC-64 authentication are used	0x06			
AES encryption and MIC-128 authentication are used	0x07			

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

4.11 NWK_POLL_CONFIRMATION

4.11.1 Description

This function reports the results of a polling attempt.

4.11.2 Usage

Cmd	Length	Status
0x208b	0x01	1 byte

Status: SUCCESS or FAILURE

4.12 NWK_COMM_STATUS_INDICATION

4.12.1 Description

This function reports a comm status error.

4.12.2 Usage

ID	Length	Status	SrcAddressMode	SrcAddress	DestAddressMode	DestAddress	PanID	Reason
0x208d	0x21	1 byte	1 byte	8 bytes	1 byte	8 bytes	2 bytes	1 byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex
8 bytes	1 bytes	1 bytes	1 byte

Status: Status of the indication.

SrcAddressMode: Indicates the format of the source address

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

SrcAddress: Address of the initiating device

DestAddressMode:

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

DestAddress: Address of the remote device

PanID: PAN ID of the remote device

 $\textbf{Reason:} \ The \ reason \ of \ the \ event.$

KeySource: Key Source of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	0x02

MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame.

4.13 NWK_DATA_CONFIRMATION

4.13.1 Description

This function is used to send the results of a request to transfer a data SPDU (MSDU) from a local SSCS entity to a single peer SSCS entity, or multiple peer SSCS entities.

4.13.2 Usage

I	Cmd	Length	Status	msduHandle	Timestamp	Timestamp2
	0x2084	0x08	1 byte	1 byte	4 bytes	2 bytes

Status: Status of the frame

msduHandle: Handle of the frame

Timestamp: The time, in backoffs, at which the data were received

Timestamp2: The time, in internal MAC timer units, at which the data were recieved

4.14 NWK_DATA_INDICATION

4.14.1 Description

This function indicates the transfer of a data SPDU (MSDU) from the MAC sub-layer to the local SSCS entity.

4.14.2 Usage

Cmd	Length	SrcAddressMode	SrcAddress	DestAddressMode	DestAddress
0x2085	0x2C - 0x92	1 byte	8 bytes	1 byte	8 bytes

Tin	nestamp	Timestamp2	SrcPanID	DestPanID	mpduLinkQuality	Lqi	Rssi	Dsn
4	bytes	2 bytes	2 bytes	2 bytes	1 byte	1 byte	1 byte	1 byte

KeySource	SecurityLevel	KeyIdMode	KeyIndex	MSDULength	MSDU
8 bytes	1 bytes	1 bytes	1 byte	1 byte	0-102 bytes

SrcAddressMode:

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

SrcAddress: Address of the initiating device

DestAddressMode:

Description	Value
Address Not Present	0x00
Address 16 bit	0x02
Address 64 bit	0x03
Broadcast	0xFF

DestAddress: Address of the remote device

Timestamp: The time, in backoffs, at which the data were received

Timestamp2: The time, in internal MAC timer units, at which the data were received

SrcPanID: Pan Id of the initiating device **DestPanID**: Pan Id of the remote device

mpduLinkQuality:

Lqi: Raw LQI of the received data frame.Rssi: Raw RSSI of the received data frame.

Dsn:

KeySource: Key Source of this frame.

SecurityLevel: Security Level of this frame.

Description	Value
No security is used	0x00
MIC-32 authentication is used	0x01
MIC-64 authentication is used	0x02
MIC-128 authentication is used	0x03
AES encryption is used	0x04
AES encryption and MIC-32 authentication are used	0x05
AES encryption and MIC-64 authentication are used	0x06
AES encryption and MIC-128 authentication are used	0x07

KeyIdMode: Key Id Mode of this frame.

Description	Value
Key is not used / Key is determined implicitly	0x00
Key is determined from the 1-byte key index	0x01
Key is determined from the 4-byte key index	0x02
Key is determined from the 8-byte key index	0x03

KeyIndex: Key Index of this frame. **MSDULength**: Length of the data

MSDU: The actual data

4.15 NWK_RX_ENABLE_CONFIRMATION

4.15.1 Description

This function reports the results of an RX enable attempt.

4.15.2 Usage

Cmd	Length	Status
0x208f	0x01	1 byte

Status: SUCCESS or FAILURE

4.16 NWK_PURGE_CONFIRMATION

4.16.1 Description

This function reports the results of a purge attempt.

4.16.2 Usage

Cmd	Status	Length	msduHandle
0x2090	1 byte	0x02	1 byte

msduHandle: Application-defined handle value associated with the data request.

Status: SUCCESS or FAILURE

5. NWK Interface

5.1 Introduction

These commands allow the tester to issue commands to the NWK layer in the target and receive responses. Each of these messages has a corresponding message that is returned by the target. The response message only indicates that the command message was received and executed. The result of the command execution will be conveyed to the tester via a callback message interface (defined in the next section), if applicable.

5.2 NLDE DATA REQUEST

5.2.1 Description

This command enables the tester to request the transfer of data from the local APS sub-layer to a peer APS sub-layer entity.

5.2.2 **Usage**

The message format is as follows.

С	md = 0x0101	Len = variable	DestAddress	NSDULength	NSDU	NSDUHandle	NSDUHandleOptions
	SecurityEnable Disco		coverRoute	RadiusCounter			

DestAddress is a 2 byte field which is the short address of the destination device.

NSDULength is a byte field which indicates the length of the NSDU.

NSDU is the actual network data packet which is of size indicated by nsduLength.

NSDUHandle is a byte field which indicates the transaction handle (that was created when the data request was issued)

NSDUHandleOptions is a 2 byte field which indicates the options applied to the transmission of this packet.

SecurityEnable is a 1 byte field which, if set to FALSE (0x00), explicitly prohibits this packet from being secured.

DiscoverRoute is a 1 byte field which, if set to TRUE (non-zero value), will attempt a route discovery operation for the destination device if no route already exists.

RadiusCounter is a 1 byte field which determines how many hops this packet will travel in the network.

5.2.3 NLDE_DATA_RESPONSE

Cmd = 0x0101 Len = 0x01 Star	atus	Status	Len = 0x01	Cmd = 0x0101
----------------------------------	------	--------	------------	--------------

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLDE status codes).

5.3 NLME_NETWORK_FORMATION_REQUEST

5.3.1 Description

This command is used by tester to request (on behalf of the next higher layer) that the device be initiated as a coordinator.

5.3.2 Usage

The message format is as follows

Cmd = 0x0102	Len = 0x03	PanID	ScanChannels	ScanDuration	BeaconOrder	SuperFameOrder	BattervLifeExtension
Cina onoroz	Een onos	I will	Seamenanners	Scan Baration	Beaconoraci	Superi ame oraci	BatteryEneEntension

PanID is a 2 bytes short address of the intended device.

ScanChannels is a 4 bytes field indicates the list of channels in bit map format.

ScanDuration is a byte field represents the scanning time.

BeaconOrder is a byte field which represents the beacon order type. This parameter doesn't make sense in a non-beacon device. If this value is set to anything other than BEACON_ORDER_NO_BEACONS (0xf) and the device is compiled as a mesh mode device, the response message's status field will be set to ZNwkInvalidParam (0xc1).

SuperFrameOrder is a byte field which specifies the length of the active portion of the superframe. This parameter doesn't make sense in a non-beacon device. If this value is set to anything other than BEACON_ORDER_NO_BEACONS (0xf) and the device is compiled as a mesh mode device, the response message's status field will be set to ZNwkInvalidParam (0xc1).

BatteryLifeExtension is a byte field which indicates whether NLME will request that the ZigBee coordinator is started supporting battery life extension mode.

5.3.3 NLME NETWORK FORMATION RESPONSE

Cmd = 0x1102	Len = 0x01	Status
--------------	------------	--------

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

5.4 NLME_PERMITJOINING_REQUEST

5.4.1 Description

This command is used by the tester to define how the next higher layer of a coordinator device would permit devices to join its network for a fixed period.

5.4.2 Usage

Cmd = 0x0103	I en - 0x01	PermitDuration
Ciliu – UNUTUS	LCII - UXUI	1 CHIIILDUI ation

PermitDuration is a byte field which indicates the length of time during which the ZigBee coordinator will be allowing associations. The values 0x00 and 0xff indicate that permission is disabled or enabled, respectively.

5.4.3 Response

Cmd = 0x1103	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

5.5 NLME_JOIN_REQUEST

5.5.1 Description

This command is used by tester to make a request (on behalf of the next higher layer) to join the device itself or another device to a network.

5.5.2 Usage

The message format is as follows.

Cı	md = 0x0104	Len = $0x0a$	PanID	Channel	CapabilityInfo
----	-------------	--------------	-------	---------	----------------

PanID is a 2 bytes field and indicates the short address of the intended device.

Channel is a byte field and specifies the channel of the intended device.

CapabilityInfo is a byte field which is a bitmap which specifies the operational capabilities of the joining device. The meaning of each bit is specified in the following table.

Meaning	Bit map
Alternate Pan coordinator	0
Device type	1
Power source	2
Receiver on when idle	3

Reserved	4-5
Security capability	6
Allocate address	7

5.5.3 NLME_JOIN_RESPONSE

Cmd = 0x1104	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

5.6 NLME_LEAVE_REQUEST

5.6.1 Description

This command is used by tester to make a request (on behalf of the next higher layer) that the device itself or one of its child devices leave the network.

5.6.2 Usage

The message format is as follows

DeviceAddress is an 8-byte field that specifies which device is being asked to leave the network. An address of zero is used to indicate the device itself. An 8-byte IEEE extended address is used to indicate one of the device's children.

RemoveChildren(a 1 byte field) indicates whether the device, specified by the DeviceAddress, should remove its children.

Reassociate(a 1 byte field) indicates whether the device, specified by the DeviceAddress, should reassociate after it leaves. It has value of either 1 or 0. If the filed has a value of 1, the device being asked to leave form the current parent is requested to rejoin the network again after the leave. Otherwise, it does not reassociate.

5.6.3 NLME LEAVE RESPONSE

Cmd = 0x1105	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

5.7 NLME_RESET_REQUEST

5.7.1 Description

This command is used by tester to make a request (on behalf of the next higher layer) that the NWK layer perform a reset operation

5.7.2 Usage

The message format is as follows

Cmd = $0x0106$ Len = $0x00$

5.7.3 NLME_RESET_RESPONSE

Cmd = 0x1106	Len = 0x01	Status
--------------	------------	--------

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

5.8 NLME_SYNC_REQUEST

5.8.1 **Usage**

The message format is as follows

|--|

Track is a 1 byte field. 1 = track beacons, = 0 do no track beacons.

5.8.2 NLME_SYNC_RESPONSE

$Cmd = 0x1107 \qquad Len = 0x01 \qquad Statu$	S
---	---

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

5.9 NLME_GET_REQUEST

5.9.1 Description

This command is used by tester to make a request (on behalf of the next higher layer) to read the value of an attribute from the NWK information base (NIB).

5.9.2 Usage

The message format is as follows

Cmd = 0x0108 Len = $0x02$ NIBAttribute	Index	Value
--	-------	-------

NIBAttribute is a byte field which identifies the intended attribute of the NIB.

Index is a byte field and is used to index into table NIB items.

Value is a two byte field that contains the data value

5.9.3 NLME_GET_RESPONSE

$Cmd = 0x1108 \qquad Len = 0x0B$	Status	NIBAttributeValue
----------------------------------	--------	-------------------

Status is a 1 byte field that indicates SUCCESS or FAILURE.

NIBAttributeValue is a 16 byte field to store the attribute value. The field is 16 bytes to accommodate the largest attribute.

5.10 NLME_SET_REQUEST

5.10.1 Description

This command is used by tester to make a request (on behalf of the next higher layer) to set the value of an attribute in the NWK information base (NIB).

5.10.2 Usage

The message format is as follows

Cmd = 0x0109	Len = 0x0C	NIBAttribute	Index	NIBAttributeValue

NIBAttribute is a byte field which identifies the intended attribute of the NIB.

Index is a 1 byte field which contains the index into table NIB items.

NIBAttributeValue is a 16 byte field which specifies the value of the NIBAttribute. The field is 16 bytes to accommodate the largest attribute.

5.10.3 NLME_SET_RESPONSE

Cmd = 0x1109	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

5.11 NLME_NETWORKDISCOVERY_REQUEST

5.11.1 Description

This command is used by tester to scan channels for networks.

5.11.2 Usage

The message format is as follows

Cmd = 0x010B	Len $=0x5$	ScanChannels	ScanDuration

ScanChannels is a 4 byte field which is the network scan list

ScanDuration is a 1 byte field which scan duration is 2 times the beacon order values.

5.11.3 NLME_NETWORKDISCOVERY_RESPONSE

Cmd = 0x110B	Len = 0x01	Status
CIIIa = 0x110b	Len = $0x01$	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

5.12 NLME_ROUTEDISCOVERY_REQUEST

5.12.1 Description

This command is used by tester to force a route discovery.

5.12.2 Usage

The message format is as follows

Cmd = 0x010C	Len = 0x3	DestAddress	Repair

DestAddress is a 2 byte field which address to do a route for.

Repair is a 1 byte field which specifies a route repair operation if set to TRUE.

5.12.3 NLME_ROUTEDISCOVERY_RESPONSE

Cmd = 0x110C	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

5.13 NLME_DIRECTJOIN_REQUEST

5.13.1 Description

This allows the tester to request to join itself or another device to a network.

5.13.2 Usage

The message format is as follows

Cmd = 0x010D Len = 0x9 ExtendedAddress CapabilityInfo

ExtendedAddress is an 8 byte field – 64 byte address of child device.

CapabilityInfo is a 1 byte field – capability information of the child device.

5.13.3 NLME_ DIRECTJOIN _RESPONSE

		_
Cmd = 0x110D	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

5.14 NLME_ORPHANJOIN_REQUEST

5.14.1 Description

This command is used by tester to search for its parent.

5.14.2 Usage

The message format is as follows

Cmd = 0x010E	Len =0x5	ScanChannels	ScanDuration
--------------	----------	--------------	--------------

ScanChannels is a 4 byte field – Channels on which to discover parent.

ScanDuration is a 1 byte field – Time duration to scan each channel.

5.14.3 NLME_ORPHANJOIN_RESPONSE

Cmd = 0x110E	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

5.15 NLME_STARTROUTER_REQUEST

5.15.1 Description

This command is used by tester to request the device to start functioning as a router.

5.15.2 Usage

The message format is as follows

Cmd = 0x010F Len = 0x3 BeaconOrder SuperFrameOrder BatteryLifeExtension

BeaconOrder is a 1 byte field – beacon order

SuperFrameOrder is a 1 byte field – superframe order

BatteryLifeExtension is a 1 byte field – true if the device is a battery operated device.

5.15.3 NLME_STARTROUTER_RESPONSE

Cmd = 0x110F	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

6. NWK Callback Interface

6.1 Introduction

This message interface enables the target NWK to issue callbacks to the tester. Each message has a response to a message that is sent by the tester to the target. The response message only indicates successful reception of the callback message. These messages are subscription messages. Refer to SYS_CALLBACK_SUBSCRIBE for a description of the subscription mechanism.

6.2 NLDE_DATA_CONFIRMATION

6.2.1 Description

This message is issued by the target NWK to the tester to report the results of a request to transfer a data PDU from a local APS sub-layer entity to a single peer APS sub-layer entity.

6.2.2 Usage

The message format is as follows

Cmd=0x0180	Len=0x02	NSDUHandle	Status

NSDUHandle is a byte field which indicates the transaction handle (that was created when the data request was issued)

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLDE status codes).

6.3 NLDE_DATA_INDICATION

6.3.1 Description

This message is issued by the target NWK to the tester to indicate the transfer of a data PDU from the NWK layer to the local APS sub-layer entity.

6.3.2 Usage

The packet format is as follows

Cmd=0x0181	Len=var	SrcAddress	NSDULength	NSDU	LinkQuality

SrcAddress is a 2 byte field which is the short address of the source device.

NSDULength is a byte field which indicates the length of the NSDU.

NSDU is the actual network data packet which is of size indicated by NSDULength.

LinkQuality is a byte field which indicates the link quality measured during reception.

6.4 NLME NETWORKFORMATION CONFIRMATION

6.4.1 Description

This message is used by the target NWK to inform the tester of the result of a previous association request command.

6.4.2 Usage

The message format is as follows

Cmd=0x0182	Len=0x01	Status
CIIId-0X0102	LCII-OXO I	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

6.5 NLME_JOIN_CONFIRMATION

This command is issued by the target NWK (to tester) to notify the next higher layer of the results of its request to join itself or another device to a network.

6.5.1 Usage

The packet format is as follows.

Cmd=0x0183	Len=0x09	DeviceAddress	PanId	Status

DeviceAddress is an 8 byte field which specifies the IEEE extended address of the device

PanId is a 2 byte field that indicates the PAN identifier of the network to which the device has joined.

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

6.6 NLME JOIN INDICATION

6.6.1 Description

This message is sent by the target to notify the next higher layer of a remote join request.

6.6.2 Usage

The message format is as follows

C 1 0 0104	T 0 01	C1	E . 1 14 11	G 1317 I G
Cmd = 0x0184	Len = 0x0b	ShortAddress	ExtendedAddress	CapabilityInfo

ShortAddress is a 2 byte field which indicates the network address of an entity that has been added to the network.

Extended Address is a 8-byte field which specifies the IEEE extended address of the same entity.

CapabilityInfo is a byte field which is a bitmap which specifies the operational capabilities of the joining device.

6.7 NLME_LEAVE_CONFIRMATION

6.7.1 Description

This message is sent by the target to indicate to the next higher layer that the device itself or another device is leaving the network.

6.7.2 Usage

The message format is as follows

Cmd=0x0185	Len=0x01	DeviceAddress	Status
Cilia-070103	Len-onor	Devicer laaress	Status

DeviceAddress is an 8 byte field which specifies the IEEE extended address of the device

Status is a byte field that indicates SUCCESS or FAILURE.

6.8 NLME_LEAVE_INDICATION

6.8.1 Description

This message is sent by the target to indicate a remote leave request to the next higher layer of a coordinator.

6.8.2 Usage

The message format is as follows

Cmd=0x0186	Len=0x9	DeviceAddress	Status
Cilia Onoroo	Len on	De vicer laaress	Status

DeviceAddress is an 8 byte field. The 64 bit IEEE address of an entity that has removed itself from the network or NULL in the case that the device issuing the primitive has been removed from the network by its parent.

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).


6.9 NLME SYNC INDICATION

6.9.1 Description

This message is sent by the target to indicate a sync request to the next higher layer of a coordinator.

6.9.2 Usage

The message format is as follows



Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).


6.10 NLME_NETWORKDISCOVERY_CONFIRMATION

6.10.1 Description

This message is sent by the target to indicate that the network discovery is complete.

6.10.2 Usage

The message format is as follows



Number is a 1 byte field that contains the number of networks found

PanID_x is a 2 byte field PAN Id of network found.

LogicalChannel_x is a 1 byte field. Network channel.

BeaconOrder_x is a 1 byte field Beacon Order found for network.

SuperFrameOrder_x is a 1 byte field Super Frame order of found network.

RouterCapacity_x is a 1 byte field – Router capacity for found network (from beacon).

DeviceCapacity_x is a 1 byte field – Device capacity for found network (from beacon).

Version_x is a 1 byte field - network version.

StackProfile_x is a 1 byte field. Found network's profile ID.

SecurityLevel_x is a 1 byte field - Network's security level.

6.11 NLME_STARTROUTER_CONFIRMATION

6.11.1 Description

This message is sent by the target to the next higher layer of the results of its request to start a router.

6.11.2 Usage

The message format is as follows

Cmd=0x018F	Len=0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for NLME status codes).

7. AF Interface

7.1 Introduction

This message interface enables the target AF to issue callbacks to the tester. Each message has a response to a message that is sent by the tester to the target. The response message only indicates successful reception of the callback message. These messages are subscription messages. Refer to SYS_CALLBACK_SUBSCRIBE for a description of the subscription mechanism.

7.2 AF_INIT_REQUEST

7.2.1 Description

This command enables the tester to initialize the target AF.

7.2.2 Usage

The message format is as follows.

CIIIU = 0x0900 Leii = 0x01	Cmd = 0x0900	Len = 0x01
------------------------------	--------------	------------

7.3 AF REGISTER REQUEST

7.3.1 Description

This command enables the tester to register an application's endpoint description.

7.3.2 Usage

The message format is as follows.

Cmd = x0901 Len =	var Endpoint	AppProfileID	AppDeviceID	AppDevice Version	ApFlags
-------------------	--------------	--------------	-------------	----------------------	---------

AppNumInClusters	AppOutClusterList	AppNumOutClusters	AppOutClusterList	Latency

Endpoint is a byte field which specifies the endpoint of the device

AppProfileID is a 2 byte field which specifies the profile id of the application

AppDeviceID is a 2 byte field which specifies the device description id for this endpoint

AppDeviceVersion is a byte field which specifies the version of the device description

AppFlags is a byte field which specifies if a complex identifier is available

AppNumInClusters is a byte field which specifies the number of Input cluster Ids following in the AppInClusterList

AppInClusterList is a variable length field of size 'AppNumInClusters' and is the list of Input Cluster Ids.

AppNumOutClusters is a byte field which specifies the number of Output cluster Ids following in the AppOutClusterList

AppOutClusterList is a variable length field of size 'AppNumOutClusters' and is the list of Output Cluster Ids.

Latency is a byte field and has any of the following values 0x00(noLatencyReqs), 0x01 (fastBeacons) and 0x02(slowBeacons).

7.3.3 AF_REGISTER_RESPONSE

Cmd = 0x1901	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for AF status codes).

7.4 AF_SENDMSG_REQUEST

7.4.1 Description

This command is used by tester to build and send a KVP or MSG message. For KVP messages, the code must be built with the following compiler directive: -DAF_KVP_SUPPORT=TRUE

7.4.2 Usage

The message format is the following:

Cmd = 0x09	902	Len = var	FrameTyp	e	TxOptions	S	Radius			
DestAddr	Des	stEndpoint	SrcEndpoin	t	ClusterId		AddOrSei	nd	TransId	
CmdType	Atı	tribDataType	e AttribId]	ErrorCode	7	ΓransDatal	Len	TransDa	ta

FrameType is a byte field which specifies either FRAMETYPE_KVP or FRAMETYPE_MSG.

TxOptions is a byte field which consists of the AF Tx Options bit fields; zero for none.

Radius is a byte field representing the number of hops allowed to deliver the message; usually use 7.

DestAddr is the 16-bit ZigBee network address for the message.

DestEndpoint is a byte field which specifies the destination endpoint of the message.

SrcEndpoint is a byte field which specifies the origination endpoint of the message.

ClusterId is a 2-byte field which specifies the cluster ID (only the LSB is used in V1.0 networks.)

AddOrSend is a byte field indicating to ADD_MESSAGE or SEND_MESSAGE; MSG set to 0.

TransId is a byte field which specifies the transaction sequence number of the message.

CmdType is a byte field which specifies the KVP command type of the message; MSG set to zero.

AttribDataType is a byte field which specifies the KVP data type of the message; MSG set to zero.

AttributeID is a 2-byte field which specifies the attribute ID; MSG set to zero.

ErrorCode is a byte field which specifies the KVP error code, if any; MSG set to zero.

TransDataLen is a byte field which specifies the length of the TransactionData field.

TransData is a variable length field of size TransDataLength and is the transaction data frame.

7.4.3 AF_SENDMSG_RESPONSE

Cmd = $0x1902$ Lo	en = 0x01	Status
-------------------	-----------	--------

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for AF status codes).

8. AF Callback Interface

8.1 AF INCOMINGDATA INDICATION

8.1.1 Description

This callback message is in response to incoming data to any of the registered endpoints on this device.

8.1.2 Usage

The message format is the following:

Cmd = 0x09	903	Len = var	FrameType	WasBroado	east	LinkQual	ity	Secur	ityUse
SrcAddr	Sro	eEndpoint	DestEndpoint	ClusterId	Т	ransCnt	Tr	ansId	
CmdType	At	tribDataType	e AttribId	ErrorCode	Tra	ansDataLen	,	TransDa	ıta

FrameType is a byte field which specifies either FRAMETYPE_KVP or FRAMETYPE_MSG.

WasBroadcast is a byte field indicating whether the incoming message was broadcast.

LinkQuality is a byte field which indicates the link quality measured during reception.

SecurityUse is a 1 byte field which indicates the type of security used for the transaction.

SrcAddr is the 16-bit ZigBee network address of the source device sending the message.

SrcEndpoint is a byte field which specifies the source endpoint of the message.

DestEndpoint is a byte field which specifies the destination endpoint of the message.

ClusterId is a 2-byte field which specifies the cluster ID (only the LSB is used in V1.0 networks.)

TransCnt is a byte field indicating the number of concatenated KVP messages in the transaction data; MSG set to 0.

TransId is a byte field which specifies the transaction sequence number of the message.

CmdType is a byte field which specifies the KVP command type of the message; MSG set to zero.

AttribDataType is a byte field which specifies the KVP data type of the message; MSG set to zero.

AttributeID is a 2-byte field which specifies the attribute ID; MSG set to zero.

ErrorCode is a byte field which specifies the KVP error code, if any; MSG set to zero.

TransDataLen is a byte field which specifies the length of the TransactionData field.

TransData is a variable length field of size TransDataLength and is the transaction data frame.

9. ZDO Interface

9.1 Introduction

These commands allow the tester to issue commands to the ZDO layer in the target and receive responses. Each of these messages has a corresponding message that is returned by the target. The response message only indicates that the command message was received and executed. The result of the command execution will be conveyed to the tester via a callback message interface (defined in the next section), if applicable.

9.2 ZDO_AUTOAPPENDENDDEVICEBIND_REQUEST

9.2.1 Description

This command will tell the ZDO to request an End Device Bind. The ZDO will send the message to the ZigBee coordinator based on the information found in the AF Endpoint description for the passed in endpoint.

9.2.2 Usage

The message format is as follows.

Cmd = 0x0A00	Len = 0x01	Endpoint
01110		2.1.000011110

Endpoint – byte - Which endpoint to issue the End Device Bind request for.

9.2.3 ZDO_AUTOAPPENDENDDEVICEBIND_RESPONSE

Cmd = 0x1A00	Len = 0x01	Status
--------------	------------	--------

Status is a 1 byte field that indicates SUCCESS(0) or FAILURE.

9.3 ZDO AUTOFINDDESTINATION REQUEST

9.3.1 Description

This function will issue a Match Description Request for the requested endpoint outputs. This message will generate a broadcast message.

9.3.2 Usage

The message format is as follows.

Cmd = 0x0A01	Len = 0x01	Endpoint

Endpoint – byte - Which endpoint to issue the End Device Bind request for.

9.3.3 ZDO AUTOFINDDESTINATION RESPONSE

Cmd = 0x1A01	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS(0) or FAILURE.

9.4 ZDO NETWORKADDRESS REQUEST

9.4.1 Description

This message will request the device to send a "Network Address Request". This message sends a broadcast message looking for a 16 bit address with a known 64 bit IEEE address. You must subscribe to "ZDO Network Address Response" to receive the response to this message. The response message listed below only indicates whether or not the message was received properly.

9.4.2 Usage

The message format is as follows.

Cmd = 0x0A02	Len = 0x09	IEEEAddr	ReqType	StartIndex	SecuritySuite

IEEEAddr - 8 bytes - 64 bit address bait.

ReqType – byte – following options:

Value	Description
0	Single device response
1	Extended – include associated devices

StartIndex - 1 byte – Starting index into the list of children. This is used to get more of the list if the list is too large for one message.

SecuritySuite - 1 byte -. Security options. i

9.4.3 ZDO_NETWORKADDRESS_RESPONSE

Cmd = 0x1A02	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for APSME status codes).

9.5 ZDO_IEEEADDRESS_REQUEST

9.5.1 Description

This command will request a device's IEEE 64-bit address. You must subscribe to "ZDO IEEE Address Response" to receive the data response to this message. The response message listed below only indicates whether or not the message was received properly.

9.5.2 Usage

The message format is as follows.

Cmd = 0x0A03 Len =	: 0x04 ShortAddr	ReqType S	StartIndex	SecuritySuite
---------------------	--------------------	-----------	------------	---------------

ShortAddr – 16 bits – short address of the destination device.

ReqType – byte – following options:

Value	Description
0	Single device response
1	Extended – include associated devices

StartIndex – 1 byte – Starting index into the list of children. This is used to get more of the list if the list is too large for one message.

SecuritySuite - 1 byte -. Security options.

9.5.3 ZDO IEEEADDRESS RESPONSE

Cmd = 0x1A03	Len = $0x01$	Status
0.111		S ceres

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.6 ZDO_NODEDESCRIPTOR_REQUEST

9.6.1 Description

This command is generated to inquire about the Node Descriptor information of the destination device.

9.6.2 Usage

The message format is as follows

Cmd = 0x0A04	Len = 5	DstAddr	NWKAddrOfInterest	SecuritySuite
1				

DstAddr – 16 bit –NWK address of the device generating the inquiry.

NWKAddrOfInterest - 16 bit - NWK address of the destination device being queried .

SecuritySuite - 1 byte -. Security options.

9.6.3 ZDO_NODEDESCRIPTOR_RESPONSE

Cmd = 0x1A04	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.7 ZDO_POWERDESCRIPTOR_REQUEST

9.7.1 Description

This command is generated to inquire about the Power Descriptor information of the destination device.

9.7.2 Usage

The message format is as follows

Cmd = 0x0A05	Len = 5	DstAddr	NWKAddrOfInterest	SecuritySuite
--------------	---------	---------	-------------------	---------------

DstAddr – 16 bit –NWK address of the device generating the inquiry.

NWKAddrOfInterest – 16 bit - NWK address of the destination device being queried.

SecuritySuite - 1 byte -. Security options.

9.7.3 ZDO_POWERDESCRIPTOR_RESPONSE

Cmd = 0x1A05	Len = 0x01	Status
Ciliu – UXIAUS	LCII — 0A01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.8 ZDO_SIMPLEDESCRIPTOR_REQUEST

9.8.1 Description

This command is generated to inquire as to the Simple Descriptor of the destination device's Endpoint.

9.8.2 Usage

The message format is as follows

Cmd = 0x0A06 Len = 6 DstAddr NWKAddrOfInterest Endpoint SecuritySuite

DstAddr – 16 bits – NWK address of the device generating the inquiry.

NWKAddrOfInterest – 16 bit - NWK address of the destination device being queried.

Endpoint – byte – represents the application endpoint the data is from.

SecuritySuite - 1 byte -. Security options.

9.8.3 ZDO_SIMPLEDESCRIPTOR_RESPONSE

Cmd = 0x1A06	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.9 ZDO_ACTIVEENDPOINT_REQUEST

9.9.1 Description

This command is generated to request a list of active endpoint from the destination device.

9.9.2 Usage

The message format is as follows

Cmd = 0x0A07	Len = 5	DstAddr	NWKAddrOfInterest	SecuritySuite

DstAddr – 16 bit – NWK address of the device generating the request..

NWKAddrOfInterest – 16 bit - NWK address of the destination device being queried.

SecuritySuite - 1 byte -. Security options.

9.9.3 ZDO ACTIVEENDPOINT RESPONSE

|--|

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.10 ZDO_MATCHDESCRIPTOR_REQUEST

9.10.1 Description

This command is generated to request a list of active endpoint from the destination device.

9.10.2 Usage

The message format is as follows

Cmd = 0x0A08	Len = var	DstAddr	Addr NWKAddrOfInterest		Pro	ofileID	
NumInClusters	InClusterLis	st NumC	OutClusters	OutClusterI	List	Securi	tySuite

DstAddr – 16 bit – NWK address of the device generating the request..

NWKAddrOfInterest – 16 bit - NWK address of the destination device being queried.

ProfileID – 16 bit – Profile ID to match.

NumInClusters - byte - Number of ClusterIds in the InClusterList.

InClusterList – byte array – Array of input cluster IDs – (NumInClusters * 2) long.

NumOutClusters - byte - Number of ClusterIds in the OutClusterList.

OutClusterList – byte array – Array of output cluster IDs – (NumOutClusters * 2) long.

SecuritySuite - 1 byte -. Security options.

9.10.3 ZDO_MATCHDESCRIPTOR_RESPONSE

Cmd = 0x1A08 L	Len = 0x01	Status
----------------	------------	--------

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.11 ZDO_COMPLEXDESCRIPTOR_REQUEST

9.11.1 Description

This command is generated to request for the destination device's complex descriptor.

9.11.2 Usage

The message format is as follows

DstAddr - 16 bits - NWK address of the device generating the request .

NWKAddrOfInterest – 16 bit - NWK address of the destination device being queried.

SecuritySuite - 1 byte -. Security options.

9.11.3 ZDO_COMPLEXDESCRIPTOR_RESPONSE

Cmd = 0x1A09	Len = $0x01$	Status
CIIIG = 0X17107	Len - oxor	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.12 ZDO_USERDESCRIPTOR_REQUEST

9.12.1 Description

This command is generated to request for the destination device's user descriptor.

9.12.2 Usage

The message format is as follows

	ySuite
--	--------

DstAddr - 16 bits - NWK address of the device generating the request.

NWKAddrOfInterest – 16 bit - NWK address of the destination device being queried.

SecuritySuite - 1 byte -. Security options.

9.12.3 ZDO_USERDESCRIPTOR_RESPONSE

Cmd = 0x1A0A	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.13 ZDO_ENDDEVICEBIND_REQUEST

9.13.1 Description

This command is generated to request an End Device Bind with the destination device.

9.13.2 Usage

The message format is as follows

Cmd = 0x0A0B	Len = var	Dst	tAddr LocalCoordinator		Endpoint		ProfileID		
NumInClusters	InClusterLis	st	NumOu	tClusters	OutClu	sterList	Secui	ritySuite	

DstAddr – 16 bits – NWK address of the device generating the request.

LocalCoordinator – 16 bit – Local coordinator's short address. In the case of source binding, it's the short address of the source address.

Endpoint – byte – Device's Endpoint.

ProfileID – 16 bit – Profile ID to match.

NumInClusters - byte - Number of ClusterIds in the InClusterList.

InClusterList – byte array – Array of input cluster IDs – (NumInClusters * 2) long.

NumOutClusters - byte - Number of ClusterIds in the OutClusterList.

OutClusterList – byte array – Array of output cluster IDs – (NumOutClusters * 2) long.

SecuritySuite - 1 byte -. Security options.

9.13.3 ZDO_ENDDEVICEBIND_RESPONSE

Cmd = 0x1A0B I	en = 0x01	Status
----------------	-----------	--------

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.14 ZDO BIND REQUEST

9.14.1 Description

This command is generated to request a Bind.

9.14.2 Usage

The message format is as follows

Cmd = 0x0A0	$Cmd = 0x0A0C \qquad Len = 24$		DstAddr	SrcAddress	SrcEndpoint	
ClusterID	DstAddrMode		DstAddress	DstEndpoint	SecuritySuite	

DstAddr – 16 bits –destination address of the device generating the bind request

SrcAddress – 8 bytes – 64 bit Binding source IEEE address

SrcEndpoint – 8 bits – Binding source endpoint.

ClusterID – 2 byte – Cluster ID to match in messages.

DstAddrMode – 1 byte – Destination address mode: 01 for Group address; 03 for Extended address.

DstAddress – 8 bytes / 2bytes – Binding destination IEEE address. Not to be confused with DstAddr.

DstEndpoint- 8 bits / 0 byte - Binding destination endpoint. It is used only when DstAddrMode is 64 bits extended address

SecuritySuite - 1 byte -. Security options.

9.14.3 ZDO BIND RESPONSE

Cmd = 0x1A0C	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.15 ZDO UNBIND REQUEST

9.15.1 Description

This command is generated to request an UnBind.

9.15.2 Usage

The message format is as follows

Cmd = 0x0A0	0D	Len = 24	DstAddr	SrcAddress		SrcEndpoint
ClusterID	Ds	AddrMode	DstAddre	ss	DstEndpoint	SecuritySuite

DstAddr – 16 bits –destination address of the device generating the bind request.

SrcAddress – 8 bytes – 64 bit Binding source IEEE address

SrcEndpoint – 8 bits – Binding source endpoint.

ClusterID – 2 byte – Cluster ID to match in messages.

DstAddrMode – 1 byte – Destination address mode: 01 for Group address; 03 for Extended address.

DstAddress – 8 bytes – 64 bit Binding destination IEEE address. Not to be confused with DstAddr.

DstEndpoint – 8 bits – Binding destination endpoint.

SecuritySuite - 1 byte -. Security options.

9.15.3 ZDO UNBIND RESPONSE

G 1 0 110	¥ 0.01	a
Cmd = 0x1A0D	Len = $0x01$	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.16 ZDO MGMT NWKDISC REQUEST

9.16.1 Description

This command is generated to request the destination device to perform a network discovery.

9.16.2 Usage

The message format is as follows

|--|

DstAddr – 16 bits –network address of the device performing the discovery.

ScanChannels- 32 bits - Bit Mask for channels to scan

ScanDuration is a byte field represents the scanning time.

StartIndex -8 bits - Where to start in the response array list. The result may contain more entries than can be reported, so this field allows the user to retrieve the responses anywhere in the array list.

9.16.3 ZDO MGMT NWKDISC RESPONSE

Cmd = 0x1A0E	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.17 ZDO_MGMT_LQI_REQUEST

9.17.1 Description

This command is generated to request the destination device to perform a LQI query of other devices in the network.

9.17.2 Usage

The message format is as follows

Cmd = 0x0A0F	Len = $0x3$	DstAddr	StartIndex

DstAddr – 16 bits –network address the device generating the query.

StartIndex -8 bits - Where to start in the response array list. The result may contain more entries than can be reported, so this field allows the user to retrieve the responses anywhere in the array list.

9.17.3 ZDO_MGMT_LQI_RESPONSE

Cmd = 0x1A0F	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.18 ZDO_MGMT_RTG_REQUEST

9.18.1 Description

This command is generated to request the Routing Table of the destination device

9.18.2 Usage

The message format is as follows

Cmd = 0x0A10	Len = $0x3$	DstAddr	StartIndex

DstAddr – 16 bits –network address of the device being queried.

StartIndex -8 bits - Where to start in the response array list. The result may contain more entries than can be reported, so this field allows the user to retrieve the responses anywhere in the array list.

9.18.3 ZDO_MGMT_RTG_RESPONSE

Cmd = 0x1A10	Len = $0x01$	Status
Cilia Onli II	Den onor	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.19 ZDO_MGMT_BIND_REQUEST

9.19.1 Description

This command is generated to request the Binding Table of the destination device.

9.19.2 Usage

The message format is as follows

Cmd = 0x0A11	Len = $0x3$	DstAddr	StartIndex
--------------	-------------	---------	------------

DstAddr – 16 bits –network address of the device being queried.

StartIndex -8 bits - Where to start in the response array list. The result may contain more entries than can be reported, so this field allows the user to retrieve the responses anywhere in the array list.

9.19.3 ZDO_MGMT_BIND_RESPONSE

Cmd = 0x1A11	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.20 ZDO_MGMT_DIRECT_JOIN_REQUEST

9.20.1 Description

This command is generated to request the Management Direct Join Request of a designated device.

9.20.2 Usage

The message format is as follows

Cmd = 0x0A12	Len = 0xB	DstAddr	DeviceAddress	CapInfo

DstAddr – 16 bits –network address of the device to which the device specified in DeviceAddress is to join.

DeviceAddress – 8 bytes – The 64 bit IEEE Address of the device you want to be joined to the device at DstAddr.

CapInfo -8 bits - The operating capabilities of the device being directly joined. Bit weighted values follow: Can you please verify if the table below is accurate? I understand that for a router, the value should be 0x8E, and for an ED, it's 0x80, and I'm not sure if these jive with this table?

Bit	Description
0	Alternate PAN Coordinator
1	Device type: 1 – ZigBee Router 0 – End Device
2	Power Source: 1 – Mains powered
3	Receiver on when idle
4-5	Reserved
6	Security capability
7	Reserved

9.20.3 ZDO_MGMT_DIRECT_JOIN_RESPONSE

Cmd = 0x1A12	Len = 0x01	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.21 ZDO_USERDESCRIPTOR_SET_REQUEST

9.21.1 Description

This command is generated to write a User Descriptor value to the targeted device.

9.21.2 Usage

The message format is as follows

Cmd = 0x0A13	I an -	Det Addr	NWKAddrOfInterest	Dasal an	Descriptor	SaguritySuita
Cilia = 0x0A13	Len =	DStAddi	N W KAddi Offilielest	DescLeii	Descriptor	SecuritySuite
	var					

DstAddr – 16 bits –network address of the device generating the set request.

NWKAddrOfInterest – 16 bit - NWK address of the device targeted for the set request.

DescLen – 8 bits – Length, in bytes, of the user descriptor.

Descriptor – byte array – User descriptor array (can be up to 16 bytes).

SecuritySuite - 1 byte - Security options.

9.21.3 ZDO USERDESCRIPTOR SET RESPONSE

Cmd = 0x1A13	I en - 0x01	Status
Cilia – Oximio	Len - oxor	Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.22 ZDO_END_DEVICE_ANNCE

9.22.1 Description

This command is generated to request an End Device Announce.

9.22.2 Usage

The message format is as follows

	(Cmd = 0x0A14	Len = $0xC$	DevAddr	DeviceAddress	SecuritySuite	Capabilities
--	---	--------------	-------------	---------	---------------	---------------	--------------

DevAddr – 16 bits – network address of the device generating the request.

DeviceAddress – 8 bytes – The 64 bit IEEE Address of the device being announced.

SecuritySuite - 1 byte - Security options.

Capabilities – 1 byte – MAC capabilities – see capabilities field of ZDO_MGMT_DIRECT_JOIN_REQUEST for bit definitions.

9.23 ZDO_MGMT_LEAVE_REQUEST

9.23.1 Description

This command is generated to request a Management Leave Request for the target device.

9.23.2 Usage

The message format is as follows

Cmd = 0x0A15	Len = $0xA$	DstAddr	DeviceAddress

DstAddr – 16 bits –network address of the device generating the request.

DeviceAddress - 8 bytes - The 64 bit IEEE Address of the target device you want to leave.

9.23.3 ZDO_MGMT_LEAVE_RESPONSE

	Cmd = 0x1A15	Len = 0x01	Status
--	--------------	------------	--------

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.24 ZDO_MGMT_PERMIT_JOIN_REQUEST

9.24.1 Description

This command is generated to set the Permit Join for the destination device.

9.24.2 Usage

The message format is as follows

Cmd = 0x0A16	Len = $0x4$	DstAddr	Duration	TC Significance

DstAddr – 16 bits –network address of the destination device whose Permit Join information is to be modified.

Duration – 1 byte – The duration to permit joining. 0 = join disabled. $0 \times \text{monotonic} = \text{monotonic} =$

TC Significance – 1 byte - Trust Center Significance.

9.24.3 ZDO_MGMT_PERMIT_JOIN_RESPONSE

Cmd = 0x1A16	Len = 0x01	Status
01110		

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.25 ZDO SYSTEM SERVER DISC REQUEST

9.25.1 Description

The command is used for local device to discover the location of a particular system server or servers as indicated by the ServerMask parameter. The destination addressing on this request is 'broadcast to all RxOnWhenIdle devices'.

9.25.2 Usage

The message format is as follows

Cmd = 0x0A17	Len = 0x03	Server Mask	Securiy Suite
Ciliu – UXUAT/	$LCH - 0\lambda03$	SCI VCI IVIASK	occurry outcome

Server Mask is a two byte field with bit settings signifying the system server capabilities of the device.

Security Suite: one byte security option.

9.25.3 ZDO_SYSTEM_SERVICE_DISC_RESPONSE

Cmd = 0x1A17 Len = $0x01$ Status

Status is a 1 byte field that indicates SUCCESS or FAILURE.

9.26 ZDO_NETWORK_START_REQUEST

9.26.1 Description

In the case where compiler flag HOLD_AUTO_START is defined by default, device will start from HOLD state. Issuing this command will trigger the device to leave HOLD state to form or join a network.

9.26.2 Usage

The command message format is as follows

Cmd=0x0A18	Len=0x00
------------	----------

There is no parameter for this command.

9.26.3 SYS_NETWORK_START_RESPONSE

Cmd=0x1A18	Len=0x01	Status
CIIIU-UXIAIO	LCII-UXU1	Status

Status is a 1 byte field that will be SUCCESS(0) or FAILURE(1).

10. ZDO Callback Interface

10.1 Introduction

These commands allow the tester to issue commands to the ZDO layer in the target and receive responses. Each of these messages has a corresponding message that is returned by the target. The response message only indicates that the command message was received and executed. The result of the command execution will be conveyed to the tester via a callback message interface (defined in the next section), if applicable. These messages are subscription messages. Refer to SYS_CALLBACK_SUBSCRIBE for a description of the subscription mechanism.

10.2 ZDO NETWORKADDRESS RESPONSECB

10.2.1 Description

This callback message is in response to the ZDO Network Address Request.

10.2.2 Usage

The message format is as follows

Cmd = 0x0A8	0	Len = var	SrcAddrMode	SrcAddr	Status	IEEEAddr
nwkAddr	Nu	mAssocDev	StartIndex	AssocDevl	List	

SrcAddrMode – byte – indicates that the SrcAddr is either 16 bits (2) or 64 bits (3)

SrcAddr – 8 bytes or 16 bits – Source address, size is dependent on SrcAddrMode

Status – byte – this field indicates either SUCCESS or FAILURE.

IEEEAddr – 8 bytes – 64 bit IEEE address of source device

nwkAddr - 16 bit - short network address of responding device

NumAssocDev – byte – the number of associated devices

StartIndex – byte - Starting index into the list of associated devices for this report.

AssocDevList – array of 16 bit short addresses – list of network address for associated devices. This list can be a partial list if the entire list doesn't fit into a packet. If it is a partial list, the starting index is StartIndex.

10.3 ZDO_IEEEADDRESS_RESPONSECB

10.3.1 Description

This callback message is in response to the ZDO IEEE Address Request.

10.3.2 Usage

The message format is as follows

Cmd = 0x0A81	Len = var	SrcAddrMode	SrcAddı	r Status	IEEEAddr
NumAssocDev	StartIndex	AssocDevLis	t		

SrcAddrMode – byte – indicates that the SrcAddr is either 16 bits (2) or 64 bits (3)

SrcAddr – 8 bytes or 64 bits – Source address, size is dependent on SrcAddrMode

Status – byte – this field indicates either SUCCESS or FAILURE.

IEEEAddr – 8 bytes – 64 bit IEEE address of source device

NumAssocDev – byte – the number of associated devices

StartIndex – byte - Starting index into the list of associated devices for this report.

AssocDevList – array of 16 bit short addresses – list of network address for associated devices. This list can be a partial list if the entire list doesn't fit into a packet. If it is a partial list, the starting index is StartIndex.

10.4 ZDO_NODEDESCRIPTOR_RESPONSECB

10.4.1 Description

This callback message is in response to the ZDO Node Descriptor Request.

10.4.2 Usage

The message format is as follows

Cmd = 0x0A82	Len = 18	Status	SrcAddr NV		NWK	NWKAddrOfInterest		ype	ComplexDescriptor Available		
UserDescriptor Available	APSFlags	Frequence Band	су	Capab	ilities	Manufacturer Code	Buffer Size	Tra Size	nsfer e	Server Mask	

Status – byte – this field indicates either SUCCESS or FAILURE.

SrcAddr – 16 bit – the message's source network address.

NWKAddrOfInterest – 16 bits – Device's short address of this Node descriptor

NodeType – 8 bits – defined as follows:

Bits	Name	Description
7-5	NodeLogicalType	Identifies Node as ZigBee Coordinator or other ZigBee device type
4-0	N/A	Reserved

NodeLogi	calType
Type	Value
ZigBee Coordinator	0
ZigBee Router	1
ZigBee End Device	2
Reserved	3-7

ComplexDescriptorAvailable – byte – Indicates if complex descriptor is available for the node

UserDescriptorAvailable – byte – Indicates if user descriptor is available for the node

APSFlags – byte – Node Flags assigned for APS. For V1.0 all bits are reserved.

NodeFrequencyBand - byte - Identifies node frequency band capabilities

Capabilities – byte – Capability flags stored for the MAC

ManufacturerCode -2 bytes - specifies a manufacturer code that is allocated by the ZigBee Alliance, relating to the manufacturer to the device.

BufferSize - byte - Indicates size of maximum NPDU. This field is used as a high level indication for management.

TransferSize -2 bytes - Indicates maximum size of Transfer up to 0x7fff (This field is reserved in version 1.0 and shall be set to zero).

ServerMask – 2 bytes – Specifies the system server capability. It is defined as follows:

Bit Number	Assignment
0	Primary Trust Center
1	Backup Trust Center
2	Primary Binding Table Cache
3	Backup Binding Table Cache
4	Primary Discovery Cache
5	Backup Discovery Cache
6–15	Reserved

10.5 ZDO_POWERDESCRIPTOR_RESPONSECB

10.5.1 Description

This callback message is in response to the ZDO Power Descriptor Request.

10.5.2 Usage

The message format is as follows

88

Cmd = 0x0A83	Len = 9	Status	SrcAddr	NWK	AddrOfInterest	NodeCurrentPowe	erMode
NodeAvailablePo	werSources	NodeCi	urrentPowerS	Source	NodeCurrentPov	verSourceLevel	

Status – byte – this field indicates either SUCCESS or FAILURE.

SrcAddr – 16 bit – the message's source network address.

NWKAddrOfInterest – 16 bits – Device's short address that this response describes.

NodeCurrentPowerMode – 8 bits – Indicates Power Mode

NodeCurrentPowe	rMode
Description	Value
Receiver permanently on or periodically on	0
Receiver periodically comes on	1
Receiver comes on when stimulated	2
Reserved	0x3 - 0xf

NodeAvailablePowerSources – 8 bits – Bit field showing available power sources

NodeAvailablePowe	rSources
Description	Value
Constant (Mains) power	0
Recharable battery	1
Disposable battery	2
Reserved	0x3 - 0xf

NodeCurrentPowerSource – byte – Indicates current power source. Same values as NodeAvailablePowerSources NodeCurrentPowerSourceLevel – byte – Indicates charge status of power supply

10.6 ZDO_SIMPLEDESCRIPTOR_RESPONSECB

10.6.1 Description

This callback message is in response to the ZDO Simple Descriptor Request.

10.6.2 Usage

The message format is as follows

Cmd = 0x0A84	4	Len = v	ar S	Status	SrcAddr		NWKAddrOfInterest	į	Endpoint	AppP	ProfID
AppDevID	Aj	ppDevVe	r	AppFlags Appl		pInClusterCount	A	ppInClusterLis	t		
AppOutCluster	rCo	unt	AppOutClusterList				•			•	

Status – byte – this field indicates either SUCCESS or FAILURE.

SrcAddr – 16 bit – the message's source network address.

NWKAddrOfInterest – 16 bits – Device's short address that this response describes.

Endpoint – 8 bits

AppProfID – 16 bits – The profile ID for this endpoint.

AppDevID – 16 bits – The Device Description ID for this endpoint.

AppDevVer - 8 bits - Defined as the following format

AppDevVer	:
Description	Value
Version 1.00	0
Reserved	0x1 - 0xf

AppFlags – 8 bits – Defined as the following format

AppFlags	
Description	bit
ComplexDescriptorAvailableFlag	0
Reserved	1
Reserved	2
Reserved	3

AppInClusterCount – byte – The number of input clusters in the AppInClusterList:

AppInClusterList – byte array – List of input cluster IDs supported

AppOutClusterCount – byte – The number of output clusters in the AppOutClusterList:

AppOutClusterList – byte array – List of output cluster IDs supported

10.7 ZDO ACTIVEENDPOINT RESPONSECB

10.7.1 Description

This callback message is in response to the ZDO Active Endpoint Request.

10.7.2 Usage

The message format is as follows

Cmd = 0x0A85 Len = var Status SrcAddr NWKAddrOfInterest ActiveEndpointCount Active
--

Status – byte – this field indicates either SUCCESS or FAILURE.

SrcAddr – 16 bit – the message's source network address.

NWKAddrOfInterest – 16 bits – Device's short address that this response describes.

ActiveEndpointCount – 8 bits – Number of active endpoint in the list

ActiveEndpointList – byte array – Array of active endpoints on this device.

10.8 ZDO_MATCHDESCRIPTOR_RESPONSECB

10.8.1 Description

This callback message is in response to the ZDO Match Description Request.

10.8.2 Usage

The message format is as follows

(Cmd = 0x0A86	Len = var	Status	SrcAddr	NWKAddrOfInterest	MatchCount	MatchEPList
---	--------------	-----------	--------	---------	-------------------	------------	-------------

Status – byte – this field indicates either SUCCESS or FAILURE.

SrcAddr – 16 bit – the message's source network address.

NWKAddrOfInterest – 16 bits – Device's short address that this response describes.

MatchCount - 8 bits - Number of active endpoints in the list

MatchEndpointList – byte array – Array of active endpoints on this device.

10.9 ZDO_USERDESCRIPTOR_RESPONSECB

10.9.1 Description

This callback message is in response to the ZDO User Description Request.

10.9.2 Usage

The message format is as follows

Cmd = 0x0A8F	Len = var	Status	SrcAddr	NWKAddrOfInterest	DescLen	Descriptor

Status – byte – this field indicates either SUCCESS or FAILURE.

SrcAddr – 16 bit – the message's source network address.

NWKAddrOfInterest – 16 bits – Device's short address that this response describes.

DescLen – 8 bits – Length, in bytes, of the user descriptor

Descriptor – byte array – User descriptor array (can be up to 16 bytes).

10.10 ZDO_ENDDEVICEBIND_RESPONSECB

10.10.1 Description

This callback message is in response to the ZDO End Device Bind Request.

10.10.2 Usage

The message format is as follows

|--|

Status – byte – this field indicates status of the bind request with the following values:

Status	
Description	Value
SUCCESS	0
NOT SUPPORTED	1
TIMEOUT	2
NO MATCH	3
Reserved	0x04 – 0xFF

SrcAddr – 16 bit – the message's source network address.

10.11 ZDO_BIND_RESPONSECB

10.11.1 Description

This callback message is in response to the ZDO Bind Request.

10.11.2 Usage

The message format is as follows:

Cmd = 0x0A88	Len = 1	Status	SrcAddr

Status – byte – this field indicates status of the bind request with the following values:

Status	
Description	Value
SUCCESS	0
NOT SUPPORTED	1
TABLE FULL	2
Reserved	0x03 – 0xFF

SrcAddr – 16 bit – the message's source network address.

10.12 ZDO_UNBIND_RESPONSECB

10.12.1 Description

This callback message is in response to the ZDO UnBind Request.

10.12.2 Usage

The message format is as follows

	Cmd = 0x0A89	Len = 1	Status	SrcAddr
--	--------------	---------	--------	---------

Status – byte – this field indicates status of the bind request with the following values:

Status	
Description	Value
SUCCESS	0
NOT SUPPORTED	1

NO ENTRY	2
Reserved	0x03 – 0xFF

SrcAddr – 16 bit – the message's source network address.

10.13 ZDO_MGMT_NWKDISC_RESPONSECB

10.13.1 Description

This callback message is in response to the ZDO Management Network Discovery Request.

10.13.2 Usage

The message format is as follows

Cr	nd =	Len =	SrcAddr	Status	NetworkCount	StartIndex	NetworkListCount	NetworkList
0x	A8A0	var						

SrcAddr – 16 bit – Source address of the message

Status – byte – this field indicates either SUCCESS or FAILURE.

NetworkCount – 1 byte – Total number of entries available in the device.

StartIndex – 1 byte – Where in the total number of entries this response starts.

NetworkListCount – 1 byte – Number of entries in this response.

NetworkList – list – an array of NetworkList items. NetworkListCount contains the number of items in this table.

		NetworkList Ite	n
Name	Size(1.0)	Size(1.1)	Description
PAN ID/Extended PAN ID	2 bytes	8 bytes	PAN ID of the neighbor device
Logical Channel	1 byte	1 byte	The current logical channel occupied by the network.
Stack Profile	1 byte	1 byte	A ZigBee stack profile identifier indicating the stack profile in use in the discovered network.
ZigBee Version	1 byte	1 byte	The version of the ZigBee protocol in use in the discovered network.
Beacon Order	1 byte	1 byte	The network's beacon order.
Super frame Order	1 byte	1 byte	MAC sub-layer superframe order
Permit Joining	1 byte	1 byte	Permit joining flag

10.14 ZDO_MGMT_LQI_RESPONSECB

10.14.1 Description

This callback message is in response to the ZDO Management LQI Request.

10.14.2 Usage

The message format is as follows

Cmd =	Len =	SrcAddr	Status	NeighborLQIEntries	StartIndex	NeighborLQICount	NeighborLqiList	
0x0A8B	var							

SrcAddr – 16 bit – Source address of the message

Status – byte – this field indicates either SUCCESS or FAILURE.

NeighborLQIEntries – 1 byte – Total number of entries available in the device.

StartIndex – 1 byte – Where in the total number of entries this response starts.

NeighborLQICount – 1 byte – Number of entries in this response.

NeighborLqiList – list – an array of NeighborLqiList items. NeighborLQICount contains the number of items in this table.

NeighborLqiList Item				
Name	Size (1.0)	Size(1.1)	Description	
PAN ID	2 bytes	8 bytes	PAN ID of the neighbor device	
Network Address	2 bytes	2 bytes	Network short address	
Rx LQI	1 byte	1 byte	Receiver Link Quality	
Tx Quality	1 byte	1 byte	Transmitter Quality factor	

10.15 ZDO_MGMT_RTG_RESPONSECB

10.15.1 Description

This callback message is in response to the ZDO Management Routing Table Request.

10.15.2 Usage

The message format is as follows

Cmd =	Len =	SrcAddr	Status	RtgCount	StartIndex	RtgListCount	RtgList
0x0A8C	var						

SrcAddr – 16 bit – Source address of the message

Status – byte – this field indicates either SUCCESS or FAILURE.

RtgCount – 1 byte – Total number of entries available in the device.

StartIndex – 1 byte – Where in the total number of entries this response starts.

RtgListCount – 1 byte – Number of entries in this response.

RtgList – list – an array of RtgList items. RtgListCount contains the number of items in this table.

RtgList Item				
Name	Size	Description		
Destination Address	2 bytes	Network destination address		
Next Hop	2 bytes	Next hop network address		
Status	1 byte	Route status: 0x00 Active 0x01 Discovery Underway 0x02 Discovery Failed 0x03 Inactive 0x04 – 0x07 Reserved		

10.16 ZDO_MGMT_BIND_RESPONSECB

10.16.1 Description

This callback message is in response to the ZDO Management Binding Table Request.

10.16.2 Usage

The message format is as follows

Cmd =	Len =	SrcAddr	Status	BindCount	StartIndex	BindListCount	BindList
0x0A8D	var						

SrcAddr – 16 bit – Source address of the message

Status – byte – this field indicates either SUCCESS or FAILURE.

BindCount – 1 byte – Total number of entries available in the device.

StartIndex – 1 byte – Where in the total number of entries this response starts.

BindListCount – 1 byte – Number of entries in this response.

BindList – list – an array of BindList items. BindListCount contains the number of items in this table.

BindList Item					
Name	Size		Description		
	V1.0	V1.1			
Source Address	8 bytes	8 bytes	Binding Entry's source IEEE address		
Source Endpoint	1 byte	1 byte	Binding Entry's source endpoint		
Cluster ID	1 byte	2 byte	Message ID in binding table		
Destination Address Mode	0 byte	1 byte	Address mode for binding entry's destination address		
Destination Address	8 bytes	8 bytes/ 2 bytes	Binding Entry's destination IEEE address		
Destination Endpoint	1 byte	1 byte/0 byte	Binding Entry's destination endpoint. For V1.1, this field is only present when the DestAddrMode is 64-bits extended address.		

10.17 ZDO_MGMT_DIRECT_JOIN_RESPONSECB

10.17.1 Description

This callback message is in response to the ZDO Management Direct Join Request.

10.17.2 Usage

The message format is as follows

Cmd =	Len =	SrcAddr	Status
0x0A8E	0x03		

SrcAddr – 16 bit – Source address of the message

Status – byte – this field indicates either SUCCESS (0) or FAILURE (1).

10.18 ZDO_USERDESCRIPTOR_SET_RESPONSECB

10.18.1 Description

This callback message is in response to the ZDO User Descriptor Set Request.

10.18.2 Usage

The message format is as follows

Cmd =	Len =	Status	SrcAddr	
0x0A90	0x03			

Status – byte – this field indicates status of the request with the following values:

SrcAddr – 16 bit – Source address of the message

Status			
Description	Value		
SUCCESS	0		
NOT SUPPORTED	1		
Reserved	0x04 - 0xFF		

10.19 ZDO_MGMT_LEAVE_RESPONSECB

10.19.1 Description

This callback message is in response to the ZDO Management Leave Request.

10.19.2 Usage

The message format is as follows

	-	G	G 4 1 1
Cmd =	Len =	Status	SrcAddr
0x0A91	0x03		

Status – byte – this field indicates either SUCCESS (0) or FAILURE (1).

SrcAddr - 16 bit - Source address of the message

10.20 ZDO MGMT PERMIT JOIN RESPONSECB

10.20.1 Description

This callback message is in response to the ZDO Management Permit Join Request.

10.20.2 Usage

The message format is as follows

Cmd =	Len =	Status	SrcAddr
0x0A92	0x03		

Status – byte – this field indicates either SUCCESS (0) or FAILURE (1).

SrcAddr – 16 bit – Source address of the message

10.21 ZDO_SYSTEM_SERVER_DISC_RESPONSECB

10.21.1 Description

This callback message is in response to the ZDO System Service Discovery Request. Upon receiving the request, remote devices shall compare the ServerMask parameter to the Server Mask field in their own Node descriptor. If no bits are found to match, no action is taken.

10.21.2 Usage

The message format is as follows

I	Cmd - 0v0 4 02	L an - 0x02	Ctotus	Cuo A d du	Comron Moole
ı	Cmd = 0x0A93	Len = $0x03$	Status	SrcAddr	Server Mask

Status – 1 byte – this field indicates either SUCCESS (0) or FAILURE (1).

SrcAddr – 16bit – Source address of the address.

Server Mask -16 bits - each bit signifies one system server capability of the node. The bit setting is defined in the following table:

Bit Number	Assignment			
0	Primary Trust Center			
1	Backup Trust Center			
2	Primary Binding Table Cache			
3	Backup Binding Table Cache			
4	Primary Discovery Cache			
5	Backup Discovery Cache			
6–15	Reserved			

11. Application Interface

11.1 Introduction

This interface allows the tester to issue application-specific commands to the target and receive responses. The actual commands and responses will depend on the application and will be decided later.

11.2 USERTEST_REQUEST

11.2.1 Description

This message is sent to the target in order to test the functions defined for individual applications (which internally use attributes and cluster IDs from various device descriptions).

11.2.2 Usage

The message format is as follows

Cmd=0x0B51 Le	en=0x08 Endpoint	Command	Param1	Param2
---------------	------------------	---------	--------	--------

Endpoint is a byte field that indicates the endpoint of the application

Command is a two byte field that is used to identify the application command to invoke

Param1 is a two byte field that is used as the first parameter of the

Param2 is a two byte field which is used as the second parameter of the command (usually an attribute value). This value is not necessary for some commands.

11.2.3 USERTEST RESPONSE

Status is a 1 byte field that indicates SUCCESS or FAILURE (see appendix for failure codes).

Appendix A Status Codes and Query types

MAC Callback ID codes

Callback Name	Callback ID
SPI_CB_NWK_SYNC_LOSS_IND	0x2080
SPI_CB_NWK_ASSOCIATE_IND	0x2081
SPI_CB_NWK_ASSOCIATE_CNF	0x2082
SPI_CB_NWK_BEACON_NOTIFY_IND	0x2083
SPI_CB_NWK_DATA_CNF	0x2084
SPI_CB_NWK_DATA_IND	0x2085
SPI_CB_NWK_DISASSOCIATE_IND	0x2086
SPI_CB_NWK_DISASSOCIATE_CNF	0x2087
SPI_CB_NWK_GTS_CNF	0x2088
SPI_CB_NWK_GTS_IND	0x2089
SPI_CB_NWK_ORPHAN_IND	0x208a
SPI_CB_NWK_POLL_CNF	0x208b
SPI_CB_NWK_SCAN_CNF	0x208c
SPI_CB_NWK_SECURITY_ERR_IND	0x208d
SPI_CB_NWK_START_CNF	0x208e

NWK Callback ID codes

Callback Name	Callback ID
SPI_CB_NLDE_DATA_CNF	0x0180
SPI_CB_NLDE_DATA_IND	0x0181
SPI_CB_NLME_INITCOORD_CNF	0x0182
SPI_CB_NLME_JOIN_CNF	0x0183
SPI_CB_NLME_JOIN_IND	0x0184
SPI_CB_NLME_LEAVE_CNF	0x0185
SPI_CB_NLME_LEAVE_IND	0x0186
SPI_CB_NLME_SYNC_IND	0x0189
SPI_CB_NLME_NWK_DISC_CNF	0x018D
SPI_CB_NLME_START_ROUTER_CNF	0x018F

AF Callback ID codes

Callback Name	Callback ID
SPI_CB_AF_DATA_IND	0x0903

ZDO Callback ID codes

Callback Name	Callback ID
SPI_CB_ZDO_NWK_ADDR_RSP	0x0A80
SPI_CB_ZDO_IEEE_ADDR_RSP	0x0A81
SPI_CB_ZDO_NODE_DESC_RSP	0x0A82
SPI_CB_ZDO_POWER_DESC_RSP	0x0A83
SPI_CB_ZDO_SIMPLE_DESC_RSP	0x0A84
SPI_CB_ZDO_ACTIVE_EPINT_RSP	0x0A85
SPI_CB_ZDO_MATCH_DESC_RSP	0x0A86
SPI_CB_ZDO_END_DEVICE_BIND_RSP	0x0A87
SPI_CB_ZDO_BIND_RSP	0x0A88
SPI_CB_ZDO_UNBIND_RSP	0x0A89
SPI_CB_ZDO_MGMT_NWKDISC_RSP	0x0A8A
SPI_CB_ZDO_MGMT_LQI_RSP	0x0A8B
SPI_CB_ZDO_MGMT_RTG_RSP	0x0A8C
SPI_CB_ZDO_MGMT_BIND_RSP	0x0A8D
SPI_CB_ZDO_MGMT_DIRECT_JOIN_RSP	0x0A8E
SPI_CB_ZDO_USER_DESC_RSP	0x0A8F

NLME Status values

STATUS	VALUE
NLME_SUCCESS	0x00
NLME_FAILURE	0x01
NLME_ILLEGAL_REQUEST	0x02
NLME_UNKNOWN_DEVICE	0x03
NLME_STARTUP_FAILURE	0x04
NLME_NO_SHORT_ADDRESS	0x05
NLME_UNAVAILABLE_KEY	0x06
NLME_FRAME_TOO_LONG	0x07
NLME_FAILED_SECURITY_CHECK	0x08
NLME_INVALID_PARAMETER	0x09
NLME_UNSUPPORTED_ATTRIBUTE	0x0A
NLME_NOT_JOINED	0x0B
NLME_ALREADY_JOINED	0x0C
NLME_NOT_POSSIBLE	0x0D
NLME_TX_FAIL	0x0E
NLME_TX_ERROR	0x0F
NLME_RX_SUCCESS	0x10
NLME_RX_FAILURE	0x11
NLME_ALREADY_PRESENT	0x12
NLME_NO_NETWORKS	0x13
NLME_TABLE_FULL	0x14

NLME RX_STATE values

RX_STATE	VALUE
NLME_RX_CHECK	0x00
NLME_RX_DISABLE	0x01
NLME_RX_ENABLE	0x02
NLME_RX_TRACK	0x03

NLDE Status values

STATUS	VALUE
NLDE_SUCCESS	0x00
NLDE_INVALID_TARGET	0x01
NLDE_INVALID_PARAMETER	0x02
NLDE_BUFFER_FULL	0x03
NLDE_MEMORY_ERROR	0x04
NLDE_INVALID_NETWORK_STATE	0x05
NLDE_FAILURE	0x06

AF Status values

STATUS	VALUE
afStatus_SUCCESS	0x00
afStatus_FAILED	0x01
afStatus_MEM_FAIL	0x02
afStatus_INVALID_PARAMETER	0x03

Discovery: Query types and values

QUERY TYPE	QUERY VALUE
NWK_ADDR_LIST	NULL
IEEE_ADDR_LIST	NULL
SIMPLE_DESC	Endpoint
NODE_DESC	NULL

Transaction Codes

TRANSACTION CODE	VALUE
TRANSACTIONCODE_OK	0x00
TRANSACTIONCODE_INVALID_ENDPOINT	0x01
TRANSACTIONCODE_INVALID_INTERFACE	0x02
TRANSACTIONCODE_INVALID_ATTRIBUTEID	0x03
TRANSACTIONCODE_INVALID_TRANSTYPE	0x04
TRANSACTIONCODE_INVALID_TRANSDATALENGTH	0x05
TRANSACTIONCODE_INVALID_TRANSDATA	0x06

ⁱ Currently, it is not supported in Z-Stack to enable security for each single ZDO command. The parameter "In order to turn security on, users need to set SECURITY to 1 in f8wConfig.cfg. Then devices will form the network with security on and all over the air message are encrypted and authenticated.