

Application Note: Heap Memory Management

Document Number: F8W-2006-0026

Texas Instruments, Inc. San Diego, California USA (619) 497-3845

Version	Description	Date
1.0	Initial release.	12/06/2006
1.1	Changed document name. Updated title page.	05/21/2007

TABLE OF CONTENTS

I. ACRONYMS	III
4 WEAR MEMORY MANAGEMENT	
1. HEAP MEMORY MANAGEMENT	1
1.1 Introduction	1
1.2 API	
1.2.1 osal_mem_alloc()	
1.2.2 osal_mem_free()	
1.3 STRATEGY	
1.4 DISCUSSION	2
1.5 CONFIGURATION	
1.5.1 MAXMEMHEAP	2
1.5.2 OSALMEM_PROFILER	2
1.5.3 OSALMEM_MIN_BLKSZ	3
1.5.4 OSALMEM_SMALL_BLKSZ	3
1.5.5 SMALLBLKHEAP	3
1.5.6 OSALMEM_NODEBUG	
1.5.7 OSALMEM_GUARD	4
APPENDIX A. APPLICABLE DOCUMENTS	5

i. Acronyms

API Application Programming Interface

BSP Board Support Package – taken together, HAL & OSAL comprise a rudimentary

operating system commonly referred to as a BSP.

HAL Hardware (H/W) Abstraction Layer

OSAL Operating System (OS) Abstraction Layer

OTA Over-The-Air

1. Heap Memory Management

1.1 Introduction

The OSAL heap memory manager provides a POSIX-like API for allocating and re-cycling dynamic heap memory. Two important considerations in a low-cost, resource-constrained embedded system, size and speed, have been duly addressed in the implementation of the heap memory manager.

- Overhead memory cost to manage each allocated block has been minimized as little as 2 bytes on CPU's with byte-aligned memory access.
- Interrupt latency for the allocation and free operations has been minimized as little as 26 usecs on average combined total to allocate and free a block of memory during heavy OTA message load.

1.2 API

1.2.1 osal mem alloc()

The osal_mem_alloc() function is a request to the memory manager to reserve a block of the heap.

1.2.1.1 Prototype

```
void *osal_mem_alloc( uint16 size );
```

1.2.1.2 Parameters

size – the number of bytes of dynamic memory requested.

1.2.1.3 Return

If a big enough free block is found, the function returns a void pointer to the RAM location of the heap memory reserved for use. A NULL pointer is returned if there isn't enough memory to allocate. Any non-NULL pointer returned must be freed for re-use by invoking osal_mem_free().

1.2.2 osal mem free()

The osal_mem_free() function is a request to the memory manager to release a previously reserved block of the heap so that the memory can be re-used.

1.2.2.1 Prototype

```
void osal_mem_free( void *ptr );
```

1.2.2.2 Parameters

ptr-a pointer to the buffer to release for re-use – this pointer must be the non-NULL pointer that was returned by a previous call to osal_mem_alloc().

1.2.2.3 Return

None.

1.3 Strategy

Memory management should strive to maintain contiguous free space in the heap, in as few blocks as possible, with each block as big as possible. Such a general strategy helps to ensure that requests for large memory blocks always succeed if the total heap size has been set properly for the application's use pattern.

The following specific strategies have been implemented:

- Memory allocation begins searching for a large enough free block at the first free block in the heap.
- Memory allocation attempts to coalesce all contiguous free blocks traversed in an attempt to form a single free block large enough for an allocation request.
- Memory allocation uses the first free block encountered (or created by coalescing) that is big enough to meet the request; the memory block is split if it is very much bigger than the requested allocation.

1.4 Discussion

It is immediately after system task initialization that the effective "start of the heap" mark is set to be the first free block. Since the memory manager always starts a "walk", looking for a large enough free block, from the aforementioned mark, it will **greatly** reduce the run-time overhead of the walk if all long-lived heap allocations are packed at the start of the heap so that they will not have to be traversed on every memory allocation. Therefore, any application should make all long-lived dynamic memory allocations in its respective system initialization routine.

The application implementer shall ensure that their use of dynamic memory does not adversely affect the operation of the underlying layers of the Z-Stack. The Z-Stack is tested and qualified with sample applications that make minimal use of heap memory. Thus, the user application that uses significantly more heap than the sample applications, or the user application that is built with a smaller value set for MAXMEMHEAP than is set in the sample applications, may inadvertently starve the lower layers of the Z-Stack to the point that they cannot function effectively or at all. For example, an application could allocate so much dynamic memory that the underlying layers of the stack would be unable to allocate enough memory to send and/or receive any OTA messages – the device would not be seen to be participating OTA.

1.5 Configuration

1.5.1 MAXMEMHEAP

The MAXMEMHEAP constant is usually defined in OnBoard.h. It must be defined to be less than 32768.

MAXMEMHEAP is the number of bytes of RAM that the memory manager will reserve for the heap — it cannot be changed dynamically at runtime — it must be defined at compile-time. If MAXMEMHEAP is defined to be greater than or equal to 32768, a compiler error in osal_memory.c will trigger. MAXMEMHEAP does not reflect the total amount of dynamic memory that the user can expect to be usable because of the overhead cost per memory allocation.

1.5.2 OSALMEM PROFILER

The OSALMEM PROFILER constant is defined locally in osal memory.c to be **FALSE** by default.

After the implementation of a user application is mature, the OSAL memory manager may need to be re-tuned in order to achieve optimal run-time performance with the constraint of the MAXMEMHEAP defined. The code enabled by defining the OSALMEM_PROFILER constant to **TRUE** allows the user to gather the empirical, run-time results required to tune the memory manager for the application. The profiling code does the following.

1.5.2.1 OSALMEM INIT

The OSALMEM_INIT constant is defined locally in osal_memory.c to be ascii 'X'.

The memory manager initialization sets all of the bytes in the heap to the value of OSALMEM_INIT.

1.5.2.2 OSALMEM ALOC

The OSALMEM_INIT constant is defined locally in osal_memory.c to be ascii $\underline{\mathbf{A}}$.

The user available bytes of any block allocated are set to the value of OSALMEM_ALOC.

1.5.2.3 OSALMEM REIN

The OSALMEM_INIT constant is defined locally in osal_memory.c to be ascii ${\bf \underline{F}}$.

Whenever a block is freed, what had been the user available bytes are set to the value of OSALMEM REIN.

1.5.2.4 OSALMEM PROMAX

The OSALMEM_PROMAX constant is defined locally in osal_memory.c to be 8.

OSALMEM_PROMAX is the number of different bucket sizes to profile. The bucket sizes are defined by an array:

```
static uint16 proCnt[OSALMEM_PROMAX] = { OSALMEM_SMALL_BLKSZ, 48, 112, 176, 192, 224, 256, 65535 };
```

The bucket sizes profiled should be set according to the application being tuned, but the last bucket must always be 65535 as a catch-all. There are 3 metrics kept for each bucket.

- proCur the current number of allocated blocks that fit in the corresponding bucket size.
- proMax the maximum number of allocated blocks that corresponded to the bucket size at once.
- proTot the total number of times that a block was allocated that corresponded to the bucket size.

In addition, there is a count kept of the total number of times that the part of heap reserved for "small blocks" was too full to allow a requested small-block allocation: proSmallBlkMiss.

1.5.3 OSALMEM MIN BLKSZ

The OSALMEM_MIN_BLKSZ constant is defined locally in osal_memory.c to be 4 by default.

OSALMEM_MIN_BLKSZ is the minimum size in bytes of a block that is created by splitting a free block into two new blocks. The 1st new block is the size that is being requested in a memory allocation and it will be marked as in use. The 2nd block is whatever size is leftover and it will be marked as free. A larger number may result in significantly faster overall runtime of an application without necessitating any more or not very much more overall heap size. For example, if an application made a very large number of inter-mixed, short-lived memory allocations of 2 & 4 bytes each, the corresponding blocks would be 4 & 6 bytes each with overhead. The memory manager could spend a lot of time thrashing, as it were, repeatedly splitting and coalescing the same general area of the heap in order to accommodate the inter-mixed size requests.

1.5.4 OSALMEM_SMALL_BLKSZ

The OSALMEM SMALL BLKSZ constant is defined locally in osal memory.c to be 16 by default.

The heap memory use of the Z-Stack was profiled using the TransmitApp Sample Application and it was empirically determined that the best worst-case average combined time for a memory allocation and free, during a heavy OTA load, can be achieved by splitting the free heap into two sections. The first section is reserved for allocations of smaller-sized blocks and the second section is used for larger-sized allocations as well as for smaller-sized allocations if and when the first section is full. OSALMEM_SMALL_BLKSZ is the maximum block size in bytes that can be allocated from the first section.

1.5.5 SMALLBLKHEAP

The SMALLBLKHEAP constant is locally defined in osal_memory.c to be 232 by default.

SMALLBLKHEAP is the number of bytes dedicated to the previously described first section of the heap which is reserved for smaller-sized blocks. While profiling the heap memory use with TransmitApp, as many as 18 blocks of size OSALMEM_SMALL_BLKSZ (i.e. 16) were allocated simultaneously. Although the former observation would beg to define SMALLBLKHEAP to be 288 (i.e. 16 * 18), further work showed that the best worst-case times were achieved with the slightly smaller number defined by default.²

1.5.6 OSALMEM_NODEBUG

The OSALMEM_NODEBUG constant is locally defined in osal_memory.c to be **TRUE** by default.

The Z-Stack and Sample Applications do not misuse the heap memory API.³ The onus to be equally correct is on the user application: in order to provide the minimum throughput latency possible, there are no run-time checks for correct use of the API. An application can be shown to be correct by defining the OSALMEM_NODEBUG constant to FALSE. Such a setting will enable code that traps on the following misuse scenarios.

- invoking osal_mem_alloc() with size equal to zero.
- invoking osal_mem_free() with a NULL pointer.
- invoking osal_mem_free() with an already freed pointer.

Warning: invoking osal_mem_free() with a dangling or invalid pointer cannot be detected.

1.5.7 OSALMEM_GUARD

The OSALMEM_GUARD constant is locally defined in osal_memory.c to be **TRUE** by default.

The 1.4 Z-Stack is being released with a known bug: if a constant, LCD_SUPPORTED, is defined. The system initialization of the LCD support uses the heap memory API before the heap memory manager has been initialized. In order to guard against any use of the heap memory API before it has been initialized, the code enabled by OSALMEM_GUARD causes a run-time throughput cost in order to check a flag. If the application is not using the LCD, or if the user fixes the bug locally, then the runtime check (and concomitant throughput loss) can be eliminated by defining OSALMEM_GUARD as FALSE.

Appendix A. Applicable Documents

Internal Documents

- 1. Z-Stack OSAL API, F8W-2002-0002
- 2. Z-Stack Compile Options, F8W-2005-0038

Copyright © 2006 Texas Instruments, Inc. All rights reserved.

¹ There is no automatic garbage collection implemented in the memory manager. So any heap memory that is no longer used but not manually freed will be lost forever and is considered to be a "memory leak". The Z-Stack and Sample Applications are leak-free. A memory leak will eventually make the application appear to "lock-up" – eventually there will not even be enough free heap to set an OSAL timer or write a debug message to the serial port.

² The analysis of this counter-intuitive result is beyond the scope of this document.

³ Except the misuse noted below in section 1.4.6.