

Tresos License Handling

Version 2.00.00 2016-10-26 Application Note AN-ISC-8-1171

Author	Roland	Süß
-auiioi	i (Olai la	Ouis

Restrictions Customer Confidential – Vector decides

Abstract Support the user in handling the EB tresos™ license related to the 3rd Party software

packages

Table of Contents

1	Ove	rview	2
		dle the Single User License	
		Activation of the license	
	2.2	Deactivation of the license	3
3 Additional Resources		3	
4 Contact			3
4	COIII	Ilaul	



1 Overview

Vector integrations must not contain EB tresos[™] generation tool with activated license. Therefore the user has to perform some actions to prepare the EB tresos[™] tool for configuration respectively generation. The EB Client License Administration utility (provided by the 3rd Party vendor or Elektrobit) supports the user in activating the EB tresos[™] generation tool to work with the 3rd Party software packages (plugins).

Elektrobit offers several licensing variants:

- Single User Licenses
- > Floating licenses
- > Dongled licenses



Note

This document only considers the first variant as this is Vector's method of working with EB tresos™ driven 3rd Party software packages. Further information regarding the other variants can be found in Additional Resources.

2 Handle the Single User License

This license variant is restricted for usage with your local PC.

2.1 Activation of the license

Install the EB Client License Administration utility with the default option to use license activation codes





Figure 2-1 - Installing EB Client License Administration utility

> Enter a valid activation code and press the "Activate" button; the utility will connect to the Elektrobit license server for verification of the activation code and inform you about the result in the "Status" window







Note

The activation code has to be requested from the 3rd Party vendor.

Now EB tresos™ is prepared for configuration and generation via GUI respectively generation via command line (when using integration of Third-Party software with signed plugins within Vector tooling).

2.2 Deactivation of the license

If the license is no longer necessary you might remove it from your local PC by selecting the related license from the "Licenses" view and pressing the "Return" button



3 Additional Resources

EB tresos™ User Documentation:

- EB_tresos_installation_guide.pdf (provided with a Tresos installation from the 3rd Party vendor or Elektrobit)
- Licensing Users Guide.pdf (provided with the EB Client License Administration utility from the 3rd Party vendor or Elektrobit)

4 Contact

For a full list with all Vector locations and addresses worldwide, please visit http://vector.com/contact/.