

Power & Filters

File: Power&Filter.kicad_sch

CPU-ROM-RAM

File: CPU-ROM-RAM.kicad_sch

EPM7128S

File: EPM7128S.kicad_sch

VideoEarMic

File: Video.kicad_sch

Joystick

File: Joystick.kicad_sch

Turbo Sound

File: Turbo S0und.kicad_sch

SAA1099

File: SAA1099.kicad_sch

Midi

File: Midi.kicad_sch

PlusD

File: PlusD.kicad_sch



MountingHole



MountingHole



MountingHole



MountingHole



MountingHole



MountingHole

Sheet: /
File: ZX Max 128 PlusD Issue1.kicad_sch

Title:


Size: A4


Date:


Rev:


KiCad E.D.A. 10.0.4

Id: 1/10










Sheet: /VideoEarMic/
File: Video.kicad_sch

Title:

Size: A4
KiCad E.D.A. 10.0.4

Date:

Rev:
Id: 5/10




Sheet: /Joystick/
File: Joystick.kicad_sch

Title:

Size: A4
KiCad E.D.A. 10.0.4

Date:

Rev:
Id: 6/10



Sheet: /Turbo Sound/
File: Turbo S0und.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 10.0.4

Rev:

Id: 7/10



Sheet: /SAA1099/
File: SAA1099.kicad_sch

Title:


Size: A4


Date:

KiCad E.D.A. 10.0.4

Rev:

Id: 8/10





Sheet: /PlusD/
File: PlusD.kicad_sch

Title:

Size: A4
KiCad E.D.A. 10.0.4

Date:

Rev:
Id: 10/10