

# MAINTENANCE SCHEDULE

## SCHEDULE A

### CONDITIONS:

- Towing a trailer, using a camper or car top carrier.
- Repeated short trips less than 5 miles (8 km) and outside temperature remains below freezing.
- Extensive idling and/or speed driving for a long distance such as police, taxi or door-to-door delivery use.
- Operating on dusty, rough, muddy or salt spread roads.

Maintenance operations:

A = Check and adjust if necessary

R = Replace, change or lubricate

I = Inspect and correct or replace if necessary

| System            | Service interval<br>(Odometer reading or<br>months whichever comes<br>first) | Maintenance services beyond 60,000 miles (96,000 km) should continue to be performed at intervals shown for each maintenance schedule. |                                                                                                                                                                   |     |       |    |       |      |       |    |       |      |       |    |       |      |       |    |                                         | See page<br>(Item No.) |                 |
|-------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|-------|----|-------|------|-------|----|-------|------|-------|----|-------|------|-------|----|-----------------------------------------|------------------------|-----------------|
|                   |                                                                              | Miles x 1,000                                                                                                                          | 3.75                                                                                                                                                              | 7.5 | 11.25 | 15 | 18.75 | 22.5 | 26.25 | 30 | 33.75 | 37.5 | 41.25 | 45 | 48.75 | 52.5 | 56.25 | 60 | Months                                  |                        |                 |
| Maintenance items |                                                                              | km x 1,000                                                                                                                             | 6                                                                                                                                                                 | 12  | 18    | 24 | 30    | 36   | 42    | 48 | 54    | 60   | 66    | 72 | 78    | 84   | 90    | 96 |                                         |                        |                 |
| ENGINE            | Timing belt                                                                  |                                                                                                                                        |                                                                                                                                                                   |     |       |    |       |      |       |    |       |      |       |    |       |      |       | R  | —                                       | MA-4 (item 1)          |                 |
|                   | Valve clearance                                                              |                                                                                                                                        |                                                                                                                                                                   |     |       |    |       |      |       |    |       |      |       |    |       |      |       | A  | A: Every 72 months                      | MA-7 (item 12)         |                 |
|                   | Drive belt                                                                   |                                                                                                                                        | I: First period, 60,000 miles (96,000 km) or 72 months. I: After that every 7,500 miles (12,000 km) or 12 months.                                                 |     |       |    |       |      |       |    |       |      |       |    |       |      |       |    |                                         |                        | MA-4 (item 2)   |
|                   | Engine oil* MaintenanceE                                                     | 3S-GTE engine                                                                                                                          | R: Every 2,500 miles (4,000 km) or 3 months                                                                                                                       |     |       |    |       |      |       |    |       |      |       |    |       |      |       |    |                                         |                        | MA-6 (item 6)   |
|                   |                                                                              | Others                                                                                                                                 | R                                                                                                                                                                 | R   | R     | R  | R     | R    | R     | R  | R     | R    | R     | R  | R     | R    | R     | R  | R: Every 6 months                       |                        |                 |
|                   | Engine oil filter*                                                           | 3S-GTE engine                                                                                                                          | R: Every 5,000 miles (8,000 km) or 6 months                                                                                                                       |     |       |    |       |      |       |    |       |      |       |    |       |      |       |    |                                         |                        | MA-6 (item 6)   |
|                   |                                                                              | Others                                                                                                                                 | R                                                                                                                                                                 | R   | R     | R  | R     | R    | R     | R  | R     | R    | R     | R  | R     | R    | R     | R  | R: Every 6 months                       |                        |                 |
|                   | Engine coolant                                                               |                                                                                                                                        | R: First period, 45,000 miles (72,000 km) or 36 months. R: After that every 30,000 mile (48,000 km) or 24 months                                                  |     |       |    |       |      |       |    |       |      |       |    |       |      |       |    |                                         |                        | MA-7 (item 7)   |
| FUEL              | Exhaust pipes and mountin s                                                  |                                                                                                                                        |                                                                                                                                                                   |     | I     |    |       |      |       | I  |       |      |       | I  |       |      |       | I  | I: Every 24 months                      | MA-8 (item 11)         |                 |
|                   | Idle speed                                                                   | 4A-FE engine                                                                                                                           | A: Adjust at first 7,500 miles (12,000 km) or 12 months, and at 15,000 miles (24,000 km) or 24 months<br>Then adjust every 15,000 miles (24,000 km) or 24 months. |     |       |    |       |      |       |    |       |      |       |    |       |      |       |    |                                         |                        | MA-8 (item 13)  |
|                   | Air Filter (2)-,                                                             | 3S-GTE engine                                                                                                                          | I: Every 5,000 miles (8,000 km) or 6 months<br>R: Every 30,000 miles (48,000 km) or 36 months                                                                     |     |       |    |       |      |       |    |       |      |       |    |       |      |       |    |                                         |                        | MA-5 (item 3,4) |
|                   | Others                                                                       | I                                                                                                                                      | I                                                                                                                                                                 | I   | I     | I  | I     | I    | R     | I  | I     | I    | I     | I  | I     | I    | I     | R  | I: Every 6 months<br>R: Every 36 months |                        |                 |
| IGNITION          | Fuel lines and connections                                                   |                                                                                                                                        |                                                                                                                                                                   |     |       |    |       |      |       |    | I     |      |       |    |       |      |       | I  | I: Every 36 months                      | MA-8 (item 10)         |                 |
|                   | Fuel tank ca sket                                                            |                                                                                                                                        |                                                                                                                                                                   |     |       |    |       |      |       |    |       |      |       |    |       |      |       | R  | I: Every 72 months                      | MA-7 (item 9)          |                 |
| EVAP              | Spark plug                                                                   | 4A-FE engine *,                                                                                                                        |                                                                                                                                                                   |     |       |    |       |      |       |    | R     |      |       |    |       |      |       | R  | R: Every 36 months                      | MA-5 (item 5)          |                 |
|                   |                                                                              | Others                                                                                                                                 |                                                                                                                                                                   |     |       |    |       |      |       |    |       |      |       |    |       |      |       | R  | R: Every 72 months                      |                        |                 |
| BRAKES            | Charcoal canister                                                            |                                                                                                                                        |                                                                                                                                                                   |     |       |    |       |      |       |    |       |      |       |    |       |      |       | I  | I: Every 72 months                      | MA-7 (item 8)          |                 |
|                   | Brake linings and drums (d)                                                  |                                                                                                                                        |                                                                                                                                                                   | I   |       | I  |       | I    |       | I  |       | I    |       | I  |       | I    |       | I  | I: Every 12 months                      | MA-10 (item 16)        |                 |
| CHASSIS           | Brake pads and discs Front and rear                                          |                                                                                                                                        |                                                                                                                                                                   | I   |       | I  |       | I    |       | I  |       | I    |       | I  |       | I    |       | I  | I: Every 12 months                      | MA-10 (item 15)        |                 |
|                   | Brake line pipes and hoses                                                   |                                                                                                                                        |                                                                                                                                                                   |     |       | I  |       |      |       | I  |       |      |       | I  |       |      |       | I  | I: Every 24 months                      | MA-9 (item 14)         |                 |
|                   | Steerin linka e                                                              |                                                                                                                                        |                                                                                                                                                                   | I   |       | I  |       | I    |       | I  |       | I    |       | I  |       | I    |       | I  | I: Every 12 months                      | MA-11 (item 17)        |                 |
|                   | SRS airba,                                                                   |                                                                                                                                        | I: First period, 10 years. I: After that every 2 years.                                                                                                           |     |       |    |       |      |       |    |       |      |       |    |       |      |       |    |                                         |                        | MA-11 (item 18) |
|                   | Drive shaft boots                                                            |                                                                                                                                        |                                                                                                                                                                   | I   |       | I  |       | I    |       | I  |       | I    |       | I  |       | I    |       | I  | I: Every 12 months                      | MA-12 item 20          |                 |
|                   | Ball joints and dust covers                                                  |                                                                                                                                        |                                                                                                                                                                   | I   |       | I  |       | I    |       | I  |       | I    |       | I  |       | I    |       | I  | I: Every 12 months                      | MA-12 item 21          |                 |
|                   | Manual transaxle, automatic transaxle,<br>transfer and differential          |                                                                                                                                        |                                                                                                                                                                   |     |       | R  |       |      |       | R  |       |      |       | R  |       |      |       | R  | R: Every 24 months                      | MA-13 (item 22, 23)    |                 |
|                   | Steerin ear housin oil                                                       |                                                                                                                                        |                                                                                                                                                                   |     |       | I  |       |      |       | I  |       |      |       | I  |       |      |       | I  | I: Every 24 months                      | MA-12 item 19          |                 |
|                   | Bolts and nuts on chassis and bod                                            |                                                                                                                                        |                                                                                                                                                                   | I   |       | I  |       | I    |       | I  |       | I    |       | I  |       | I    |       | I  | I: Every 12 months                      | MA-15 item 24          |                 |

\*and ' marks indicate maintenance which is part of the warranty conditions for the Emission Control System. The warranty period is in accordance with the owner's guide or the warranty booklet.

(\* California specification vehicles

': Other specification vehicles)

(1) Applicable to vehicles operated under conditions of extensive idling and/or low speed driving for a long distance such as police, taxi or door-to-door delivery use.

(2) Applicable when operating mainly on dusty road. If not, apply SCHEDULE B.

(3) Includes inspection of fuel tank band and vapor vent system.

(4) Also applicable to lining drum for parking brake.

(5) Check for leakage.

(6) Check for oil leaks from steering gear housing.

(7) Applicable only when operating mainly on rough, muddy roads. The applicable parts are listed below. For other usage conditions, refer to SCHEDULE B.

- Front and rear suspension member to cross body

- Strut bar bracket to body bolts

- Bolts for seat installation

# SCHEDULE B

CONDITIONS: Conditions other than those listed for SCHEDULE A.

| System                      | Service interval<br>(Odometer reading<br>months, whichever<br>comes first) | Maintenance service beyond 60,000 miles (96,000 km) should continue to be performed at the same intervals shown for each maintenance schedule. |                                                                                                                                                                 |    |      |    |      |    |      |                    |                    | See page<br>(item No.) |                 |
|-----------------------------|----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|----|------|----|------|----|------|--------------------|--------------------|------------------------|-----------------|
|                             |                                                                            | Miles x 1,000                                                                                                                                  | 7.5                                                                                                                                                             | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | 60                 | Months             |                        |                 |
|                             | Maintenance items                                                          | km x 1,000                                                                                                                                     | 12                                                                                                                                                              | 24 | 36   | 48 | 60   | 72 | 84   | 96                 |                    |                        |                 |
| ENGINE                      | Valve clearance                                                            |                                                                                                                                                |                                                                                                                                                                 |    |      |    |      |    |      | A                  | A: Every 72 months | MA-8 (item 12)         |                 |
|                             | Drive belt                                                                 |                                                                                                                                                | I: First period, 60,000 miles (96,000 km) or 72 months. I: After that every 7,500 miles (12,000 km) or 12 months.                                               |    |      |    |      |    |      |                    |                    |                        | MA-4 (item 2)   |
|                             | Engine oil*                                                                | 3S-GTE engine                                                                                                                                  | R: Every 5,000 miles (8,000 km) or 6 months.                                                                                                                    |    |      |    |      |    |      |                    |                    |                        | MA-6 (item 6)   |
|                             |                                                                            | Others                                                                                                                                         | R                                                                                                                                                               | R  | R    | R  | R    | R  | R    | R                  | R                  | R: Every 12 months     |                 |
|                             | Engine oil filter"                                                         | 3S-GTE engine                                                                                                                                  | R: Every 10,000 miles (16,000 km) or 12 months.                                                                                                                 |    |      |    |      |    |      |                    |                    |                        | MA-6 (item 6)   |
|                             |                                                                            | Others                                                                                                                                         | R                                                                                                                                                               | R  | R    | R  | R    | R  | R    | R                  | R                  | R: Every 12 months     |                 |
|                             | Engine coolant                                                             |                                                                                                                                                | R: First period, 45,000 miles (72,000 km) or 36 months. R: After that every 30,000 miles (48,000 km) or 24 months.                                              |    |      |    |      |    |      |                    |                    |                        | MA-7 (item 7)   |
| Exhaust pipes and mountings |                                                                            |                                                                                                                                                |                                                                                                                                                                 |    | I    |    |      |    | I    | I: Every 36 months | MA-8 (item 11)     |                        |                 |
| FUEL                        | Idle speed                                                                 | 4A-FE engine                                                                                                                                   | A: Adjust at first 7,500 miles (12,000 km) or 12 months, and at 15,000 miles (24,000 km) or 24 months. Then adjust every 15,000 miles (24,000 km) or 24 months. |    |      |    |      |    |      |                    |                    |                        | MA-8 (item 13)  |
|                             | Air filter"                                                                |                                                                                                                                                |                                                                                                                                                                 |    | R    |    |      |    |      | R                  | R: Every 36 months | MA-5 (item 4)          |                 |
|                             | Fuel lines and connections                                                 |                                                                                                                                                |                                                                                                                                                                 |    | I    |    |      |    |      | I                  | I: Every 36 months | MA-8 (item 10)         |                 |
|                             | Fuel tank cap gasket                                                       |                                                                                                                                                |                                                                                                                                                                 |    |      |    |      |    |      | R                  | R: Every 72 months | MA-7 (item 9)          |                 |
| IGNITION                    | Speak plugs                                                                | 4A-FE engine"                                                                                                                                  |                                                                                                                                                                 |    |      | R  |      |    |      | R                  | R: Every 36 months | MA-5 (item 5)          |                 |
|                             |                                                                            | Others                                                                                                                                         |                                                                                                                                                                 |    |      |    |      |    |      | R                  | R: Every 72 months |                        |                 |
| EVAP                        | Charcoal canister                                                          |                                                                                                                                                |                                                                                                                                                                 |    |      |    |      |    |      | I                  | I: Every 72 months | MA-7 (item 8)          |                 |
| BRAKES                      | Brake linings and drums (2)                                                |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-10 (item 16)        |                 |
|                             | Brake pads and discs (Front and rear)                                      |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-10 (item 15)        |                 |
|                             | Brake line pipes and hoses                                                 |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-9 (item 14)         |                 |
| CHASSIS                     | Steering linkage                                                           |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-11 (item 17)        |                 |
|                             | SRS airbag                                                                 |                                                                                                                                                | I: First period, 10 years. I: After that every 2 years.                                                                                                         |    |      |    |      |    |      |                    |                    |                        | MA-11 (item 18) |
|                             | Drive shaft boots                                                          |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-12 (item 20)        |                 |
|                             | Ball joints and dust covers                                                |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-12 (item 21)        |                 |
|                             | Manual transaxle, automatic transaxle and differential (3)                 |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-13 (item 22)        |                 |
|                             | Steering gear housing oil                                                  |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-12 (item 19)        |                 |
|                             | Bolts and nuts on chassis and body (5)                                     |                                                                                                                                                |                                                                                                                                                                 | I  |      | I  |      | I  |      | I                  | I: Every 24 months | MA-15 (item 24)        |                 |

\* ad \* marks conditions for the Emission Control System. The warranty period is in accordance with the owner's guide or the warranty booklet .

i\*: California specification vehicles \*: Other specification vehicles)

1 Includes inspection of fuel tank band and vapor vent system.

2 Also applicable to lining drum for parking brake.

3 Check for leakage.

4 Check for oil leaks from steering gear housing.

5 The applicable parts are listed below.

- Front and rear suspension member to cross body
- Strut bar bracket to body bolt