PINOUT TABLES - one table per connector, bus plug, splice and end of the set; every pin, the wire on it and where its other end lands

Length = layout path + end allowance (estimate until measured). Built with = the harness that builds that wire (a wire passing through is built with its owner). A pin with no wire takes a sealing plug.

ECU-A - Link G4X plug A (centre dash)

housing 4-1437290-1 | contacts 3-1447221-4 | pins per Link G4X XtremeX QSG p.5 pin numbering (1-34)

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
1	w111_c	20	White	🟦🟨🟦🟨	Injector 4 drive (-)	DRB102 receptacle (RH firewall) pin 24	630	ST185-AB-cabin	INJ4
2	w110_c	20	White	🟦🟨🟦🟦	Injector 3 drive (-)	DRB102 receptacle (RH firewall) pin 23	630	ST185-AB-cabin	INJ3
3	w109_c	20	White	🟦🟦⬜⬜	Injector 2 drive (-)	DRB102 receptacle (RH firewall) pin 22	630	ST185-AB-cabin	INJ2
4	w108_c	20	White	🟦🟦⬜🟨	Injector 1 drive (-)	DRB102 receptacle (RH firewall) pin 21	630	ST185-AB-cabin	INJ1
5	w_a5_pin	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse (+ IG2 wak...	ECU splice point - SP-A5: ECU main feed (SW12 + IG2 diode)	310	ST185-AB-cabin	SW12
6	w19	20	Orange	⬜🟦⬜	+8 V sensor supply	ECU splice point - SP-8V: +8 V cam sensor supply (ECU A6)	310	ST185-AB-cabin	8V
7	w_drain_ecu_a	20	Black	🟨⬜🟦	Shield drain	6 mm behind the ECU-A plug - SP-SHIELD-A: drains to A7	200	ST185-AB-cabin	SHLD
8	w200_c	20	White	🟦🟦⬜🟦	Crank sensor signal	DRB102 receptacle (RH firewall) pin 74	630	ST185-AB-cabin	CRANKC
9	w_trig2_pin	20	White	🟦🟦🟨	Cam sensor signal	At the ECU plugs - SP-CAM: cam signal + 1.8k pull-up to +8V	310	ST185-AB-cabin	CAM
10	w123_c	20	White	⬜⬜⬜	Coil 4 trigger (IGT)	DRB102 receptacle (RH firewall) pin 12	630	ST185-AB-cabin	COP4
11	w122_c	20	White	⬜⬜🟨	Coil 3 trigger (IGT)	DRB102 receptacle (RH firewall) pin 11	630	ST185-AB-cabin	COP3
12	w121_c	20	White	⬜🟨⬜	Coil 2 trigger (IGT)	DRB102 receptacle (RH firewall) pin 10	630	ST185-AB-cabin	COP2
13	w120_c	20	White	⬜🟨🟨	Coil 1 trigger (IGT)	DRB102 receptacle (RH firewall) pin 9	630	ST185-AB-cabin	COP1
14	w38	20	Blue	🟨⬜⬜	Pedal 1 signal main	accelerator pedal sensor pin 6	1090	ST185-AB-cabin	APS
15	w201_c	20	White	🟦🟦🟦🟦	Coolant temp signal	DRB102 receptacle (RH firewall) pin 70	630	ST185-AB-cabin	ECT
16	w202_c	20	White	🟦🟨🟨🟨	Intake temp signal	DRB102 receptacle (RH firewall) pin 33	630	ST185-AB-cabin	IATC
17	w26_c	20	White	🟦🟨⬜🟨	MAP sensor signal	DRB102 receptacle (RH firewall) pin 17	630	ST185-AB-cabin	MAPC
18	w_fan285	18	White	⬜🟦	Cond fan relay (-)	Condenser Fan Relay (on/off) (seated in the POWER box R5) - ACTIVE-LOW - ECU sinks coi...	680	ST185-AB-cabin	FAN2
19	w_fp85	18	White	⬜⬜🟦	Fuel pump relay (-)	Fuel Pump Relay, TE HCR150 (seated in the battery relay block K1) - ACTIVE-LOW - ECU si...	3130	ST185-AB-cabin	FP
20	w81	20	White	⬜⬜	ETB relay coil (-)	ETB Power Relay (seated in the LOGIC box M4) - ACTIVE-LOW - ECU sinks coil- (85); coil+ ...	680	ST185-CabinPower	ETB
21	w103_c	20	White	🟦🟦🟦⬜	Boost solenoid (-)	DRB102 receptacle (RH firewall) pin 58	630	ST185-AB-cabin	BOOST
22	w128_c	20	White	🟦🟦⬜	Throttle pos 1 main	DRB102 receptacle (RH firewall) pin 42	630	ST185-AB-cabin	ETBS
23	cab_fspur_l	20	Blue	⬜🟦🟨	FL conditioned out	to front VR conditioner pin 3	530	ST185-AB-cabin	WSSF
24	w68	18	Blue	🟨🟨	Sensor ground	DT06-12 plug (ECU splice point) pin 1	310	ST185-AB-cabin	SGND
25	w70	18	Black	🟨🟨⬜	ECU power ground	ECU splice point - SP-GND-ECU: ECU power ground (A25 A34 B25 B34) to the NEG bar	310	ST185-AB-cabin	GND
26	w_str85	18	White	⬜🟨	Start relay coil (-)	Start Relay (seated in the POWER box R3) - ACTIVE-LOW - ECU sinks coil- (85); coil+ (86) s...	680	ST185-AB-cabin	STR
27	w_mrs_c	20	White	🟦🟨⬜⬜	EHPS pump speed	DRB102 receptacle (RH firewall) pin 84	630	ST185-AB-cabin	MRSSPD
28	w76	18	White	🟦🟨	EFI relay coil (-)	EFI Main Relay (seated in the POWER box R2) - ACTIVE-LOW - ECU sinks coil- (85); coil+ (...	680	ST185-CabinPower	EFI
29	w_fan85	18	White	🟨⬜	Rad fan relay (-)	Radiator Fan Relay (on/off) (seated in the POWER box R4) - ACTIVE-LOW - ECU sinks coil- ...	680	ST185-AB-cabin	FAN
30	w16_c	20	White	🟨🟦⬜	Turbo speed signal	DRB102 receptacle (RH firewall) pin 53	630	ST185-AB-cabin	TURBO
31	w48_c	20	White	🟨🟨🟨	Flex fuel signal	DRB102 receptacle (RH firewall) pin 31	630	ST185-AB-cabin	FLEX
32	w67	18	Orange	🟦🟦	+5 V sensor supply	DT06-12 plug (ECU splice point) pin 1	310	ST185-AB-cabin	5V
33	w129_c	20	White	🟦🟦⬜	Throttle pos 2 sub	DRB102 receptacle (RH firewall) pin 44	630	ST185-AB-cabin	ETBS
34	w_a34	18	Black	🟨🟨⬜	ECU power ground	ECU splice point - SP-GND-ECU: ECU power ground (A25 A34 B25 B34) to the NEG bar	310	ST185-AB-cabin	GND

ECU-B (Link G4X plug B, centre dash)

housing 4-1437290-0 | contacts TBD | pins per Link G4X XtremeX QSG p.5 pin numbering (1-34)

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
1					spare, not used				
2					spare, not used				
3					spare, not used				
4					spare, not used				
5	w82_ac	18	Red	⬜⬜	ETB motor +12 V	ETB Power Relay (seated in the LOGIC box M4) - ACTIVE-LOW - ECU sinks coil- (85); coil+ ...	680	ST185-CabinPower	ETB
6	w203_c	20	White	🟦🟦🟨🟦	Oil temp signal	DRB102 receptacle (RH firewall) pin 61	630	ST185-AB-cabin	OILT
7	w204_c	20	White	🟦🟨🟨🟦	Charge temp signal	DRB102 receptacle (RH firewall) pin 59	630	ST185-AB-cabin	CIAT
8					spare, not used				
9	w205_c	20	White	🟦🟦🟦⬜	Knock sensor signal	DRB102 receptacle (RH firewall) pin 71	630	ST185-AB-cabin	KNOCK
10	w_acc_trig	18	White	🟨🟦	A/C clutch relay (-)	SP-ACC-85 - A/C clutch relay coil- net: ECU B10, k_acc 85 and the A/C switch lamp	420	ST185-AB-cabin	ACC
11					spare, not used				
12	w_eps_trig	18	White	🟦⬜	EPS enable relay (-)	EPS Enable Relay (seated in the LOGIC box M6) - ACTIVE-LOW - ECU sinks coil- (85); coil+...	680	ST185-AB-cabin	EPSEN
13					spare, not used				
14					spare, not used				
15	w29_c	20	White	🟦⬜🟦🟦	Oil pressure signal	DRB102 receptacle (RH firewall) pin 28	630	ST185-AB-cabin	OILPC
16	w32_c	20	White	🟦🟦🟦🟨	Fuel pressure signal	DRB102 receptacle (RH firewall) pin 14	630	ST185-AB-cabin	FUELP
17	w_drain_ecu_b	20	Black	🟨⬜🟦	Shield drain B	6 mm behind the ECU-B plug - SP-SHIELD-B: drains to B17	200	ST185-AB-cabin	SHLD
18	w124_c	18	White	🟦🟨⬜	ETB motor +	DRB102 receptacle (RH firewall) pin 45	630	ST185-AB-cabin	ETBM
19	cab_rspur_r	20	Blue	🟦🟦🟨🟨	Rear right wheel spd	IX-WS-R inline to rear VRC (dash above ECU) pin 4	530	ST185-AB-cabin	WSSR
20	cab_rspur_l	20	Green	🟦🟦🟨🟨	Rear left wheel spd	IX-WS-R inline to rear VRC (dash above ECU) pin 3	530	ST185-AB-cabin	WSSR
21	cab_fspur_r_ac	20	White	⬜🟦🟨	FR conditioned out	to front VR conditioner pin 4	530	ST185-AB-cabin	WSSF
22	w69	18	Blue	🟨🟨	Sensor ground B	DT06-12 plug (ECU splice point) pin 1	310	ST185-AB-cabin	SGND
23	w35_c	20	White	⬜🟨🟦	Coolant press signal	DRB102 receptacle (RH firewall) pin 26	630	ST185-AB-cabin	CLNTP
24	w_fl_sig_pin	20	White	🟦🟨🟦	Fuel level signal	SP-FUEL-LVL - fuel sender signal + 470R pull-up to ECU-B B24	310	ST185-AB-cabin	FLVL
25	w_b25_ac	18	Black	🟨🟨⬜	ECU power ground	ECU splice point - SP-GND-ECU: ECU power ground (A25 A34 B25 B34) to the NEG bar	310	ST185-AB-cabin	GND
26	w215_c	18	White	🟦🟨⬜	ETB motor -	DRB102 receptacle (RH firewall) pin 46	630	ST185-AB-cabin	ETBM
27	w_at_immob2	20	White	🟨🟦🟨	Anti-theft input	Alarm module - main harness (DT06-12SA) pin 9	380	ST185-AntiTheft	IMMOB
28	w_ign	20	Yellow	🟦🟨⬜🟦	Ignition sw sense	OEM J/B No.1 (LH kick panel) 1H pin 7, B-O pin 7	1100	ST185-AB-cabin	IGNSW
29	w_vss_sig_c	20	White	🟨⬜🟨	Gearbox speed signal	DRB102 receptacle (RH firewall) pin 68	630	ST185-AB-cabin	VSS
30	w_start	20	Yellow	🟦🟨🟨	Start request	LOGIC box - custom fuse + relay box, glove box inboard (cad/fusebox rev 5, DECISIONS R7...	680	ST185-AB-cabin	B30
31					spare, not used				
32					spare, not used				
33	w_aps_vpa2	20	Blue	🟨⬜⬜	Pedal 2 signal sub	accelerator pedal sensor pin 3	1090	ST185-AB-cabin	APS
34	w_b34_ac	18	Black	🟨🟨⬜	ECU power ground	ECU splice point - SP-GND-ECU: ECU power ground (A25 A34 B25 B34) to the NEG bar	310	ST185-AB-cabin	GND

ECU-C - ECU Comms/Tuning Port

housing DTM06-6S + WM-6S | contacts 0462-201-2031 | pins per Deutsch DT / DTM cavity numbers (moulded on the housing)

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
1	w_shd_can_trunk	20	Black	🟨	CAN screen trunk	CAN trunk, cluster branch - SP-CAN-SH-CLU: CAN screen	650	ST185-CAN	CAN
2					spare, sealing plug				
3	wc_h_ecu	20	White	🟨	CAN 1 high	CAN H join - ECU, CSB3, cluster, Pi, bulkhead	250	ST185-CAN	CAN
4	wc_l_ecu	20	Green	🟨	CAN 1 low	CAN L join - ECU, CSB3, cluster, Pi, bulkhead	250	ST185-CAN	CAN
5					spare, sealing plug				
6					spare, sealing plug				

BUS-5V - DT06-12 plug (ECU splice point)

housing DT06-12SA + W12S; DT04-12PA-P021 (bussed cap) | contacts 0462-201-16141 | pins per Deutsch DT / DTM cavity numbers (moulded on the housing)

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
1	w67	18	Orange	🟦🟦	+5 V from ECU A32	Link G4X plug A (centre dash) pin 32	310	ST185-AB-cabin	5V
2	w_rail_sp_5v_c	20	Orange	🟦🟦	+5 V throttle sensor	DRB102 receptacle (RH firewall) pin 41	520	ST185-AB-cabin	5V
3	w_5v_a_c39	20	Orange	🟦🟦	+5 V MAP sensor	DRB102 receptacle (RH firewall) pin 16	520	ST185-AB-cabin	5V
4	w_5v_a_c40	20	Orange	🟦🟦	+5 V turbo speed	DRB102 receptacle (RH firewall) pin 52	520	ST185-AB-cabin	5V
5	w_5v_brail_c45	20	Orange	🟦🟦	+5 V oil pressure	DRB102 receptacle (RH firewall) pin 27	520	ST185-AB-cabin	5V
6	w_5v_brail_c46	20	Orange	🟦🟦	+5 V fuel pressure	DRB102 receptacle (RH firewall) pin 13	520	ST185-AB-cabin	5V
7	w_5v_brail_c47	20	Orange	🟦🟦	+5 V coolant press	DRB102 receptacle (RH firewall) pin 25	520	ST185-AB-cabin	5V
8	w_aps_vc1	20	Red	🟦🟦	+5 V pedal sensor 1	accelerator pedal sensor pin 4	1200	ST185-AB-cabin	5V
9	w210	20	Red	🟦🟦	+5 V pedal sensor 2	accelerator pedal sensor pin 1	1200	ST185-AB-cabin	5V
10	cab_fspur_5v	20	Red	🟦🟦	+5 V front VRC	to front VR conditioner pin 1	640	ST185-AB-cabin	5V
11	cab_rspur_5v	20	Red	🟦🟦	+5 V rear VRC	IX-WS-R inline to rear VRC (dash above ECU) pin 1	640	ST185-AB-cabin	5V
12	w_5v_bus_link	20	Orange	🟦🟦	+5 V to BUS-5V-2	DT06-8 plug (ECU splice point) pin 1	200	ST185-AB-cabin	5V

BUS-5V-2 - DT06-8 plug (ECU splice point)

housing DT06-08SA + W8S; DT04-08PA-P021 (bussed cap) | contacts 0462-201-16141 | pins per Deutsch DT / DTM cavity numbers (moulded on the housing)

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
1	w_5v_bus_link	20	Orange	🟦🟦	+5 V from BUS-5V	DT06-12 plug (ECU splice point) pin 12	200	ST185-AB-cabin	5V
2	w_cru_5v_ac	20	Orange	🟦🟦	+5 V cruise ladder	resistor r_cruise on CSB3 pin 1	680	ST185-AB-cabin	5V
3					spare, sealing plug				
4	w44	20	Orange	🟦🟨🟦	+5 V fuel lvl pullup	470R fuel level pull-up to +5V pin 2	200	ST185-AB-cabin	FLVL
5					spare, sealing plug				
6					spare, sealing plug				
7					spare, sealing plug				
8					spare, sealing plug				

BUS-GNDOUT-A - DT06-12 plug (ECU splice point)

housing DT06-12SA + W12S; DT04-12PA-P021 (bussed cap) | contacts 0462-201-16141 | pins per Deutsch DT / DTM cavity numbers (moulded on the housing)

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
1	w68	18	Blue	🟨🟨	Sensor gnd from A24	Link G4X plug A (centre dash) pin 24	310	ST185-AB-cabin	SGND
2	w_rail_sp_gndout_c	20	Blue	🟨🟨	Gnd IAT/TPS/coolant	DRB102 receptacle (RH firewall) pin 34	520	ST185-AB-cabin	SGND
3	w_gnd_a_c41	20	Blue	🟨🟨	Gnd crank sensor	DRB102 receptacle (RH firewall) pin 75	520	ST185-AB-cabin	SGND
4	w_gnd_a_c42	20	Blue	🟨🟨	Gnd cam sensor	DRB102 receptacle (RH firewall) pin 65	520	ST185-AB-cabin	SGND
5	w_gnd_a_c43	20	Blue	🟨🟨	Gnd turbo speed	DRB102 receptacle (RH firewall) pin 56	520	ST185-AB-cabin	SGND
6	w_gnd_a_c44	20	Blue	🟨🟨	Gnd flex + MAP	DRB102 receptacle (RH firewall) pin 18	520	ST185-AB-cabin	SGND
7	w40	20	Yellow	🟨🟨	Pedal 1 ground	accelerator pedal sensor pin 5	1200	ST185-AB-cabin	SGND
8	w_aps_gnd2	20	Yellow	🟨🟨	Pedal 2 ground	accelerator pedal sensor pin 2	1200	ST185-AB-cabin	SGND
9	cab_fspur_gnd	20	Yellow	🟨🟨	Front VRC ground	to front VR conditioner pin 2	640	ST185-AB-cabin	SGND
10					spare, sealing plug				
11					spare, sealing plug				
12					spare, sealing plug				

BUS-GNDOUT-B - DT06-12 plug (ECU splice point)

housing DT06-12SA + W12S; DT04-12PA-P021 (bussed cap) | contacts 0462-201-16141 | pins per Deutsch DT / DTM cavity numbers (moulded on the housing)

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
1	w69	18	Blue	🟨🟨	Sensor gnd from B22	ECU-B (Link G4X plug B, centre dash) pin 22	310	ST185-AB-cabin	SGND
2	w45	20	Blue	🟨🟨	Fuel level ground	IX-FUEL inline to fuel sender lead (trunk end) pin 2	2820	ST185-AB-cabin	SGND
3	cab_rspur_gnd	20	Yellow	🟨🟨	Rear VRC ground	IX-WS-R inline to rear VRC (dash above ECU) pin 2	640	ST185-AB-cabin	SGND
4					spare, sealing plug				
5					spare, sealing plug				
6	w12_c	20	Blue	🟦🟦🟦⬜	Knock sensor (-)	DRB102 receptacle (RH firewall) pin 72	520	ST185-AB-cabin	KNOCK
7	w_gnd_b_c19	20	Blue	🟨🟨	Gnd oil/clnt/temps	DRB102 receptacle (RH firewall) pin 29	520	ST185-AB-cabin	SGND
8	w_gnd_b_c21	20	Blue	🟨🟨	Gnd fuel press + VSS	DRB102 receptacle (RH firewall) pin 15	520	ST185-AB-cabin	SGND
9					spare, sealing plug				
10					spare, sealing plug				
11					spare, sealing plug				
12					spare, sealing plug				

BUS-SW12 - SW12 bus plug DT06-12 (glove box, by LOGIC box)

housing DT06-12SA + W12S; DT04-12PA-P021 (bussed cap) | contacts 0462-201-16141 | pins per Deutsch DT / DTM cavity numbers (moulded on the housing)

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
1	w_cp_sw12_in	16	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	LOGIC box - custom fuse + relay box, glove box inboard (cad/fusebox rev 5, DECISIONS R7...	200	ST185-CabinPower	SW12
2	w_fb_sw12	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	ECU splice point - SP-SW12: switched +12 V (LOGIC SW12)	570	ST185-AB-cabin	SW12
3	w_k_fp_86_cp	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	Fuel Pump Relay, TE HCR150 (seated in the battery relay block K1) - ACTIVE-LOW - ECU si...	2650	ST185-CabinPower	SW12
4	w_k_fan_86_cp	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	Radiator Fan Relay (on/off) (seated in the POWER box R4) - ACTIVE-LOW - ECU sinks coil- ...	200	ST185-CabinPower	SW12
5	w_k_etb_86_cp	20	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	ETB Power Relay (seated in the LOGIC box M4) - ACTIVE-LOW - ECU sinks coil- (85); coil+ ...	200	ST185-CabinPower	SW12
6	w_k_str_86_cp	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	Start Relay (seated in the POWER box R3) - ACTIVE-LOW - ECU sinks coil- (85); coil+ (86) s...	200	ST185-CabinPower	SW12
7	w_k_fan2_86_cp	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	Condenser Fan Relay (on/off) (seated in the POWER box R5) - ACTIVE-LOW - ECU sinks coi...	200	ST185-CabinPower	SW12
8	w_k_eps_86_cp	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	MR-S EHPS pump relay (HCR150, glove box, beside the POWER box) - coil- (85) switched to...	200	ST185-CabinPower	SW12
9	w_k_eps_en_86_cp	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse	EPS Enable Relay (seated in the LOGIC box M6) - ACTIVE-LOW - ECU sinks coil- (85); coil+...	200	ST185-CabinPower	SW12
10					spare, sealing plug				
11					spare, sealing plug				
12					spare, sealing plug				

SP-12V-SHK - Shock sensor +12 V splice - LOGIC ALMS 2A fuse to shock sensor pin A

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_at_12v_shk_tie_cp	20	Red	🟨⬜⬜	AMI BUS1 50 A fuse -> LOGIC ALMS 2 A fuse	LOGIC box - custom fuse + relay box, glove box inboard (cad/fusebox rev 5, DECISIONS R7...	860	ST185-CabinPower	ALMS
	w_at_12v_shk	20	Red	🟨⬜⬜	AMI BUS1 50 A fuse -> LOGIC ALMS 2 A fuse	Shock / tilt sensor * pin A	200	ST185-AntiTheft	ALMS

SP-8V - ECU splice point - SP-8V: +8 V cam sensor supply (ECU A6)

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_cam_pullup_8v	20	Orange	🟦🟦🟨	+8 V to cam pull-up	Cam pull-up 1.8 k to +8 V pin 1	200	ST185-AB-cabin	CAM
	w19	20	Orange	⬜🟦⬜	+8 V sensor supply	Link G4X plug A (centre dash) pin 6	310	ST185-AB-cabin	8V
	w_rail_sp_8v_c	20	Orange	⬜🟦⬜	+8 V to cam sensor	DRB102 receptacle (RH firewall) pin 63	520	ST185-AB-cabin	8V

SP-A5 - ECU splice point - SP-A5: ECU main feed (SW12 + IG2 diode)

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w78	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse (+ IG2 wak...	ECU splice point - SP-SW12: switched +12 V (LOGIC SW12)	200	ST185-AB-cabin	SW12
	w_ig2_diode	20	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse (+ IG2 wak...	IG2 wake diode (1N5822) pin 2	200	ST185-AB-cabin	SW12
	w_a5_pin	18	Red	🟦	EFI relay k_efi -> LOGIC SW12 7.5 A fuse (+ IG2 wak...	Link G4X plug A (centre dash) pin 5	310	ST185-AB-cabin	SW12

SP-AC-SGND - auto A/C sensor common (replaces the engine-bay splice E10, 1993 EWD p.211): A32 pin 15, A24 pin 3, A21 / A18 pin 2 via I8, and the ambient sensor A1 return

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_tam_rtn	20	Blue	⬜⬜🟦	Ambient temp return	A/C ambient temp sensor A1 pin 1 (front centre, ahead of the condenser) pin 1	2000	ST185-EngineRoom-C	TAM
	w_acsg_a32	20	Blue	⬜🟨⬜	Auto A/C sensor common	OEM auto A/C sensor common cowl lead (firewall, cabin side): Y from IQ3 pin 1 to old splice ...	200	ST185-EngineRoom-C	ACSG
	w_acsg_a24	20	Blue	⬜🟨⬜	Auto A/C sensor common	OEM auto A/C sensor common cowl lead (firewall, cabin side): Y from IJ1 pin 5 to old splice E...	200	ST185-EngineRoom-C	ACSG
	w_acsg_i8	20	Blue	⬜🟨⬜	Auto A/C sensor common	OEM auto A/C sensor common cowl lead (firewall, cabin side): Y from splice I8 to old splice E...	200	ST185-EngineRoom-C	ACSG

SP-ACC-85 - A/C clutch relay coil- net: ECU B10, k_acc 85 and the A/C switch lamp

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_acc_trig	18	White	🟨🟦	A/C clutch relay (-)	ECU-B (Link G4X plug B, centre dash) pin 10	420	ST185-AB-cabin	ACC
	w_acc85	18	White	🟨🟦	A/C clutch relay (-)	A/C Clutch Relay (on/off) (seated in the LOGIC box M5) - ACTIVE-LOW - ECU sinks coil- (85)...	460	ST185-AB-cabin	ACC
	w_ac_lamp	20	White	🟨🟦	A/C switch lamp sink	OEM A/C amplifier A15 plug pin 1, R-Y lead (amp removed, behind the glove box) pin 1	600	ST185-AB-cabin	ACC

SP-ACPS - ACPS 10 A fuse out (outside the POWER box): A5 pressure switch feed and the A/C switch V-R feed

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_acps_out	18	Red	🟦🟨⬜	ACPS 10 A fuse out	POWER box with the bus bar in it - custom fuse + relay box, glove box outboard (cad/fusebox...	200	ST185-CabinPower	ACPS
	w_ac_sw_feed	18	Red	🟦🟨⬜	A/C switch feed (V-R)	OEM old R/B4 10 A A/C fuse lead, load side (RH kick), V-R pin fuse terminal 2	450	ST185-CabinPower	ACPS
	w_acp_1	18	Yellow	🟦🟨⬜	A/C press sw feed	A/C pressure switch A5 pin 1 (2-pin dual pressure switch on Dan's car) pin 1	1350	ST185-EngineRoom-C	ACPS

SP-AT-12V - Alarm +12 V splice - LOGIC ALM 5A fuse to alarm pin 1

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_at_12v_tie_cp	20	Red	🟨⬜🟨	AMI BUS1 50 A fuse -> LOGIC ALM 5 A fuse	LOGIC box - custom fuse + relay box, glove box inboard (cad/fusebox rev 5, DECISIONS R7...	860	ST185-CabinPower	ALM
	w_at_12v	20	Red	🟨⬜🟨	AMI BUS1 50 A fuse -> LOGIC ALM 5 A fuse	Alarm module - main harness (DT06-12SA) pin 1	200	ST185-AntiTheft	ALM

SP-CAM - At the ECU plugs - SP-CAM: cam signal + 1.8k pull-up to +8V

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_trig2_pin	20	White	🟦🟦🟨	Cam sensor signal	Link G4X plug A (centre dash) pin 9	310	ST185-AB-cabin	CAM
	w_cam_sig_c	20	White	🟦🟦🟨	Cam sensor signal	DRB102 receptacle (RH firewall) pin 64	520	ST185-AB-cabin	CAM
	w_cam_pullup_sig	20	White	🟦🟦🟨	Cam pull-up 1.8k	Cam pull-up 1.8 k to +8 V pin 2	200	ST185-AB-cabin	CAM

SP-CAN-SH-BH - CAN trunk, bulkhead B branch - SP-CAN-SH-BH: CAN screen to CAN-Lambda

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	cab_canbh_bc_sh		Shield	🟨	CAN-Lambda shield	DRB102 receptacle (RH firewall) pin 81	680	ST185-AB-cabin	CAN
	w_shd_can_bh	20	Black	🟨	CAN screen trunk	CAN trunk, cluster branch - SP-CAN-SH-CLU: CAN screen	600	ST185-CAN	CAN

SP-CAN-SH-CLU - CAN trunk, cluster branch - SP-CAN-SH-CLU: CAN screen

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_shd_can_trunk	20	Black	🟨	CAN screen trunk	ECU Comms/Tuning Port pin 1	650	ST185-CAN	CAN
	cab_can_ecu_sh		Shield	🟨	ECU CAN shield	cab_can_ecu screen (floats at the device end)	650	ST185-CAN	CAN
	cab_can_clu_sh		Shield	🟨	Cluster CAN shield	cab_can_clu screen (floats at the device end)	200	ST185-CAN	CAN
	w_shd_can_csb	20	Black	🟨	CAN screen trunk	CAN trunk, CSB3 branch - SP-CAN-SH-CSB: CAN screen	1020	ST185-CAN	CAN
	w_shd_can_bh	20	Black	🟨	CAN screen trunk	CAN trunk, bulkhead B branch - SP-CAN-SH-BH: CAN screen to CAN-Lambda	600	ST185-CAN	CAN

SP-CAN-SH-CSB - CAN trunk, CSB3 branch - SP-CAN-SH-CSB: CAN screen

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	cab_can_csb_sh		Shield	🟨	CSB3 CAN shield	cab_can_csb_csb screen (floats at the device end)	200	ST185-CAN	CAN
	w_shd_can_csb	20	Black	🟨	CAN screen trunk	CAN trunk, cluster branch - SP-CAN-SH-CLU: CAN screen	1020	ST185-CAN	CAN
	w_shd_can_rd	20	Black	🟨	CAN screen trunk	CAN trunk, RealDash Pi branch - SP-CAN-SH-RD: CAN screen	870	ST185-CAN	CAN

SP-CAN-SH-RD - CAN trunk, RealDash Pi branch - SP-CAN-SH-RD: CAN screen

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	cab_can_rd_sh		Shield	🟨	Pi CAN shield	cab_can_rd screen (floats at the device end)	200	ST185-CAN	CAN
	w_shd_can_rd	20	Black	🟨	CAN screen trunk	CAN trunk, CSB3 branch - SP-CAN-SH-CSB: CAN screen	870	ST185-CAN	CAN

SP-CANH - CAN H join - ECU, CSB3, cluster, Pi, bulkhead

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	wc_h_bh_bc	20	White	🟨	CAN H to CAN-Lambda	DRB102 receptacle (RH firewall) pin 79	680	ST185-AB-cabin	CAN
	wc_h_ecu	20	White	🟨	CAN 1 high	ECU Comms/Tuning Port pin 3	250	ST185-CAN	CAN
	wc_term1	20	Green	🟨	ECU 120R CAN H	r_term_ecu pin 1	200	ST185-CAN	CAN
	wc_h_csb	20	White	🟨	CAN H to CSB3	ECUMaster CSB3 - Power/CAN/Switch I/O pin 5	620	ST185-CAN	CAN
	wc_h_clu	20	White	🟨	CAN H to cluster	Cluster CAN board CANH + CANL pins (old meter spot)	600	ST185-CAN	CAN
	wc_h_rd	20	White	🟨	CAN H to RealDash Pi	Pi USB-CAN adapter CANH + CANL pins (center dash)	450	ST185-CAN	CAN

SP-CANH-LAM - CAN H join - bulkhead, Lambda, 120 ohm end

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	wc_h_lam_be	20	White	🟨	CAN H to CAN-Lambda	BULKHEAD pin 79	440	ST185-AB-engine	CAN
	wc_term3	20	Green	🟨	Lambda 120R CAN H	r_term_end pin 1	200	ST185-CAN	CAN
	wc_h_lam_pin	20	Green	🟨	CAN H to CAN-Lambda	Link CAN-Lambda pin 4	350	ST185-CAN	CAN

SP-CANL - CAN L join - ECU, CSB3, cluster, Pi, bulkhead

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	wc_l_bh_bc	20	Green	🟨	CAN L to CAN-Lambda	DRB102 receptacle (RH firewall) pin 80	680	ST185-AB-cabin	CAN
	wc_l_ecu	20	Green	🟨	CAN 1 low	ECU Comms/Tuning Port pin 4	250	ST185-CAN	CAN
	wc_term2	20	Green	🟨	ECU 120R CAN L	r_term_ecu pin 2	200	ST185-CAN	CAN
	wc_l_csb	20	Green	🟨	CAN L to CSB3	ECUMaster CSB3 - Power/CAN/Switch I/O pin 6	620	ST185-CAN	CAN
	wc_l_clu	20	Green	🟨	CAN L to cluster	Cluster CAN board CANH + CANL pins (old meter spot)	600	ST185-CAN	CAN
	wc_l_rd	20	Green	🟨	CAN L to RealDash Pi	Pi USB-CAN adapter CANH + CANL pins (center dash)	450	ST185-CAN	CAN

SP-CANL-LAM - CAN L join - bulkhead, Lambda, 120 ohm end

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	wc_l_lam_be	20	Green	🟨	CAN L to CAN-Lambda	BULKHEAD pin 80	440	ST185-AB-engine	CAN
	wc_term4	20	Green	🟨	Lambda 120R CAN L	r_term_end pin 2	200	ST185-CAN	CAN
	wc_l_lam_pin	20	Green	🟨	CAN L to CAN-Lambda	Link CAN-Lambda pin 3	350	ST185-CAN	CAN

SP-CHASSIS-ENG - Coil ground splice - ignition coils 1-4 to the engine block ground stud

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_cop1g	18	Black	⬜🟨🟨	Coil 1 ground	COP 1 (1ZZ) pin 4	820	ST185-AB-engine	COP1
	w_cop2g	18	Black	⬜🟨⬜	Coil 2 ground	COP 2 (1ZZ) pin 4	640	ST185-AB-engine	COP2
	w_cop3g	18	Black	⬜⬜🟨	Coil 3 ground	COP 3 (1ZZ) pin 4	460	ST185-AB-engine	COP3
	w_cop4g	18	Black	⬜⬜⬜	Coil 4 ground	COP 4 (1ZZ) pin 4	300	ST185-AB-engine	COP4
	w_eng_gnd	10	Black	🟦🟨🟨	Coil ground	Engine block ground stud (RADLOK engine ground, H6), M6 ring	500	ST185-AB-engine	EGND

SP-CLR - Clearance feed split - F7 LH + F8 RH

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_clr	16	Red	⬜	Clearance lamp feed	OEM J/B No.1 1H pin 6 (left kick) pin 1H-6	3680	ST185-EngineRoom-C	CLR
	w_clr_f7	16	Red	⬜	LH clearance +	LH front turn / clearance lamp F7 pin 1 pin 1	900	ST185-EngineRoom-C	CLR
	w_clr_f8	16	Red	⬜	RH clearance +	RH front turn / clearance lamp F8 pin 1 pin 1	900	ST185-EngineRoom-C	CLR

SP-COP-ENG - Coil +12 V splice - BH-A pin 1 (LOGIC COP 15A) to coils 1-4

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_cop_pwr_e_ae	12	Red	🟦⬜🟨	EFI relay k_efi -> LOGIC COP 15 A fuse	BULKHEAD pin 1	500	ST185-AB-engine	COP
	w112	16	Red	🟦⬜🟨	EFI relay k_efi -> LOGIC COP 15 A fuse	COP 1 (1ZZ) pin 1	820	ST185-AB-engine	COP
	w113	16	Red	🟦⬜🟨	EFI relay k_efi -> LOGIC COP 15 A fuse	COP 2 (1ZZ) pin 1	640	ST185-AB-engine	COP
	w114	16	Red	🟦⬜🟨	EFI relay k_efi -> LOGIC COP 15 A fuse	COP 3 (1ZZ) pin 1	460	ST185-AB-engine	COP
	w115	16	Red	🟦⬜🟨	EFI relay k_efi -> LOGIC COP 15 A fuse	COP 4 (1ZZ) pin 1	300	ST185-AB-engine	COP

SP-CRUISE-LADDER - Cruise ladder splice - stalk pin 5, 1k pull-up and CSB3 A2

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_an2	20	Yellow	🟦	Cruise ladder	OEM cruise stalk switch C14 pin 5, W wire pin 5	1220	ST185-CSB3	CRUISE
	w_cru_sig	20	Yellow	🟦	Cruise ladder	r_cruise pin 2	200	ST185-CSB3	CRUISE
	w_cru_ladder_out	20	Yellow	🟦	Cruise ladder	ECUMaster CSB3 - Power/CAN/Switch I/O pin 8	200	ST185-CSB3	CRUISE

SP-CSB-5V - CSB3 +5V: opto board VCC and the evap thermistor pull-up

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_opto_vcc	20	Orange	🟨🟦	Opto +5 V	Optocoupler board, 8 channel (Dan's, generic EL814) - inline at the CSB3 pin VCC	200	ST185-CSB3	OPTO
	w_evap_5v	20	Orange	⬜🟦🟦	+5 V evap pull-up	3.9k 1 % evap thermistor pull-up to the CSB3 +5V pin 2	200	ST185-CSB3	EVAP
	w_csb_5v	20	Orange	🟨🟦🟦	CSB3 +5V out	ECUMaster CSB3 - Power/CAN/Switch I/O pin 3	200	ST185-CSB3	CSB

SP-CSB-GND - CSB3 ground splice - CSB3 pin 2, opto board COM and stalk ground

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_csbg_ac	20	Black	🟨🟦🟦	CSB3 + opto ground	POWER box NEG bar M8 stud (glove box)	1050	ST185-AB-cabin	CSB
	w_csbg	20	Black	🟨🟦🟦	CSB3 ground	ECUMaster CSB3 - Power/CAN/Switch I/O pin 2	200	ST185-CSB3	CSB
	w_cru_gnd	20	Blue	🟨🟦🟦	Cruise stalk ground	OEM cruise stalk switch C14 pin 17, BR wire pin 17	1220	ST185-CSB3	CSB
	w_opto_inc	20	Black	🟨🟦🟦	Opto COM ground	Optocoupler board, 8 channel (Dan's, generic EL814) - inline at the CSB3 pin COM1	200	ST185-CSB3	CSB

SP-CSB-SGND - CSB3 sensor ground: opto board NEG and the evap thermistor return

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_opto_outc	20	Black	🟨🟦	Opto out ground	Optocoupler board, 8 channel (Dan's, generic EL814) - inline at the CSB3 pin NEG	200	ST185-CSB3	OPTO
	w_evap_rtn	20	Blue	⬜🟦🟦	Evap thermistor return	OEM A/C thermistor A24 pin 1, W-R lead (at the evaporator case) pin 1	1240	ST185-CSB3	EVAP
	w_csb_sgnd	20	Blue	🟨🟦🟦	CSB3 sensor ground	ECUMaster CSB3 - Power/CAN/Switch I/O pin 4	200	ST185-CSB3	CSB

SP-DEV - Dash 12 V split - cluster + RealDash Pi, center dash

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_dev_cp	16	Red	🟨🟦🟨	EFI relay k_efi -> LOGIC DEV 15 A fuse	LOGIC box - custom fuse + relay box, glove box inboard (cad/fusebox rev 5, DECISIONS R7...	980	ST185-CabinPower	DEV
	w_dev_clu	16	Red	🟨🟦🟨	EFI relay k_efi -> LOGIC DEV 15 A fuse	Cluster buck converter IN+ pin (old meter spot)	850	ST185-CAN	DEV
	w_dev_rd	16	Red	🟨🟦🟨	EFI relay k_efi -> LOGIC DEV 15 A fuse	Pi 12-to-5 V supply IN+ pin (center dash)	200	ST185-CAN	DEV

SP-DOOR - Door trigger splice - door courtesy switches to alarm pin 6

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_at_door	20	Yellow	🟦🟦	Door trigger	Alarm module - main harness (DT06-12SA) pin 6	200	ST185-AntiTheft	DOOR
	w_at_door_tie	20	Yellow	🟦🟦	Door trigger	OEM door courtesy switch lead (tap spot and EWD page TBD)	1220	ST185-AntiTheft	DOOR

SP-EVAP-SIG - evap thermistor A24 pin 2, 3.9k pull-up and CSB3 A1

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_evap_sig	20	White	⬜🟦🟦	Evap thermistor signal	OEM A/C thermistor A24 pin 2, Y-G lead (at the evaporator case) pin 2	1240	ST185-CSB3	EVAP
	w_evap_pu	20	White	⬜🟦🟦	Evap pull-up 3.9k	3.9k 1 % evap thermistor pull-up to the CSB3 +5V pin 1	200	ST185-CSB3	EVAP
	w_evap_a1	20	White	⬜🟦🟦	Evap temp to CSB3 A1	ECUMaster CSB3 - Power/CAN/Switch I/O pin 7	200	ST185-CSB3	EVAP

SP-FUEL-LVL - fuel sender signal + 470R pull-up to ECU-B B24

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w_fl_sig	20	White	🟦🟨🟦	Fuel level signal	IX-FUEL inline to fuel sender lead (trunk end) pin 1	2820	ST185-AB-cabin	FLVL
	w_fl_sig_pin	20	White	🟦🟨🟦	Fuel level signal	ECU-B (Link G4X plug B, centre dash) pin 24	310	ST185-AB-cabin	FLVL
	w43	20	White	🟦🟨🟦	Fuel lvl pull-up	470R fuel level pull-up to +5V pin 1	200	ST185-AB-cabin	FLVL

SP-GND-ECU - ECU splice point - SP-GND-ECU: ECU power ground (A25 A34 B25 B34) to the NEG bar

splice: solder splice

PIN	WIRE	AWG	COLOUR	BANDS	SIGNAL	OTHER END	LEN MM	BUILT WITH	CIRCUIT
	w70	18	Black	🟨🟨⬜	ECU power ground	Link G4X plug A (centre dash) pin 25	310	ST185-AB-cabin	GND
	w_a34	18	Black	🟨🟨⬜	ECU power ground	Link G4X plug A (centre dash) pin 34	310	ST185-AB-cabin	GND
	w_b25_ac	18	Black	🟨🟨⬜	ECU power ground	ECU-B (Link G4X plug B, centre dash) pin 25	310	ST185-AB-cabin	GND
	w_b34_ac	18	Black	🟨🟨⬜	ECU power ground	ECU-B (Link G4X plug B, centre dash) pin 34	310	ST185-AB-cabin	GND
	w66	10	Black	🟨🟨⬜	ECU power ground	POWER box NEG bar M8 stud (glove box)	570	ST185-AB-cabin	GND

REVISIONS

REV	DATE	BY	DESCRIPTION
A	2026-10-20	DG	First issue: every harness of the master in one drawing set (replaces the ST185-AB-cabin pilot, R...

ST185-harness - every wiring harness of the car, one drawing set

Pinout tables - every pin of every connector, bus, splice and end

DRAWING NO.	REV	SHEET	SIZE	DRAWN	DATE
ST185-harness-PIN	A	1 OF 1	2159 x 1340 mm	DG	2026-10-20

ST185 Celica (living-relation) - generated by docs/harness/tools/build_drawings.py from docs/harness/MASTER-wirelist.csv; not to scale