## Contents

1 Installation Instructions

2

## 1 Installation Instructions

- 1. Download the latest Raspberry Pi image from https://www.raspberrypi.org/downloads/raspbian/
- 2. Mount the image according to the instructions for your system
- **3.** On the first boot follow the set-up instructions from the Raspberry Pi installer
  - a Set the localization to US
  - b Set a new password. Suggested:ortho-lab-169
  - c Connect to the Wi-Fi and update the system
- 4. Using a text editor go to the **boot** folder and open *config.txt* a The full path of the config file is: /boot/config.txt
- 5. add the line: dtoverlay=i2c-gpio,bus=3
- **6.** Save and close the file
- 7. Open the terminal
- 8. Run: git clone https://github.com/ljaworski88/sensirion-sf04-python.git
- 9. Go into the newly created folder and goto the src subfolder
  - a The folder should be in the home directory and is called **sensirion-sf04-python**
- 10. copy *i2c-gpio.dtbo* and move it to /boot/overlay replacing the old version
- 11. Restart the Raspberry Pi