

Trust Domain Extension (TDX) Migration TD Design Guide

October 2021



You may not use or facilitate the use of this document in connection with any infringement or other legal analysis concerning Intel products described herein. You agree to grant Intel a non-exclusive, royalty-free license to any patent claim thereafter drafted which includes subject matter disclosed herein.

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

Intel technologies' features and benefits depend on system configuration and may require enabled hardware, software or service activation. Performance varies depending on system configuration. No computer system can be absolutely secure. Check with your system manufacturer or retailer or learn more at intel.com.

Intel technologies may require enabled hardware, specific software, or services activation. Check with your system manufacturer or retailer.

The products described may contain design defects or errors known as errata, which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

All information provided here is subject to change without notice. Contact your Intel representative to obtain the latest Intel product specifications and roadmaps

Copies of documents that have an order number and are referenced in this document may be obtained by calling 1-800-548-4725 or visit www.intel.com/design/literature.htm.

Intel, the Intel logo, are trademarks of Intel Corporation in the USA and/or other countries.

*Other names and brands may be claimed as the property of others.

© 2021 Intel Corporation. All rights reserved.



Contents

1	Introd	luction		6
	1.1	Backgro	ound	6
	1.2	0	W	
	1.3		ology	
2	Migra	tion Archite	ectural Overview	a
2	_			
	2.1	_	ation Orchestration	
	2.2	•	ed in migration	
	2.3	MigID	General Flow	10
3	MigTE	Design O	verview	13
	3.1	Design (Overview	13
		3.1.1	MigTD design	13
		3.1.2	MigTD layout	14
		3.1.3	MigTD boot flow	14
	3.2	Reprodu	ucibility	15
		3.2.1	Challenge	15
		3.2.2	Solution	15
	3.3	Security	Consideration	16
		3.3.1	Type safe language	16
		3.3.2	Data Execution Protection (DEP)	16
		3.3.3	Address Space Layout Randomization (ASLR)	16
		3.3.4	Control Flow Enforcement Technology (CET)	16
		3.3.5	Side Channel	17
4	MigTE) Mutual A	uthentication	18
	4.1	Remote	Attestation TLS	18
	4.2	Attestat	ion Flow	18
	4.3	Trust Ar	nchor	21
	4.4	Certifica	ate Revocation List	21
	4.5		ite Structure	
	4.6		ort Data	
	4.7	•	ed TD Quote	
	4.8		Certificate	
	4.9	•	te API	
	4.5	4.9.1	Get TD Quote	
		_	Verify TD Quote	
5	ΜίσΤΓ) Migration	Policy	27
3	5.1	_	Policy Type	
	5.2		Policy Measurement	
	5.2	_	•	
	5.3	_	Policy Definition	
		5.3.1	MigTD Policy Format	
		5.3.2	MigTD Policy Fyample	
		5.3.3	MigTD Policy Example	



6	MigTD Network Communication				
	6.1	TDVMCA	LL	36	
		6.1.1	VSock information	36	
		6.1.2	VSock data payload	37	
7	MigTD) Cryptogra _l	ohy Capability	38	
	7.1	Cryptogr	aphy	38	
		7.1.1	Cryptography Algorithm		
		7.1.2	TLS Configuration		
	7.2	Random	Number Generation	39	
8	MigTD	Binary Ima	ge	40	
	8.1	Boot Firn	nware Volume (BFV)	40	
	8.2	Configur	ation Firmware Volume (CFV)	40	
9	MigTD	Launch		42	
	9.1	MigTD in	itialization	42	
	9.2	MigTD H	and-Off Block (HOB)	42	
	9.3	MigTD te	ardown	42	
	9.4	MigTD A	P handling	42	
10	MigTD	Measurem	ent	43	
	10.1	Non-Sec	ure Boot Mode	43	
	10.2	Secure B	oot Mode	43	
	10.3	MigTD Bi	nding	44	
11	MigTD	Metadata		45	
12	Multip	le TDs Migr	ation	46	
	12.1	Multi TD:	s Migration	46	
	12.2	Multi RA	-TLS connections	46	
		12.2.1	Multi destination MigTDs	46	
		12.2.2	Multi source MigTDs	47	
	12.3	Multi-Pro	ocessor	48	
Appendix A	Refere	ence		49	
Figures					
Figure 1-1: TI) Migrati	on		6	
			ration Flow		
Figure 2-3: M	igration [']	TD flow		12	
Figure 3-1: M	igration [•]	TD Design		14	
-	_)W		
-	-				
•	•		/		
Figure 4-3: TI	Report ک	structure		20	

Introduction



Figure 4-4: MigTD VerifyQuote Flow	20
Figure 4-4: MigTD VerifyQuote FlowFigure 6-1: VMCALL based communication in MigTD	36
Figure 7-2: MigTD TLS Configuration	38
Figure 12-1: Multiple TDs Migration	46
Figure 12-2: Multiple Destination Migration TDs	47
Figure 12-3: Multiple Source Migration TDs	47
Tables	
Table 4-1: MigTD Certificate Structure Table 4-2: MigTD OID Field Table 4-3: RA-TLS OID Field	21
Table 4-2: MigTD OID Field	22
Table 4-3: RA-TLS OID Field	23
Table 4-4: Open Enclave TLS OID Field	23
Table 5-1: MigTD Policy Type	27
Table 5-2: MigTD Policy Property	28
Table 7-1: MigTD Cryptography Algorithm	38
Table 8-1: MigTD Policy Data	40
Table 10-1: TD Measurement Registers for MigTD (Non-Secure Boot)	43
Table 10-2: TD Measurement Registers for MigTD (Secure Boot)	44
Tuble 10 2. 10 Picusurement Registers for Pilg 10 (Secure Bood)	



1 Introduction

1.1 Background

Analogous to VM migration, a cloud-service provider may want to relocate/migrate an executing Trust Domain (TD) from a **source Trust Domain Extension (TDX) platform** to a **destination TDX platform** in the cloud environment. A cloud provider may use TD migration to meet customer Service Level Agreement (SLA), while balancing cloud platform upgradability, patching and other serviceability requirements. A TD runs in a CPU mode that protects the confidentiality of its memory contents and its CPU state from any other platform software, including the hosting Virtual Machine Monitor (VMM). This primary security objective must be maintained while allowing the TD resource manager (the host VMM) to migrate TDs across compatible platforms. As the figure below shows, the TD typically will be assigned a different key (and will be always assigned a different ephemeral key) on the destination platform chosen to migrate the TD.

Figure 1-1 shows the TD Migration use case.




Figure 1-1: TD Migration

1.2 Overview

In this specification, the TD being migrated is called the **source TD**, and the TD created as a result of the migration is called the **destination TD**. An extensible **TD Migration Policy** is associated with a TD that is used to maintain the TD's security posture. The TD Migration policy is enforced in a scalable and extensible manner using a **Migration TD** (as known as **MigTD**) – which is used to



perform common functions for migrating TDs. TD Migration does NOT depend on any interaction with the TD guest software operating inside the TD being migrated.

TD contents is primarily protected and transferred by Intel TDX module using a **Migration Session Key (MSK)** used only for a unique Migration session for a TD.

A Migration TD (MigTD) is used to:

- 1. Evaluate potential migration sources and targets for adherence to the TD Migration Policy.
- 2. If approved, securely transfer a Migration Session Key from the source platform to the destination platform to migrate assets of a specific TD.

The host VMM need bind a MigTD to one (or more TDs) via a new **SEAMCALL [TDH.SERVTD.BIND]** or **SEAMCALL [TDH.SERVTD.PREBIND]**. The host VMM via the Intel TDX module is responsible for export/import of the TD content. The host VMM and existing untrusted SW stack responsible for migrating the encrypted TD content.

Since the MigTD is in the TCB of the TD being migrated, a MigTD must be pre-bound to the target TD being migrated before the target TD measurement is finalized. The MigTD lifecycle does not have to be coincidental with the target TD. The MigTD may be instantiated when required for Live Migration, and must be bound to the target TD before Live Migration can begin. MigTD must be operational until the MSK has been successfully programmed for the target TD being migrated.

Figure 1-2 shows the TD Migration Architecture.




Figure 1-1: TD Migration Architecture

The full TD migration can be found at TDX TD Migration specification. This document only describes the software architecture for Migration TD.



1.3 Terminology

Term	Description
GCM	Galois/Counter Mode
GKID	Guest Key ID
HKID	Host Key ID
НОВ	Hand-off Block
MigTD	Migration TD
MigTD-s	Migration TD on source platform
MigTD-d	Migration TD on destination platform.
МКТМЕ	Multi-Key Total Memory Encryption
MSK	Migration Session key
MTK	Migration Transport Key
PAMT	Physical Address Metadata Table
SEAM	Secure Arbitration Module
ТСВ	Trust Computing Base
TD	Trust Domain
TDVF	Trust Domain Virtual Firmware
TDX	Trust Domain Extension
TLS	Transport Layer Security
RA-TLS	Remote Attestation TLS
TME	Total Memory Encryption
VKMT	Virtual Key ID Mapping Table

§



2 Migration Architectural Overview

2.1 TD Migration Orchestration

Figure 2-1 shows the TD Migration Orchestration Flow.




Figure 2-1: TD Migration Orchestration Flow

Assuming a VM orchestrator manages Node A and Node B. The VM orchestrator decides to migration the TD in Node A to Node B. The Node A is migration source, and the Node B is migration destination. The component in Node A is named as module-s, where s means source, and the component in Node B is named as module-d, where d means destination.

The high level TD migration flow is below:

- 1) The VM orchestrator selects node B as the migration destination.
- 2) The VMM-d in Node B notifies the MigTD-d to get ready for migration.
- 3) The VMM-s in Node A notifies the MigTD-s to negotiate the migration session.
- 4) MigTD-s and MigTD-d negotiate with each other, including mutual attestation, Migration Policy evaluation, negotiate Migration Transport Keys (MTK) and exchange the Migration Session Key (MSK).
- 5) MigTD-s provision MSK to TDX module in source platform. MigTD-d provision MSK to TDX module in destination platform.



- 6) TD-s in Node A is migrated to TD-d in Node B, with help of VMM and QEMU.
- 7) TD-s is teardown by the VMM-s.
- 8) TD-d is resumed by the VMM-d.
- 9) The migration is done. The orchestrator refreshes the TD information.

2.2 Keys used in migration

Two types of keys are used in MigTD.

- Migration Transport Keys (MTK): They are a set of keys generated during MigTD negotiation between source platform and destination platform. We call MigTD on source platform as MigTD-s, and MigTD on destination platform as MigTD-d. These keys are used to protect the communication message between MigTD-s and MigTD-d. If MigTD-s and MigTD-d use a network Transport Layer Security (TLS) protocol to set up a secure session, then the MTKs are the TLS session keys.
- Migration Session Key (MSK): An AES-256-GCM key generated by MigTD-s and shared with MigTD-d. The GCM key is protected by the MTK when it is transported from MigTD-s to MigTD-d. The MSK is transferred to TDX-Module by TDCALL<TDG.SERVTD.WR>, and is used to protect the data migration between TDX-Module-s and TDX-Module-d. The MSK protects the TD private data and is used for export and import of the TD confidential assets.

Figure 2-1 shows the keys used in migration setup.




Figure 2-2: Migration Key Setup

2.3 MigTD General Flow

A MigTD can be launched by VMM at any time, when VMM starts migration. Once the MigTD transfers the MSK to TDX module, the MigTD can be tear down.


See below as a typical flow:



- [MigTD-s/MigTD-d] are launched by VMM, when VMM starts migration.
- The host VMM binds a [MigTD-s/MigTD-d] to one (or more TDs) via a new **SEAMCALL** [TDH.SERVTD.BIND]. It gets back a binding handle. The binding handle will be part of input parameter for the migration information.
- [MigTD-s/MigTD-d] build secure channel to each other, e.g. via remote attestation TLS (RA-TLS) protocol.
 - [MigTD-s/MigTD-d] communicate with each other via network interface, such as a Virtlo-socket interface.
 - [MigTD-s/MigTD-d] generate local QUOTE via TDG.VP.VMCALL<GET_QUOTE> and pass the QUOTE to the peer in the TLS certificate.
 - [MigTD-s/MigTD-d] do mutual authentication, via peer QUOTE attestation.
 - Once RA-TLS authentication is done, [MigTD-s/MigTD-d] can derive a set of TLS session keys as the Migration Transport Keys (MTK). Then the secure channel is set up.
- [MigTD-s/MigTD-d] check the Migration Policy.
 - Within the secure session, [MigTD-s/MigTD-d] can check the Migration Policy to see if the peer is allowed to migrate.
- [MigTD-s/MigTD-d] setup Migration Session key (MSK)
 - [MigTD-s] generates MSK and transfers to peer via the secure channel.
 - [MigTD-d] receives MSK from peer.
 - [MigTD-s/MigTD-d] set MSK via TDCALL<TDG.SERVTD.WR>
- [MigTD-s/MigTD-d] can be tear down.



Figure 2-2 shows the general Migration TD flow.






Figure 2-3: Migration TD flow

§



3 MigTD Design Overview

3.1 Design Overview

Migration TD is a lightweight bare-metal service TD. Because MigTD is in TCB, the code in MigTD should be as minimal as possible.

3.1.1 MigTD design

Figure 3-1 shows the design of MigTD. It includes a shim layer and a core.

- TdShim is a generic shim layer to boot any service TD, as a transient environment.
 - TdShim includes a Reset Vector that is the first instruction when a VMM launches a TD.
- Core is the Migration TD runtime execution environment.
 - Crypto and TLS are used to establish a secure communication session. It should reuse the existing known good crypto library and TLS configuration including version and cipher suite.
 - VSocket is a way to pass the TLS packet to the VMM and leverage the VMM network stack to communicate with peer MigTD.
 - VMM communication should follow the Guest-Host Communication Interface (GHCI) specification.
 - Quote Attestation service is used for the mutual authentication in Remote-Attestation TLS.
 - Migration Policy is used to evaluate the migration peer according to the predefined policy.






Figure 3-1: Migration TD Design

3.1.2 MigTD layout

Figure 3-2 shows the build time layout and runtime layout.

The left-hand side shows the build time layout. The Boot Firmware Volume (BFV) include the TdShim and migration core.

The right-handle side shows the runtime layout. The TdShim should be loaded to the top of 4GB memory where the reset vector sits. Then the TdShim will relocate the MigTD core to low memory space and setup x64 long mode environment. This approach is highly recommended because the top of 4GB is usually mapped to a flash device. Executing code in flash device may bring some special restriction even in virtualization environment. All reset additional memory below the top of memory (TOM) can be used as heap, and the stack can be allocated from the heap. Avoid using the memory below 1MB, because the top of 1MB is also mapped to legacy flash ROM.




Figure 3-2: Migration TD Layout

3.1.3 MigTD boot flow

Figure 3-3 shows the Migration TD boot flow.

- ResetVector in TdShim. The reset vector code should park all application processors (APs)
 to a known place and only let bootstrap processor (BSP) to initialize the environment. The
 BSP should switch to long mode, setup stack and jump to the TdShim initial program loader
 (IPL).
- 2. IPL in TdShim. When TdShim is launched, it should get the memory information internally, such as metadata area. Then it accepted the TD memory and set up all required protection such as data execution prevention (DEP). The final step is to find the MigTD core, load it to low memory and jump to the MigTD core.



- **3. Entrypoint of MigTD Core**. The MigTD should initialize the final execution environment including heap and interrupt vector etc. It should also initialize the virtio-socket driver to prepare the communication with VMM.
- 4. MigTD Core runtime. The MigTD should set up secure communication session with peer MigTD. MigTD should send and receive the TLS packet via network socket interface, such as Virtlo-socket. After the secure session is established, the MigTD-s will generate the Migration Session key and pass to MigTD-d. Then both MigTD can pass the key to the TDX module. After that, the MigTD can tear down.




Figure 3-3: Migration TD Boot Flow

3.2 Reproducibility

A service TD binary should be reproducible, meaning you can recreate the same **service-TD release binary**, with the same service-TD source code version and same compiler version. This condition should be true under any circumstances, anytime, on any machine, and any source path location.

3.2.1 Challenge

We are aware of challenges today. For example, some code may use __FILE__, __LINE__, __DATE__, __TIME__ as the build-in information. The __FILE__ may change based upon the file location. __DATA__ and __TIME__ may change based upon the build time.

The compiler may generate debug entry, including file path. The compiler may generate time stamp on when the binary is created. In addition, the compiler may include unique GUID to provide detailed debugging information.

Refer to Microsoft PE/COFF specification.

3.2.2 Solution

To resolve above challenge, we have below recommendation:



3.2.2.1 Code

The code should use __FILE__, __LINE__, __DATE__, __TIME__ only for debug purpose.

If present, the info should be included in DEBUG macro and removed in release build.

3.2.2.2 Compiler Option

Don't generate any debug info in release build.

3.2.2.3 Additional tools

The additional tool should be created to zero the debug data fields in the PE image, and zero the time stamp and unique GUID.

For example, EDKII project includes a `GenFW` tool that has -z, --zero option to zero such information.

3.3 Security Consideration

3.3.1 Type safe language

The MigTD should consider use type safe language, such as Rust programming language to eliminate memory safety issue.

3.3.2 Data Execution Protection (DEP)

The MigTD should set up DEP to mark data region (including stack and heap) to be non-executable, and code region be read-only, to prevent code injection attack.

3.3.3 Address Space Layout Randomization (ASLR)

The MigTD should use ASLR for the heap / stack allocation. The effectiveness of ASLR is based upon random bit entropy. To be realistic, if the MigTD only has limited memory resource, then the entropy bit cannot be too large. But we can at least shift some bits, which is better than nothing.

3.3.4 Control Flow Enforcement Technology (CET)

3.3.4.1 Backward Control Flow

The MigTD should set up CET Shadow Stack (SS) protection to prevent Return Oriented Programming (ROP) attack.



3.3.4.2 Forward Control Flow

The MigTD should set up CET Indirect Branch Tracking (IBT) to prevent a Jump Oriented Programming (JOP) attack, depending upon the compiler's capability. See [rust CET].

3.3.5 Side Channel

The MigTD should also consider side-channel attack to steal the MSK or MTK.

3.3.5.1 Bound Check Bypass

The MigTD should use LFENCE before parsing any VMM input data, because the negotiated key is secret.

3.3.5.2 Branch Target Injection

The MigTD should use Indirect Branch Predictor Barrier (IBPB) by WRMSR(IA32_PRED_CMD.IBPD), which is needed in an RA-TLS context switch if a migration TD supports multiple TLS connections.

3.3.5.3 Rogue Data Cache load

N/A. MigTD is a bare metal execution environment. All code runs in supervisor mode.

3.3.5.4 Rogue System Register load

N/A.

3.3.5.5 Speculative Store Bypass

N/A.



4 MigTD Mutual Authentication

Two MigTDs use mutual authentication to verify each other when they build the secure communication channel.

4.1 Remote Attestation TLS

The network TLS protocol is a standard to allow two entities create a secure session. A typical mutual authentication in TLS requires X.509 certificate provision. However, it is hard to provision a private key to MigTD. A way to resolve this problem is to use remote attestation TLS (RA-TLS).

RA-TLS does note require private key or public certificate provision. The MigTD can generate a keypair at runtime and include the public key in the TD report data and TD quote data. Then the MigTD generates an X.509 certificate at runtime, includes the TD Quote in the X.509 certificate, and send this TD certificate to peer as the TLS certificate. When the peer MigTD receives the certificate, it gets the TD Quote, verifies the Quote, then it can trust the public key. Finally, the peer MigTD can use the public key to verify rest TLS messages.

Figure 4-1 shows the MigTD with RA-TLS.




Figure 4-1: MigTD with RA-TLS

For more detail of RA-TLS, refer to [Intel RA-TLS] or [Open Enclave RA-TLS].

4.2 Attestation Flow

The MigTD attestation flow is similar to the normal TD attestation flow. Figure 4-2 shows the flow to get TD Quote in MigTD.






Figure 4-2: MigTD GetQuote Flow

With step 1~4, the MigTD gets a TDREPORT for itself. The integrity of TDREPORT is guaranteed by the REPORTMACSTRUCT, which is MACed with TDX CPU with a unique MAC key. Figure 4-3 shows the TDREPORT structure.

In step 5~6, the MigTD uses the TDG.VP.VMCALL<GetQuote> and try to get the Quote from the Quoting Enclave (QE).

In step 7~8, the QE verifies the MAC of the TD report with the TDX CPU. This verification is needed because Quoting is requested from the VMM and is not trusted.

In step 9~10, if the verification passed, then the QE signs the TDREPORT with its attestation key to generate the TD QUOTE and returns it to the MigTD via the VMM.

Now the MigTD can include the TD Quote in the TLS certificate and send to peer.






Figure 4-3: TD Report structure

Once the MigTD receives the TLS certificate from the peer, it extracts the TD Quote from the TLS certificate, and verifies integrity of the TD Quote.




Figure 4-4: MigTD VerifyQuote Flow



4.3 Trust Anchor

The Quote is signed by the Attestation Key by the Quoting Enclave (QE). The Attestation Key Certificate is signed with the Provision Certification Key (PCK) by Provision Certification Enclave (PCE), and the PCK certificate is signed with Intel root CA Certificate. See Figure 4-4.

MigTD shall enroll the Intel Root CA certificate. And the Intel Root CA certificate shall be measured as part of migration policy.

4.4 Certificate Revocation List

Besides Root CA certificate, the verification process shall also include the check for the revoked certificate. See Figure 4-4.

MigTD shall enroll the Certificate Revocation List (CRL). And the Certificate Revocation List (CRL) shall be measured as part of migration policy.

4.5 Certificate Structure

The TD Quote Certificate shall be generated as an DER-encoded X.509 v3 format certificate. See table 4-1.

Table 4-1: MigTD Certificate Structure

Certificate Field

Field	Description	Required
Version	Version of the encoded certificate shall be present and shall be version 3 (value 0x2)	Mandatory
Serial Number	Serial number shall be present with a positive integer value.	Mandatory
	For example: Serial Number: 1	
Signature Algorithm	Signature algorithm shall be present.	Mandatory
	For example: sha384WithRSAEncryption	
Issuer	Issuer distinguished name shall be specified.	Mandatory
	For example: "CN=MigTD SDK, O=mbed TLS, C=US"	
Subject Name	Subject name shall be present and shall represent the distinguished name associated with the certificate.	Mandatory
	It shall be same as Issuer.	



	T	
Validity	Certificate may include this attribute. If the validity attribute is present, the value for notBefore field should be assigned the generalized 19700101000000Z time value and notAfter field should be assigned the generalized 99991231235959Z time value.	Mandatory
Subject Public Key Info	Device public key and the algorithm shall be present. For example:	Mandatory
	Public Key Algorithm: rsaEncryption	
	Modulus:	
	Exponent: 65537 (0x10001)	
X509v3 Extension:	CA: FALSE.	Optional
Basic Constraints		
X509v3 Extension:	Subject Key Identifier	Optional
Subject Key Identifier		
X509v3 Extension:	It should be same as Subject Key Identifier.	Optional
Authority Key Identifier		
X509v3 Extension:	MigTD Quote Certificate indicator	Mandatory
Extended Key Usage	" 1.2.840.113741 .1.5.5.1.1" - Intel	

4.6 TD Report Data

During MigTD attestation, a pair of asymmetric keys will be generated. The public key hash (SHA384) is treated nonce for TD report data.

4.7 OID based TD Quote

The MigTD Quote report is X509v3 Extension OID based data.

Table 4-2: MigTD OID Field

MigTD OID Field



Field	Description	Required
OID: MigTD_quote_report	Quote Report	Mandatory
	" 1.2.840.113741 .1.5.5.1.2" - Intel	
OID:	EventLog Report	Mandatory
MigTD_event_log	" 1.2.840.113741 .1.5.5.1.3" - Intel	,

NOTE: Current RA-TLS and OpenEnclave are using below fields.

Table 4-3: RA-TLS OID Field

RA-TLS OID Field

KA-1E3 OID Fletd				
Field	Description	Required		
OID:	Attestation Report. ias_report	Mandatory		
ias_response_body_oid	" 1.2.840.113741 .1337.2" - Intel			
OID: ias root cert oid	Attestation Report. ias sign ca cert	Mandatory		
	"1.2.840.113741.1337.3" - Intel	,		
OID: ias leaf cert oid	Attestation Report. ias sign cert	Mandatory		
	" 1.2.840.113741 .1337.4" - Intel	ĺ		
OID:	Attestation Report, ias report signature	Mandatory		
ias_report_signature_oid	" 1.2.840.113741 .1337.5" - Intel	,		

Table 4-4: Open Enclave TLS OID Field

Open Enclave OID Field

Field	Description	Required
OID: oe_report	Quote Report	Mandatory
	" 1.2.840.113556 .10.1.1" - Microsoft	
OID: oe_evidence	Attestation Report	Mandatory
	" 1.2.840.113556 .10.1.2" - Microsoft	



4.8 Sample Certificate

A sample structure is shown here assuming a minimum certificate structure. Field names and structure types match the ASN.1 names in PKCS #1 [RFC8017] and PKCS #7 [RFC2315].

```
Certificate:
  Data:
    Version: 3 (0x2)
    Serial Number: 1 (0x1)
    Signature Algorithm: sha256WithRSAEncryption
    Issuer: CN = 127.0.0.1, O = mbed TLS, C = UK
    Validity
      Not Before: Jan 1 00:00:00 2001 GMT
      Not After: Dec 31 23:59:59 2030 GMT
    Subject: CN = 127.0.0.1, O = mbed TLS, C = UK
    Subject Public Key Info:
      Public Key Algorithm: rsaEncryption
        RSA Public-Key: (3072 bit)
        Modulus:
          00:a7:f5:93:01:2d:c9:d6:c6:11:ca:1c:0e:ab:31:
          cf:51:6d:81:f6:8c:49:bc:49:ee:c2:6d:da:6c:01:
          1a:2d:d0:fb:23:f2:c9:c9:9b:4b:47:47:5b:96:f2:
          fa:00:bb:f9:a8:af:7f:73:1f:9d:c9:c7:73:88:3e:
          c1:98:a4:87:54:db:8b:43:bb:c1:57:76:9f:a5:d0:
          1c:d6:25:bc:a2:5b:fa:cd:20:ef:bd:bd:c0:13:ac:
          74:ef:a8:58:14:33:49:0f:9b:b5:f2:6f:3f:8c:ac:
          42:b3:8e:a2:03:6d:7a:dc:77:b6:fc:02:87:d6:cb:
          f2:43:99:c4:75:d9:a6:98:3b:96:2b:aa:c5:3d:3d:
          36:92:c5:e5:30:84:78:db:b4:a6:83:6a:20:ca:08:
          2b:00:c8:49:50:b4:ce:ad:e6:66:79:44:c4:79:40:
          51:62:b5:79:60:e8:56:53:88:a3:47:71:5a:49:c3:
          1d:de:31:c6:2b:96:f8:19:c3:4b:d1:c8:fa:c5:0c:
          e4:ce:c3:68:89:4b:b3:64:e6:3e:70:e8:1c:3f:8e:
          b2:08:7d:ab:50:9d:8b:f6:1f:85:85:eb:06:80:2d:
          f8:74:0f:0e:c2:93:9b:f4:6d:34:3f:54:1b:93:27:
          be:48:c1:0f:de:49:70:44:2e:ad:05:26:ca:cf:23:
          6d:62:7f:72:c6:e3:51:27:be:d5:ee:b5:8d:72:ce:
          b6:a7:50:ea:0f:38:99:4e:db:f8:3f:ee:81:e7:11:
          5a:b0:70:f4:31:f4:47:88:53:1d:9b:b9:6d:87:68:
          71:e0:79:34:bc:da:79:04:f9:fc:9c:66:a2:7b:09:
          e4:d4:19:90:cd:2b:0a:f8:64:f1:92:c0:da:0f:d0:
          e9:9e:1f:71:2d:fb:56:5c:53:ab:13:99:e7:36:ff:
          a6:47:d4:c8:3a:22:75:a6:b7:c8:a8:da:b9:0f:64:
          21:d4:e1:0e:c2:76:ce:84:e6:48:5d:9b:3d:7d:08:
          d0:4b:b1:fe:60:c4:db:c3:2b:4f
        Exponent: 65537 (0x10001)
    X509v3 extensions:
      X509v3 Basic Constraints:
        CA:FALSE
      X509v3 Subject Key Identifier:
```



E0:F1:C8:11:40:8D:3A:24:C1:9C:FA:B9:31:17:08:60:2E:E3:2A:1A X509v3 Authority Key Identifier: keyid:E0:F1:C8:11:40:8D:3A:24:C1:9C:FA:B9:31:17:08:60:2E:E3:2A:1A

1.2.840.113741.1337.2: report 1.2.840.113741.1337.3: cacert 1.2.840.113741.1337.4: signed 1.2.840.113741.1337.5:

Signature Algorithm: sha256WithRSAEncryption 33:8d:62:27:78:0c:f8:4c:24:6f:11:37:5f:54:fd:3e:8d:c4: 93:a9:31:ff:0e:f8:f9:88:6c:92:e2:b2:e8:d3:53:26:bd:b8: 03:fc:15:e6:8f:55:e4:7a:06:77:18:87:5d:57:dc:69:dd:e8: 45:5a:db:22:5b:73:ab:e8:b1:0c:b3:4c:00:d5:07:22:28:cb: 7b:7c:87:19:5f:bc:9d:c5:28:b6:ac:e9:9e:c1:21:54:51:bc: 86:d0:b2:1a:41:9c:af:52:67:cc:4a:d7:3a:c1:c0:74:b8:68: bf:22:bf:32:2e:72:46:97:ba:ad:f8:77:25:a4:3e:f9:f9:49: 79:70:2d:a4:16:20:b1:f2:34:d9:90:0e:7b:e2:84:40:b2:99: 38:ce:40:4e:fc:94:1d:70:f5:93:93:a5:fa:26:42:7b:df:08: cf:de:3e:ca:b8:8f:ba:61:58:b0:57:8f:60:20:96:29:32:35: b3:19:e6:6b:e3:40:fc:02:04:97:6c:64:6c:7c:b6:95:48:24: a2:5a:70:0d:1f:a9:ba:d9:97:92:b3:9b:e7:46:a3:39:bf:76: d4:e6:85:62:cd:f2:86:49:b1:c0:04:db:a5:de:9d:da:68:59: 32:33:17:ff:94:78:77:ea:dd:f0:3f:45:d2:97:e1:cf:5b:58: 23:1e:6a:25:fc:ce:0e:89:d0:31:1b:f9:59:1a:34:4e:8a:bb: 57:2f:99:ec:f3:b2:41:ec:a2:58:60:63:0b:64:06:4b:51:5b: 4c:2f:fe:47:92:70:2d:4c:b2:d8:31:31:9d:5b:33:52:15:96: 6f:fb:4e:6e:f5:b0:39:07:f1:90:88:fd:d5:7a:71:a3:fc:cf: 15:ff:18:0c:15:0f:46:c6:4c:9a:dc:31:ce:7c:5c:81:19:9f: b5:53:22:d1:b9:5d:d1:f2:9b:46:9a:0f:b7:7d:cb:a0:6c:fc: e9:75:72:1d:df:35:f5:f7:2e:64:3c:75:5d:8c:ce:1d:18:98: 95:f7:30:96:57:c1

4.9 TD Quote API

4.9.1 Get TD Quote

In MigTD mutual authentication, the RA-TLS need get the TD Quote and put it OID:MigTD_quote_report and create a RA-TLS certificate around it.

4.9.2 Verify TD Quote

In MigTD mutual authentication, the peer will get the RA-TLS certificate and verify the integrity of the TD Quote. If the integrity verification fails, the TLS will be terminated.





NOTE: The MigTD policy verification is irrelevant in TD Quote attestation. MigTD policy verification will be the next step after MigTD mutual authentication. The migration session key (MSK) is passed after the MigTD policy verification.

§



5 MigTD Migration Policy

The MigTD need a set of migration policy to determine if it is allowed to migrate a TD from a source platform to a destination platform.

5.1 MigTD Policy Type

In general, there might be multiple types of policy:

Table 5-1: MigTD Policy Type

Туре	Policy Owner	Definition	Example	MigTD Action
TDX Module Policy (Required)	Intel	TDX Module Specification	TD Global Metadata Field: On export: MIG_VERSION is between [MIN_EXPORT_VERSION, MAX_EXPORT_VERSION] On import: MIG_VERSION is between [MIN_IMPORT_VERSION, MAX_IMPORT_VERSION] TDX_Module's MAJOR_VERSION/MINOR_VERSION is compatibility. TD's ATTRIBUTES/XFAM/CPUID is compatible. Reference: TDX Module Migration Specification.	MigTD optional checks it to detect error earlier. Code is extended to MRTD or RTMR[1] (See below).
MigTD Default Policy (Recommended)	CSP	MigTD Design Guide	MigTD is compatible. (SVN, MRTD, etc.) Certificate is valid and not expired. (Root CA certificate, certificate revocation list)	MigTD checks the migration policy. Policy Data is extended to RTMR[2]. (See below).
MigTD Extension Policy (Optional)	CSP	CSP Extension. Out of scope of this document.	CSP Extension. Out of scope of this document.	CSP Extension. Out of scope of this document.



5.2 MigTD Policy Measurement

A MigTD should design the policy in an extensible way that the CSP/Solution vendor may add their own policy. The policy could be:

- Code executed by a common policy engine to evaluate
 - The code (a statically linked library or a dynamic loaded module) could be part of MigTD Core, which is extended to MRTD in non-SecureBoot mode or RTMR[1] in Secure Boot Mode. See more details about these two modes in Chapter 10.
 - o If the MigTD checks the "TDX Module Policy" to detect the error earlier, then this check can be done in the code, and then there is no need to define it as policy data.
- Data consumed by a common policy module.
 - The data could be provisioned later in Configuration Firmware Volume (CFV) of the MigTD, which is extended to RTMR[2].
 - The MigTD includes the "MigTD Default Policy" in CFV, so that it can be easily updated. For example, the TCB SVN or QE certificate expired date. The trust anchor "Intel Root CA Cert" and Certificate Revocation List (CRL) shall also be included in CFV as part of migration policy.

5.3 MigTD Policy Definition

The typical MigTD policy is that the TCBs and hardware are newer than the baseline date, which can be evaluated with TDX Quote attestation. Figure 4-3 shows the TDX Quote and TD Report structure.

5.3.1 MigTD Policy Property

This document defines below default policy properties.

Table 5-2: MigTD Policy Property

Family Name	Group Name	Property Name	Туре	Comment
MigTD	TEE_TCB_INFO (The integrity is	TEE_TCB_SVN.SEAM	Integer	Intel TDX module SVN. (UINT16)
	verified with TD Quote)	MRSEAM	String	Measurement of the Intel TDX module. (48 Bytes Hash)
		MRSIGNERSEAM	String	Measurement of TDX module signer if valid. (48 Bytes Hash)



		Ī	1	Τ
		ATTRIBUTES	Integer	Additional configuration ATTRIBUTES if valid. (UINT64)
	TDINFO (The integrity is	ATTRIBUTES	Integer	TD's Attributes. (UINT64)
	verified with TD Quote)	XFAM	Integer	TD's XFAM. (UINT64)
		MRTD	String	Measurement of the initial contents of the TD. (48 Bytes Hash)
		MRCONFIGID	String	Software-defined ID for non-owner- defined configuration of the guest TD. (48 Bytes Hash)
		MROWNER	String	Software-defined ID for the guest TD's owner. (48 Bytes Hash)
		MROWNERCONFIG	String	Software-defined ID for owner-defined configuration of the guest TD. (48 Bytes Hash)
		RTMRO	String	Runtime extendable measurement register 0. (48 Bytes Hash)
		RTMR1	String	Runtime extendable measurement register 1. (48 Bytes Hash)
		RTMR2	String	Runtime extendable measurement register 2. (48 Bytes Hash)
		RTMR3	String	Runtime extendable measurement register 3. (48 Bytes Hash)



	EventLog (The integrity of "Digest" is verified with RTMR. The integrity of "Data" is verified with "Digest")	Digest.TdShim	String	Digest for TDShim. (48 Bytes Hash)
		Digest.MigTdCore	String	Digest for MigTD Core. (48 Bytes Hash)
		Digest.SecureBootKey	String	Digest for SecureBootKey. (48 Bytes Hash)
		Digest.MigTdPolicy	String	Digest for MigTdPolicy.
				(This field is only valid with "self" string to indicate that the MigTdPolicy from source and destination must be same.)
		Data.MigTdCoreSvn	Integer	MigTD Core's SVN. (UINT64)
QE	Quote (The integrity is verified with TD Quote)	PckCert.ExpiredTime	String	Expired time for the PCK certificate.
		AttestationKeyCert. ExpiredTime	String	Expired time for the Attestation Key certificate.

5.3.2 MigTD Policy Format

 $\label{eq:migTD} \mbox{MigTD should use the industry standard for the policy data format- {\it JSON}.$



```
...
...
}
=======
```

Property Type	Operation- Name	Reference-Value type	Comment
Integer	"equal", "greater-or- equal", "subset"	Integer value	Not sure if we want to support "greater", "less", "less-or-equal", or "superset"
String	"equal"	String value	
String	"equal"	"self"	Used to ensure two MigTDs have same data.
String	"in-range"	" <integer><integer>"</integer></integer>	The property shall be greater-or-equal than the begin value, and less than the end value.
String	"in-time-range"	" <integer><integer>"</integer></integer>	The property time shall be within the time range. The value in the time range is UNIX time.
			(Unit time is the number of seconds that have elapsed since the UNIX epoch, minus leap seconds; the UNIX epoch is 00:00:00 UTC on 1 January 1970.)

5.3.3 MigTD Policy Example

5.3.3.1 Sample Policy in non-SecureBoot Mode

In this mode, we cannot know the SVN of the MigTDCore. We use policy to indicate the MigTD must be same.

{



```
"MigTD": {
"TEE_TCB_INFO": {
   "TEE_TCB_SVN.SEAM": {
     "operation": "greater-or-equal",
     "reference": "self"
  },
  "MRSEAM": {
     "operation": "equal",
     "reference": "self"
  },
  "MRSIGNERSEAM": {
     "operation": "equal",
     "reference": "self"
  },
  "ATTRIBUTES": {
     "operation": "equal",
    "reference": "self"
  }
},
"TDINFO": {
  "ATTRIBUTES": {
     "operation": "equal",
     "reference": "self"
  },
  "XFAM": {
     "operation": "equal",
     "reference": "self"
  },
  "MRTD": {
     "operation": "equal",
     "reference": "self"
  },
  "MRCONFIGID": {
     "operation": "equal",
     "reference": "self"
  },
   "MROWNER": {
    "operation": "equal",
     "reference": "self"
  },
   "MROWNERCONFIG": {
     "operation": "equal",
     "reference": "self"
```



```
},
   // use RTMR
   "RTMR0": {
      "operation": "equal",
      "reference": "self"
   },
   "RTMR1": {
      "operation": "equal",
      "reference": "self"
   },
   "RTMR2": {
      "operation": "equal",
      "reference": "self"
   },
   "RTMR3": {
      "operation": "equal",
      "reference": "self"
   }
 }
}
```

5.3.3.2 Sample Policy in Secure Boot Mode

In this mode, we can know the SVN of the MigTDCore. We use policy to indicate a set of MigTD that the SVN in a fixed range.

```
"MigTd": {
"TEE_TCB_INFO": {
  "TEE_TCB_SVN.SEAM": {
    "operation": "greater-or-equal",
    "reference": "self"
  },
  "MRSEAM": {
    "operation": "equal",
    "reference": "self"
  },
  "MRSIGNERSEAM": {
    "operation": "equal",
    "reference": "self"
  },
  "ATTRIBUTES": {
```



```
"operation": "equal",
    "reference": "self"
  },
},
"TDINFO": {
  "ATTRIBUTES": {
    "operation": "equal",
    "reference": "self"
  },
  "XFAM": {
    "operation": "equal",
    "reference": "self"
  },
  "MRTD": {
    "operation": "equal",
    "reference": "self"
  "MRCONFIGID": {
    "operation": "equal",
    "reference": "self"
  },
  "MROWNER": {
    "operation": "equal",
    "reference": "self"
  },
  "MROWNERCONFIG": {
    "operation": "equal",
    "reference": "self"
  },
},
"EventLog": {
  // Do not use RTMR, but SVN in event log
  // Below policy means and SVN in [13, 18).
  "Digest.TdShim": {
    "operation": "equal",
    "reference": "self"
  },
  "Digest.SecureBootKey": {
    "operation": "equal",
    "reference": "self"
  },
  "Digest.MigTdPolicy": {
```

MigTD Migration Policy



```
"operation": "equal",
    "reference": "self"
},
    "Digest.MigTdCoreSvn": {
        "operation": "in-range",
        "reference": "13..18"
},
}
}
```

§



6 MigTD Network Communication

Two MigTD need communicate with each other to establish a secure session. Because the MigTD is in TCB, it is not recommended to include a full TCP/IP network stack in a MigTD. Instead, the MigTD should use the network stack in the untrusted VMM host environment.

6.1 TDVMCALL

The MigTD-s may use ${\bf TDG.VP.VMCALL}{<} {\bf Service.MigTD.Send}{>}$ and

TDG.VP.VMCALL<Service.MigTD.Receive> to communicate the VMM host environment and pass the MigTD-to-MigTD communication packet (such as TLS packet). The VMM on the source platform need pass the communication packet to the VMM on destination platform. Then the VMM on the destination platform can return the packet to the MigTD-d. When MigTD-d finishes processing the input packet, MigTD-d can return the response back to MigTD-s by using the same mechanism. Figure 6-1 shows the flow.




Figure 6-1: VMCALL based communication in MigTD

6.1.1 VSock information

During MigTD launch, the VMM can pass the **MIGTD_STREAM_SOCKET_INFO** HOB to the MigTD to allow MigTD to communicate with the agent.

The context ID (CID) of the VMM is 2 - Well-known CID for the host. The context ID (CID) of the MigTD can be retrieved from **MIGTD_STREAM_SOCKET_INFO** HOB. The VMM or the MigTD can be client or server. The server listening port can be found in the **MIGTD_STREAM_SOCKET_INFO** HOB.



6.1.2 VSock data payload

The MigTD should put the TLS packet to the VMCALL-vsock data payload.

§



7 MigTD Cryptography Capability

MigTD needs to have cryptography for key negotiation.

7.1 Cryptography

7.1.1 Cryptography Algorithm

Table 7-1: MigTD Cryptography Algorithm

Cryptography	Options	Recommendation
Digital Signature	RSA, ECDSA	ECDSA-NIST_P384
Key Exchange	ECDHE	ECDHE-secp384r1
AEAD	AES-GCM, Chacha20-Poly1305	AES-256-GCM
Hash	SHA-2	SHA384

7.1.2 TLS Configuration

Figure 7-1: MigTD TLS Configuration

TLS Configuratio n	Options	Recommendation	
Version	1.2, 1.3	1.3	
Cipher Suite	V1.3	V1.3	
	TLS_AES_256_GCM_SHA384	TLS_AES_256_GCM_SHA3	
	TLS_AES_128_GCM_SHA256	84	
	TLS_CHACHA20_POLY1305_SHA256		
	V1.2		
	TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA38 4		



TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA 384	
TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA25 6	
TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA 256	

7.2 Random Number Generation

The MigTD should use Intel instruction **RDSEED/RDRAND** to get random number.

§



8 MigTD Binary Image

MigTD is a customized tiny TDVF.

8.1 Boot Firmware Volume (BFV)

The MigTD includes one Firmware Volumes (FV) - Boot Firmware Volume. The format of FV is defined in PI specification.

The Boot Firmware Volume includes all component required during boot.

The file system GUID must be **EFI_FIRMWARE_FILE_SYSTEM2_GUID** or **EFI_FIRMWARE_FILE_SYSTEM3_GUID**, which is defined in PI specification.

1) TD Shim

- a) ResetVector this component provides the entrypoint for MigTD, switch to long mode, and jumps to the ShimIpl. The FFS GUID must be
 EFI_FFS_VOLUME_TOP_FILE_GUID, which is defined in PI specification.
- b) ShimIpl This component prepares the required parameter for MigTDCore and jump to the MigTDCore. Module type is EFI_FV_FILETYPE_SECURITY_CORE, which is defined in PI specification.
- 2) MigTDCore The main MigTD module, which finishes all its work described in chapter 2 then tears down itself. MigTD core includes key exchange cryptography capability and networking capability via VMM interface. File type is EFI_FV_FILETYPE_DXE_CORE, which is defined in PI specification.

The BFV may include an initial static page table to assist the ResetVector switch from 32-bit mode to 64-bit mode.

8.2 Configuration Firmware Volume (CFV)

MigTD includes a Configuration Firmware Volume (CFV) to hold the migration policy data.

Table 8-1: MigTD Policy Data

Item	Variable GUID	Variable Name	Comment
MigTD Policy	MIGTD_GUID	"MigTD_Policy"	JSON file
Root CA Cert (Trust Anchor)	MIGTD_GUID	"Quote_db"	One EFI_SIGNATURE_LIST, one EFI_SIGNATURE_DATA



Certificate Revocation List	MIGTD_GUID	"Quote_dbx"	One EFI_SIGNATURE_LIST, multiple EFI_SIGNATURE_DATA
Secure Boot Key	MIGTD_GUID	"MigTdCore_db"	One EFI_SIGNATURE_LIST, one EFI_SIGNATURE_DATA
			(only applicable for SecureBootMode)

§



9 MigTD Launch

MigTD launch is similar to TDVF launch.

9.1 MigTD initialization

The MigTD initialization is the same as TDVF initialization flow, and starts from 32-bit protected mode with paging disabled, then switch to 64-bit long mode.

9.2 MigTD Hand-Off Block (HOB)

The TD HOB list is used to pass the information from VMM to TDVF. The HOB format is defined in PI specification. If the TD HOB is used, it must be extended to RTMR register.

MigTD should ignore the TD HOB passed from VMM. The TD memory information should be indicated by MigTD in the metadata area.

After launch, the MigTD should call **TDG.VP.VMCALL <Service.MigTD.WaitForRequest>** to get the new migration information.

The MigTD could be transient or persistent, the MigTD should use **TDG.VP.VMCALL <Service.MigTP.ReportStatus>** to report the migration status, after it programs the MSK to the TDX module.

9.3 MigTD teardown

MigTD can teardown itself after the migration is done with a special **TDG.VP.VMCALL** <**Service.MigTD.Shutdown>**.

MigTD is only launched when the VMM starts to migrate.

9.4 MigTD AP handling

For simplicity, a MigTD may choose to only support one processor.

As an alternative, a MigTD may support multiple processors if multiple TD migrations are supported. See chapter 12 for details.

§



10 MigTD Measurement

MigTD measurement is same as a normal TDVF.

10.1 Non-Secure Boot Mode

Usually, TD-Shim is treated as firmware code and extended to MRTD. The MigTD Core is treated as OS code and extended to RTMR[1]. The MigTD Policy is treated as application code/config and extended to RTMR[2]. See table 10-1.

However, if we choose this approach, there is no way to know a secure version number (SVN) of a MigTD. If we want to allow a MigTD to support a different peer MigTD identified with SVN, then we need a different way – Secure Boot Mode.

Table 10-1: TD Measurement Registers for MigTD (Non-Secure Boot)

Typical Usage	Register	Event Log	Extended by	Content
Firmware Code	MRTD	NO	VMM: SEAMCALL [TDH.MR.EXTEND]	TD-Shim
Firmware Config	RTMR [0]	YES	TD-Shim: TDCALL [TDG.MR.RTMR.EXTEND]	N/A
OS code / Config	RTMR [1]	YES	TD-Shim: TDCALL [TDG.MR.RTMR.EXTEND]	MigTD Core
APP code/ Config	RTMR [2]	YES	MigTD Core: TDCALL [TDG.MR.RTMR.EXTEND]	MigTD Policy (Including JSON style policy, Root CA Cert and CRL)

10.2 Secure Boot Mode

In Secure Boot Mode, only TD-Shim is extended to MRTD. TD-Shim can follow secure boot policy to verify the signature of MigTD and its SVN. The secure boot key is treated as firmware config and extended to RTMR[0]. The MigTD Core and its SVN are treated as OS code and config. They are extended to RTMR[1]. The MigTD policy is still treated as APP config and extended to RTMR[2]. See table 10-2.

With this approach, the verifier can get the MigTD core SVN. If TD-Shim and secure boot key are same and MigTD Core and SVN are updated, the MigTD can verify peer by using the SVN.



Table 10-2: TD Measurement Registers for MigTD (Secure Boot)

Typical Usage	Register	Event Log	Extended by	Content
Firmware Code	MRTD	NO	VMM: SEAMCALL [TDH.MR.EXTEND]	TD-Shim
Firmware Config	RTMR [0]	YES	TD-Shim: TDCALL [TDG.MR.RTMR.EXTEND]	Secure Boot Key
OS code / Config	RTMR [1]	YES	TD-Shim: TDCALL [TDG.MR.RTMR.EXTEND]	MigTD Core, MigTdCore SVN
APP code/ Config	RTMR [2]	YES	MigTD Core: TDCALL [TDG.MR.RTMR.EXTEND]	MigTD Policy (Including JSON style policy, Root CA Cert and CRL)

10.3 MigTD Binding

MigTD should be bound with the target TD to be migrated. If VMM chooses to keep MigTD alive, the VMM can launch the MigTD at first then use of **SEAMCALL[TDH.SERVTD.BIND]** to bind the target TD. Then the VMM gets the **TargetTD_UUID** and **BindingHandle** and passes them to MigTD in **MIGTD_MIGRATION_INFORMATION**.

If VMM chooses to launch MigTD when it is required, then the VMM can use **SEAMCALL[TDH.SERVTD.PREBIND]** to prebind the target TD. The VMM shall calculate the MigTD's TDINFO_STRUCT then SERVTD_INFO_HASH. The SERVTD_INFO_HASH shall be input as parameter during prebind.

§



11 MigTD Metadata

MigTD uses the same metadata defined for TDVF. BFV is required. CFV might be required, if CFV based policy is supported. The temp memory (stack / heap) is required, and it is used to indicate the memory that will be used by MigTD.

TD Hob is NOT required in the MigTD.

§



12 Multiple TDs Migration

12.1 Multi TDs Migration

A VMM might need migration multiple TDs at one time. If one source MigTD and one destination MigTD set up the RA-TLS connection with mutual authentication, this connection can be used to migrate multiple TDs. See figure 12-1.

This model should be supported by default, because there is no need to set up multiple RA-TLS sessions if source MigTD and destination MigTD are same.




Figure 12-1: Multiple TDs Migration

12.2 Multi RA-TLS connections

One migration TD might support multiple RA-TLS connection sessions to or from different migration TDs.

12.2.1 Multi destination MigTDs

In some case, a VMM might need migration multiple TDs to different platforms. As such, one source MigTD need setup connection to multiple destination MigTDs. See figure 12-2.






Figure 12-2: Multiple Destination Migration TDs

12.2.2 Multi source MigTDs

Similar to above case, a VMM might launch a destination and migration TD from different platforms. As such, one destination MigTD need wait for the connection from multiple source MigTDs. See figure 12-3.




Figure 12-3: Multiple Source Migration TDs



12.3 Multi-Processor

If a MigTD supports multiple connections to or from different MigTDs, the VMM can enable multiple processors. MigTD may allocate different stack and heap for different processor and launch the MigTD Core. Then each CPU can take responsibility to set up a session with a subset of destination MigTD. See figure 12-4.

For example, if there are 20 different MigTD connections need to be set up and 4 CPUs, then each CPU can handle 5 MigTD connections.




Figure 12-4: Multiple Processor Support in Migration TD

§



Appendix A Reference

[TDVF] Intel TDX Virtual Firmware Design Guide,

https://software.intel.com/content/www/us/en/develop/articles/intel-trust-domain-extensions.html

[GHCI] Guest Hypervisor Communication Interface v1.5,

https://software.intel.com/content/www/us/en/develop/articles/intel-trust-domain-extensions.html

[TDX Module EAS] Intel TDX Module v1.5 Base Architecture, Intel TDX Module v1.5 ABI, https://software.intel.com/content/www/us/en/develop/articles/intel-trust-domain-extensions.html

[TDX Migration] Intel TDX Module v1.5 TD Migration Architecture,

https://software.intel.com/content/www/us/en/develop/articles/intel-trust-domain-extensions.html

[JSON] JSON data model, https://www.json.org/json-en.html

[CBOR] Concise Binary Object Representation, http://cbor.io/

[Intel RA-TLS] Intel Remote Attestation TLS, https://github.com/cloud-security-research/sgx-ra-tls

[Open Enclave RA-TLS] open enclave Remote Attestation TLS,

https://github.com/openenclave/openenclave/tree/master/samples/attested_tls, https://github.com/openenclave/openenclave/blob/master/include/openenclave/attestation/attester.h,

https://github.com/openenclave/openenclave/blob/master/include/openenclave/attestation/ver ifier.h

§