







DESCRIPTION P/N



1	Fairing	70205-06052-065
2	Fairing	70205-06052-067
3	Fairing	70205-06053-041
4	Fairing	70215-05001-052, 053
5	Fairing	70215-05001-048
6	Panel	70500-02070-042, 066
7	Door	70500-03006-049 LH
8	Door	70500-03006-048 RH
9	Cover	70207-03007-041
10	Floor	70214-02556-051 UH, 70204
11	Floor	70214-02555-047 UH, 70204
		-42504-041 EH
12	Floor	70214-02554-047 UH, 70204
		-42503-041 EH
13	Seat frame	103701-2 LH, 103701-2 RH
14	Fairing	70215-02531-058 RH
14.1	Fairing	70215-02531-057 LH
15	Shelf	70214-01002-044
16	Work platform	70219-04902-047
17	Fairing	70219-04200-057
18	Fairing	70219-04300-069 LH
18.1	Fairing	70219-04300-070 RH
19	Fairing	70219-04400-041
19.1	Cover	70219-04400-103
20	Cowling	70302-02141-049 LH
20.1	Door	70302-02141-048 RH
21	Door	70219-04500-042 RH
22	Door	70219-04500-041 LH
23	Door	70219-04619-050
24	Door	70207-63002-041 EH
25	Door	70219-04704-047
26	Door	70219-04704-041
27	Fairing	70219-04802-058, 041
28	Fairing	70219-04901-051
29	Cover	70215-05002-041 FWD
30	Cover	70215-05002-048 AFT
31	Fairing	70205-06051-041
32	Cowling	70302-02141-045
33	Main rotor blade	70150-09100-041 /
		70150-09100-043
34	Tail rotor blade	70101-11200-044/
		70101-31000-043



