
7.7.3 Water

- (a) Principles of Water Sensitive Urban Design (WSUD) are to be applied across all aspects of the development to minimise stormwater discharged from the site and ensure any stormwater has minimal impact on local waterways and drainage infrastructure.
- (b) Provide fit for purpose water harvesting, re-use, and on-site storage.
- (c) Maximise indoor and outdoor water efficiency in order to reduce potable water consumption.
- (d) Design to increase resilience to flooding and drought and integrate with stormwater quality, quantity and urban canopy/greening requirements.
- (e) Maximise permeable areas and materials across the site to reduce runoff and better manage stormwater capacity.
- (f) Minimise infrastructure and utility conflicts to prevent damage in storms.