

Apply threadlock/superglue and insert the M16 thread into the coupling