

Push the PVC end cap onto the back of the coupling. You should have a tight fit and so don't need to use any fasteners.