Rotate the piece by 90 degrees and drill two more holes at the other end.

