

□ Agenda

- → FreeRTOS v/s SafeRTOS
 - **♦** Introduction
 - **♦** Features
 - ♦ Key Differences
- → FreeRTOS v/s Zephyr
 - **♦** Introduction
 - **♦** Architecture
 - ◆ Zephyr Directory Structure
 - ◆ Why We Moved from FreeRTOS to Zephyr RTOS





□ Introduction

- SAFERTOS is a safety critical, Real Time Operating System, delivering superior performance and pre-certified dependability, while using minimal resources.
- SafeRTOS is a safety focused upgrade of FreeRTOS.
- SafeRTOS was developed by Wittenstein High Integrity Systems, a safety systems company.
- SafeRTOS is designed and tested to comply with IEC61508 Safety Integrity Level 3, and with ISO26262, ASIL D.
- SafeRTOS follows the FreeRTOS functional model, upgrading is easy.
- SafeRTOS is not a open-source and requires commercial license for use.





□ Features

- SafeRTOS offers an extremely fast boot time.
- Ultra-low power mode.
- No dynamic memory operations.
- Spatial separation of tasks
- Compact Footprint

Typical ROM Requirements 6-15 kB.

Typical RAM Requirements 500 bytes.

Typical Stack Requirements 400 bytes/task.





□ Key Differences

FreeRTOS and SafeRTOS share a similar usage model but are not direct drop-in replacements for each other, These differences primarily arise from:

- Memory allocation
- Restricted Functionality
- Function parameter checking
- Internal data checking





☐ Memory Allocation

- Each task and queue created consumes a small amount of RAM. Under FreeRTOS the required RAM is automatically dynamically allocated at run time.
- SafeRTOS does not permit dynamic memory allocation so the required RAM must instead be statically allocated at compile time, then manually passed into the create functions for the various kernel objects.
- In FreeRTOS MPU support is optional, whereas in SafeRTOS it is a mandatory to use MPU, as it is a key and central component.
- FreeRTOS projects include pvPortMalloc() and vPortFree() implementations in files like heap_1.c, heap_2.c, etc. These files are not required when using SafeRTOS.





□ Contd...

- Changes to XTaskCreate()
 - SafeRTOS version of xTaskCreate() requires more parameters than its FreeRTOS counterpart.
 - The SAFERTOS version of xTaskCreate() accepts 2 parameters
 - pxTaskParameters which is a pointer to a xTaskParameters structure
 - pxCreatedTask which is used to pass back the handle of the created task.
- portBaseType xTaskCreate(const xTaskParameters * const pxTaskParameters,
 portTaskHandleType * pxCreatedTask);





☐ Contd...

```
xTaskParameters xTaskParams = /* Task creation parameter struct. We'll re-use this for all the tasks, */
116
                                       /* adjusting just the parts than need to change.
117
            &prvLEDPWMTask.
                                       /* The function that implements the task being created.
118
             "RedLEDTask",
                                       /* The name of the task being created. Needs to change for each task.
119
                                       /* The TCB for the task being created. Must be unique for each task.
120
            &xRedLEDTaskTCB,
                                       /* The buffer to use for the task stack. Must be unique per task.
                                                                                                                */
121
             acRedLEDPWMTaskStack,
            configMINIMAL STACK SIZE NO FPU, /* The size of the task stack - note this is in BYTES.
122
                                       /* The task parameter, used here to identify target LED in LED tasks.
123
             (void*) OUL,
            LED TASK PRIO,
                                       /* The priority assigned to the task being created.
124
                                       /* Void pointer for thread Local Storage. (Not used here).
125
            NULL,
                                       /* Indicates whether the created task will use the FPU.
126
             pdFALSE,
127
                                       /* MPU parameters that will be in effect whenever this task runs:
                                              /* This task is privileged.
128
                mpuPRIVILEGED TASK,
129
                      NULL, OUL, OUL, OUL }, /* Task region 0 - no region specified
130
                      NULL, OUL, OUL, OUL }, /* Task region 1 - no region specified
131
                      NULL, OUL, OUL, OUL }, /* Task region 2 - no region specified
132
                      NULL, OUL, OUL, OUL \ /* Task region 3 - no region specified
                                                                                         */
133
134
135
        };
136
137
138
        /* Create the red LED task */
        if ( pdPASS != xTaskCreate(&xTaskParams, (portTaskHandleType*) NULL))
139
140
            xStatus = E LED0 TASK CREATE FAIL;
141
142
```





□ Contd...

- Changes to XQueueCreate()
 - SAFERTOS version of xQueueCreate() requires three more parameters than its FreeRTOS counterpart.
 - pcQueueMemory Points to the statically declared buffer to be used by the kernel to hold the queue data structures and storage area.
 - uxBufferLength The size of the buffer pointed to by the pcQueueMemory parameter.
 - pxQueue Used to return a handle to the queue being created.





□ Contd...

Prototype of xQueueCreate in SafeRTOS
 portBaseType xQueueCreate(portInt8Type *pcQueueMemory,

portUnsignedBaseType uxBufferLength,
portUnsignedBaseType uxQueueLength,
portUnsignedBaseType uxItemSize,
xQueueHandle *pxQueue);

• Other FreeRTOS APIs like xSemaphoreCreateBinary(), xSemaphoreCreateCounting(), xTimerCreate(), xEventGroupCreate(), xMutexCreate(), and xStreamBufferCreate(), etc also require modifications for static memory allocation in SafeRTOS.





□ Restricted Functionality

The SafeRTOS functionality has been restricted to include only the core components necessary. This is standard practice for source code that is intended to undergo formal audit or certification as it greatly reduces the test burden.

Queue Sets :

- SafeRTOS does not provide an implementation of Queue Sets.
- It implements the Event Multiplex API, which supersedes the FreeRTOS Queue Sets functionality.
- An event multiplex object can be used to wait for the same event on multiple different target objects.
- For example if there are multiple queues which a task wants to receive from, the task can use an event multiplex to wait for an item to be on any of the queues.



□ Contd...

• **Co-routines**: SafeRTOS does not provide a co-routine implementation.

Thread Local Storage :

- FreeRTOS allows associating each task with a configurable number of pointers to Thread Local Storage (TLS) objects.
- SafeRTOS always implements one TLS pointer, therefore the number is not configurable and cannot be disabled.

• Task Tags:


- FreeRTOS supports the possibility of assigning an application-defined tag to each task.
- SafeRTOS does not support task tags. However, it should be possible to use the TLS pointer instead.





□ Contd...


FreeRTOS





□ Contd...

SAFERTOS







□ Function Parameter Checking

- FreeRTOS contains very little in the way of API function input parameter checking.
- As a result, many FreeRTOS API functions either just return a simple pass or fail result, or do not return any status information at all.
- SAFERTOS checks the validity of every appropriate input parameter.
- This means not only do more SAFERTOS API functions return status information, but the status information returned is also more detailed.





□ Contd...

• Example:

- o In FreeRTOS, if the queue is created successfully then a **handle** to the created queue is returned. If the memory required to create the queue could not be allocated then **NULL** is returned.
- In SafeRTOS;

pdPASS - The queue was created successfully.

errINVALID_ALIGNMENT - The alignment of the pcQueueMemory value was not correct for the target hardware.

errINVALID_QUEUE_LENGTH - uxQueueLength was found to equal zero.





□ Contd...

errINVALID_BUFFER_SIZE - uxBufferLengthBytes was found to not equal(uxQueueLength*uxItemSize)+portQUEUE_OVERHEAD_BYTES.

errNULL_PARAMETER_SUPPLIED - Either pcQueueMemory or pxQueue was NULL.

errQUEUE_ALREADY_IN_USE - The pcQueueMemory pointer refers to a buffer that is already holding another queue.





☐ Internal data checking

- FreeRTOS provides a configuration file, "FreeRTOSConfig.h", which contains configuration parameters (macros) that modify the kernel's behavior according to the application needs.
- In SafeRTOS, application code cannot be built into the kernel as it may cause unpredictable behavior. Therefore, no configuration parameters (macros) are used.
- SafeRTOS includes a small set of standard hook functions that the application can supply during kernel configuration.
- The host application must provide an "Error Hook" function. Optionally, it can supply additional hooks: "Idle Hook", "Task Delete Hook", "System Call Hook", "Tick Hook", and other architecture-specific hooks.





□ Contd...

```
98 portBaseType xInitializeScheduler(void)
        portBaseType xInitSchedResult;
100
101
1028
        /* The structure passed to xTaskInitializeScheduler() to configure the kernel
103
         * with the application defined constants and call back functions. */
        const xPORT_INIT_PARAMETERS xPortInit =
104
105
106
            configCPU CLOCK HZ,
                                                 /* ulCPUClockHz - Clock speed in Hz */
                                                 /* ulTickRateHz - configured tick rate in Hz */
107
            configTICK RATE HZ,
108
            /* Hook function pointers */
109
                                                 /* Setup tick interrupt hook (for custom tick). */
110
111
            NULL,
                                                 /* Task delete hook function. */
112
            vApplicationErrorHook,
                                                 /* Error hook function. */
113
            NULL,
                                                 /* Idle hook function. */
                                                 /* Tick hook function, */
114
            NULL,
                                                 /* SVC Hook function (for custom SVC). */
115
            NULL,
116
            /* System Stack Parameters */
117
                                                 /* Size of the system stack in bytes. */
118
            configSYSTEM STACK SIZE,
119
            configSTACK_CHECK_MARGIN,
                                                 /* Additional margin when checking stacks for overflow. */
120
121
            /* Idle Task Parameters */
122
                                                 /* Address of a buffer for the idle task stack. */
            acIdleTaskStack,
                                                 /* Size of the idle task stack in bytes. */
123
            configIDLE_TASK_STACK_SIZE,
                                                 /* The idle hook will not use the FPU. */
124
            pdFALSE,
125
            { /* Idle task MPU parameters. */
126
                mpuPRIVILEGED TASK,
                                                 /* The idle hook will be executed in privileged mode. */
127
128
                      NULL, 0U, 0U, 0U },
                                                 /* There are no additional regions defined. */
                      NULL, 6U, 6U, 6U ),
129
130
                      NULL, 6U, 6U, 6U },
131
                      NULL, 0U, 0U, 0U }
132
133
            },
134
            NULL,
                                                 /* Thread Local Storage for the Idle Task, if any. */
```





□ Contd...

- If SafeRTOS detects any errors like memory corruption, stack overflow or other error from which it is unsafe to attempt any sort of recovery then Error hook function is called.
- Error hook function is responsible for ensuring that system enters a safe state.

```
31 void vApplicationErrorHook( portTaskHandleType xHandleOfTaskWithError,
32
                                    const portCharType * pcErrorString,
33
                                    portBaseType xErrorCode )
34 {
35 portUnsignedBaseType ulBusyCounter;
36
       /* The parameters are not used, these lines prevent compiler warnings. */
37
       ( void ) xHandleOfTaskWithError;
38
       ( void ) pcErrorString;
39
40
       /* Switch the 3-colour LED to RED */
41
       vParTestSetLED( 0, 1 );
42
       vParTestSetLED( 1, 0 );
43
       vParTestSetLED( 2, 0 );
44
45
       /* Will only get here if an internal kernel error occurs. */
45
       for( ;; )
47
48
           /* Busy loops flickering LED, to allow debugger to attach. */
49
           for( ulBusyCounter = hookfunctionERROR_BUSY_LOOP_COUNT ; ulBusyCounter > 0ul ; --ulBusyCounter )
50
51
52
               xErrorCode++;
53
               xErrorCode--;
55
           vParTestToggleLED( 0 );
56
57
```





☐ Introduction

- The Zephyr OS is based on a small-footprint kernel designed for use on resource constrained and embedded systems.
 - Fits where linux is too big
- Zephyr OS is built to be secure and safe.
- Zephyr OS is fully integrated, highly configurable, modular and flexibe.
- Highly connected
 - Bluetooth 5.0 & BLE
 - Wi-Fi, Ethernet, CANbus, open thread...
 - USB & USB-C







Supported Hardware Architectures









Cortex-M, Cortex-R & Cortex-A

x86 & x86_64





32 & 64 bit










☐ Architecture



- Highly configurable and modular
- cooperative and preemptive threading
- An integrated device driver interface.
- Memory protection, stack overflow protection.
- Supports Bluetooth® Low Energy (BLE 5.1).
- 802.15.4 OpenThread.
- A native, fully featured and optimized networking stack.
- Supports a range of subsystems, including USB, filesystem, logging.





□ Zephyr Directory Structure

• Main Folders:

— arch

— boards

— doc

— drivers

— include

— kernel

— lib

— scripts

— soc

— subsys

— tests

- samples





□ Contd...

Zephyr Root

---- arch

— boards

—— drivers

—— dts

—— include

— kernel

—— lib

— modules

— soc

—— subsys

— tests

— samples

Contains architecture-specific code, such as CPU and board definitions. Each supported architecture (e.g., ARM, x86) has its own subdirectory.

- **Purpose**: Handles low-level details of each CPU architecture.
- **FreeRTOS**: The equivalent would be the *portable* directory which contains architecture-specific code for different compilers and processors.





□ Contd...

Zephyr Root

---- arch

---- boards

—— drivers

— dts

—— include

—— kernel

—— lib

— modules

— soc

—— subsys

— tests

— samples

Contains board-specific configurations. Each supported board has a subdirectory with its specific settings.

- **Purpose**: Provides device tree files and configuration for different hardware boards.
- FreeRTOS: FreeRTOS does not have a direct equivalent; board support is typically found in *demo* applications or third-party repositories.





□ Contd...

Zephyr Root

---- arch

— boards

— drivers

— dts

include

— kernel

— lib

— modules

— soc

—— subsys

— tests

L—samples

Contains hardware drivers for peripherals like UART, I2C, SPI, etc.

- **Purpose**: Implements hardware abstraction layers to interact with various peripherals.
- **FreeRTOS**: Provides basic drivers like gpio, rcc, .. in *demo* folder, needs manual integration of additional drivers.





□ Contd...

Zephyr Root

— arch

— boards

—— drivers

— dts

— include

---- kernel

—— lib

— modules

— soc

— subsys

— tests

—— samples

Contains Device Tree Source include(.dtsi) files which describe hardware components.

- **Purpose**: Provides a standardized way to describe the hardware layout.
- **FreeRTOS**: FreeRTOS does not use Device Trees; hardware descriptions are typically hardcoded or configured through header files.





□ Contd...

Zephyr Root

---- arch

—— boards

—— drivers

—— dts

— include

— kernel

— lib

— modules

— soc

—— subsys

— tests

— samples

Contains global header files used throughout the Zephyr project.

- **Purpose**: Provides common definitions and macros accessible by other parts of the OS.
- **FreeRTOS**: The *include* directory serves a similar purpose, providing global header files and APIs.





□ Contd...

Zephyr Root

---- arch

— boards

—— drivers

—— dts

—— include

— kernel

— lib

— modules

— soc

—— subsys

— tests

— samples

Contains the core RTOS kernel code.

- **Purpose**: Implements fundamental RTOS functionalities such as thread scheduling, inter-task communication, and synchronization.
- **FreeRTOS**: The *FreeRTOS/Source* directory contains the core kernel code.





□ Contd...

Zephyr Root

— arch

— boards

—— drivers

—— dts

—— include

— kernel

—— lib

— modules

— soc

—— subsys

— tests

L—samples

Contains libraries that provide various utilities and additional functionality.

- **Purpose**: Offers extended capabilities beyond the core kernel.
- FreeRTOS: Does not include extensive additional libraries like Zephyr. Additional libraries need to be integrated separately.





□ Contd...

Zephyr Root

---- arch

— boards

—— drivers

—— dts

—— include

—— kernel

—— lib

—— modules

---- soc

—— subsys

— tests

— samples

The modules directory in Zephyr serves as a place to integrate external modules and libraries into the Zephyr project.

- **Purpose**: Offers extended capabilities beyond the core kernel.
- **FreeRTOS**: FreeRTOS does not have a direct equivalent of the modules directory found in Zephyr. Requires more manual integration of external modules.





□ Contd...

Zephyr Root

—— arch

— boards

—— drivers

—— dts

—— include

— kernel

— lib

— modules

— soc

—— subsys

— tests

—— samples

Contains System-on-Chip specific code.

- **Purpose**: Handles initialization and configuration for specific SoCs.
- FreeRTOS: Similar configurations might be found in board support packages or vendor-provided code.





□ Contd...

Zephyr Root

---- arch

— boards

— drivers

—— dts

—— include

---- kernel

— lib

— modules

— soc

—— subsys

— tests

— samples

Contains various subsystems like USB, dsp, and Bluetooth.

- **Purpose**: Implements modular subsystems that provide additional services and capabilities.
- FreeRTOS: Similar functionalities might be implemented as separate modules or libraries in third-party extensions.





□ Contd...

Zephyr Root

---- arch

— boards

— drivers

—— dts

—— include

---- kernel

— lib

— modules

— soc

—— subsys

— tests

—— samples

Contains test cases for validating the functionality of Zephyr components.

- **Purpose**: Ensures reliability and correctness through automated tests.
- **FreeRTOS**: The *FreeRTOS/Test* directory contains test suites for validating the FreeRTOS kernel and components.





□ Contd...

Zephyr Root

---- arch

— boards

— drivers

—— dts

—— include

— kernel

— lib

— modules

— soc

—— subsys

— tests

— samples

Contains example applications demonstrating various features of Zephyr.

- **Purpose**: Provides reference implementations and starting points for new projects.
- **FreeRTOS**: The *FreeRTOS/Demo* directory contains example applications for various hardware platforms.





■ Why We Moved from FreeRTOS to Zephyr RTOS


- To understand the difference between FreeRTOS and Zephyr, let's refer to a blog written by **Stephen Berard**, Chief Technology Officer at **Nubix**, on March 28, 2023.
- Overview of Nubix's Mission:
 - Enable cloud-native development on resource-constrained edge devices.
 - Simplify building, deploying, managing, and securing applications at the edge.
- Need for a Flexible RTOS:
 - Development for microcontrollers (MCUs) is time-consuming and rigid.
 - A more adaptable RTOS is necessary to support diverse hardware, integrate new technologies, and meet the dynamic needs of modern applications.



☐ Initial Use of FreeRTOS

- Popularity and Limitations:
 - Widely used in embedded applications due to its simplicity and lightweight nature.
 - Limited library support and flexibility hindered development.
- Challenges Encountered:
 - Managing multiple libraries and middleware was difficult.
 - Lack of a comprehensive set of tools and toolchains for development.





□ Key Differences

Modularity and Flexibility

• FreeRTOS:

- Simplicity in design but less modular.
- Requires manual integration of additional features and libraries.

- Highly modular and configurable.
- Uses CMake and Kconfig for easy building and configuration.
- Supports a wide range of devices, from simple microcontrollers to complex systems.






- **□** Contd...
 - Security and Reliability
 - FreeRTOS:
 - Basic security features suitable for simple applications.
 - o Zephyr:
 - Robust and secure kernel with multiple scheduling algorithms.
 - Features like cryptography, secure boot, and firmware updates ensure high security.






- **□** Contd...
 - Driver Libraries
 - FreeRTOS:
 - Basic driver support requiring manual integration.
 - o Zephyr:
 - Built-in driver interfaces for a wide range of peripherals.
 - Supports IP networking, wireless communications (Wi-Fi, Bluetooth, LoRaWAN), and power management.
 - Provides consistent hardware abstraction layer through device class APIs.





- **□** Contd...
 - Board Support
 - FreeRTOS:
 - Limited and less standardized board support.
 - o Zephyr:
 - Over 450 supported boards from various architectures and vendors.
 - Uses Devicetree for easy configuration and support of new boards.
 - Quick onboarding of new edge devices.





- **□** Contd...
 - Power Management
 - FreeRTOS:
 - Limited capabilities for managing device power.
 - o Zephyr:
 - Advanced device power management features.
 - Automatically enters low-power states when not in use.
 - Ensures efficient power usage and long battery life.





