

Component Replacement

- electrical -



R800i, R800a, R800x, R800at, Z1





CONTENTS

| 1 | Replaceable Components | 3 |
|---|------------------------------------|---|
| | Component Placing | |
| | Repair Actions | |
| | 3.1 Shield Can Fence Modifications | |
| | 3.2 Additional Repair Info | 8 |
| 4 | Revision History | |

For general information about electrical repair related issues, refer to 1220-1336: Generic Repair Manual - electrical





Replaceable Components

EXPLANATION OF ABBREVIATIONS USED IN THE COLUMN 'COMMENTS' BELOW

COMPONENT LOCATION

P = Primary side

S = Secondary side

MOISTURE SENSITIVITY LEVEL

MSLX (X = 1, 2, 2A, 3, 4, 5, 5A or 6)

For more information on moisture sensitivity levels:

Refer to 1220-1336: Generic Repair Manual – electrical, section 'Moisture & Baking'!

REPAIR METHOD

HA = Hot Air (removal & mounting)

ST = Soldering Tool (removal & mounting)

HA/ST = Hot Air for removal - Soldering Tool for mounting

BGA = BGA Station

BH = Bottom Heater

ADDITIONAL INFORMATION

⇒1 (2,3,4, etc.) = Proceed to 'Additional Repair Info' for further instructions in the indicated section(s).

CALIBRATION

C = Calibration of the phone is required after replacing the component

Calibration to be done by authorized centers only!



| Only |
|----------|
| nd |
| |
| d 5 |
| d 8 |
| |
| |
| d 2 |
| nd |
| |
| l |
| 1 |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| יו או |



| Desition | Component | | Comments |
|----------|--|-----------|--------------|
| Position | Component | Part no. | Comments |
| N5400 | ASIC Tjatte3 CSP20 | 1000-0198 | S HA |
| N5500 | IC Amplifier 500mA | 1203-4594 | S HA ⇒ 6 |
| N5600 | IC WL-CSP 6x4 balls | 1212-7979 | S HA |
| N5701 | MEMS Compass Analog | 1228-7182 | S HA |
| S4803 | Input Switch | 1001-0060 | P HA/ST |
| S4804 | Input Switch | 1001-0060 | P HA/ST |
| S4805 | Input Switch Other TACT SWITCH 3.7 x 3.7 | 1213-3638 | SHA |
| S4806 | Input Switch Other TACT SWITCH 3.7 x 3.7 | 1213-3638 | S HA |
| S4807 | Input Switch | 1001-0060 | S HA/ST |
| S4808 | Input Switch Side Push/ | 1245-9546 | P HA/ST ⇒ 19 |
| S4809 | Input Switch Side Push/ | 1245-9546 | P HA/ST ⇒ 21 |
| S4810 | Input Switch Other TACT SWITCH 3.7 x 3.7 | 1213-3638 | S BGA |
| S5000 | Input Switch Other TACT SWITCH | 1230-4023 | S HA/ST |
| S5001 | Input Switch Other TACT SWITCH | 1230-4023 | S HA/ST |
| S5002 | Input Switch Other TACT SWITCH | 1230-4023 | S HA/ST |
| S5003 | Input Switch Other TACT SWITCH | 1230-4023 | S HA/ST |
| S5004 | Input Switch Other TACT SWITCH | 1230-4023 | S HA/ST |
| S5005 | Input Switch Other TACT SWITCH | 1230-4023 | S HA/ST |
| S5005 | Input Switch Other TACT SWITCH | 1230-4023 | S HA/ST |
| S5007 | Input Switch Other TACT SWITCH | 1230-4023 | S HA/ST |
| | | 1001-1864 | SHA |
| V3801 | ZenerDiode, 5.6V, Pb-free | | |
| V3802 | ZenerDiode, 5.6V, Pb-free | 1001-1864 | S HA |
| V3803 | Trans N-ch FET 1.2X0.8X0.5 | 1200-2023 | S HA |
| V4400 | LED White 2.04x1.64x0.7mm | 1228-6212 | P BGA ⇒ 7 |
| V4802 | LED RED/GREEN/BLUE | 1200-1926 | S HA/ST ⇒ 8 |
| V5000 | Diode Schottky 20.0 V SOD323 | 1200-1679 | P HA ⇒ 9 |
| V5100 | Diode Protection 5, V SOD-923 | 1201-8440 | SHA |
| V5102 | Trans P-ch FET WDFN6 | 1200-1780 | SHA |
| V5300 | Diode Zener 5.0 V SOT-723 | 1203-0201 | SHA |
| V5301 | Diode Zener 5.0 V SOT-723 | 1203-0201 | SHA |
| V5500 | Diode Zener 5.0 V SOT-723 | 1203-0201 | SHA |
| V5600 | MOSFET & Schottky Diode | 1201-3866 | S HA |
| W2100 | Internal Antenna Connector | 1000-0308 | P HA |
| X1900 | Conn Coax Receptacle 0p test switch | 1221-6477 | P BGA ⇒ 10 |
| X1901 | Conn Pogopin 2p | 1233-8058 | P BGA ⇒ 11 |
| X2500 | Conn Coax Receptacle 0p test switch | 1221-6477 | P BGA ⇒ 12 |
| X2501 | Conn Leaf Spring Receptacle 1p | 1200-2144 | P HA ⇒ 17 |
| X3801 | Conn Pogopin Plug 5p | 1226-6294 | P BGA ⇒ 13 |
| X4300 | Conn BtB Receptacle 64p | 1231-1872 | S BGA |
| X4500 | Conn BtB Receptacle 30p Hirose DF37B | 1216-9089 | S BGA |
| X5000 | Conn FPC Receptacle 8p | 1232-9797 | S BGA |
| X5100 | Card Conn SIM push-pull w/switch | 1227-3532 | P BGA ⇒ 14 |
| X5101 | Connector BtB | 1202-0859 | P BGA ⇒ 15 |
| X5200 | Conn USB micro B Receptacle 5p mid-mount | 1232-9759 | S BGA |
| X5401 | CONNECTOR/5 POS/FPC | 1001-6666 | P BGA ⇒ 16 |
| Z2100 | Filter 1.575 GHz | 1236-2944 | S HA |
| Z2100 | Filter SAW 1.575 GHz | 1211-5714 | P HA |
| Z2500 | Filter Cer RF 2.45 GHz Bluetooth/W-LAN | 1228-7102 | SHA |
| Z4300 | Filter 100.0 MHz | 1224-6060 | S HA ⇒ 18 |
| | Filter 100.0 MHz | 1224-6060 | |
| Z4301 | | | S HA ⇒ 18 |
| Z4302 | Filter 100.0 MHz | 1224-6060 | S HA ⇒ 18 |
| Z5200 | Filter 100.0 MHz | 1224-6060 | S HA |





2 Component Placing

To access the Component Placing document, double-click the icon below. Applicable for on-screen viewing only – icon not shown on hard-copies.





3 Repair Actions

Refer to the Tools Catalogue/Matrix for information about equipment required for PBA repair!


3.1 Shield Can Fence Modifications

Refer to the pictures below of the primary and secondary sides for repairs that require the Shield Can Fence to be modified:

- the shield can lid has to be removed
- the red symbols show where the frame should be cut to enable rework
- after rework the height of the frame should not be affected
- it should not be visible that rework has been carried out when the lid has been mounted

Primary side

Secondary side






Repair Actions

3.2 Additional Repair Info

1

B5000


Protect the white LED, the BtB connector and the SIM connector with capton tape!



2

B5500


Protect the white LED, the switch connector and the Coax connector with capton tape!



3

L5503, L5504, L5505

Protect the Microphone, the switch connector and the Coax connector with capton tape!






4

L5506, L5507, L5508

Protect the Microphone with capton tape!








5

N4401, N4402


Protect the On/Off key connector, the LED and the BtB connector with capton tape!



6

N4802, N5500


Protect the ZIF connector with capton tape!



7

V4400


Protect the Coax connector with capton tape!



8

V4802

Protect the On/Off key connector with capton tape!










9

V5000


Protect the Vibrator, the BtB connector, the switch connector, the white LED and the switch connector with capton tape!



10

X1900


Protect the connector with capton tape!!



11

X1901


Protect the switch connector with capton tape!



12

X2500

Protect the Microphone, the switch connector and the white LED with capton tape!










13

X3801


Protect the Coax connector with capton tape!



14

X5100


Protect the Vibrator, BtB connector and the ZIF connector with capton tape!



15

X5101


Protect the Vibrator, the white LED and the SIM connector with capton tape!



16

X5401

Protect the SIM connector with capton tape!








17

X2501


Protect the Microphone and the Coax connector with capton tape!



18

Z4300, Z4301, Z4302


Protect the BtB connector with capton tape!



19

B5500, V4400, X2500


Protect the LED white, Microphone and the Coax connector with capton tape!



20

S4805, X5200

Protect the USB connector and the input switch with capton tape!






Repair Actions: Additional Repair Info

21

X1901

Protect the connector with capton tape!





4 Revision History

| Rev. | Date | Changes / Comments |
|------|-------------|--------------------|
| 1 | 2011-Mar-24 | Initial release |