

Lock-in amplifier

Measuring input

Oscillator voltage out

V_{meas}

$V_0 \text{ rms}$

R_0

1

2

C_p

4

3

sample

