

# Lock-in amplifier

Measuring input

Oscillator voltage out

$V_{\text{meas}}$

$V_0 \text{ rms}$

$R_0$

1

2

$C_p$

4

3

sample

