
## Updating Firmware

- 1. Download Teensy loader program from: https://www.pjrc.com/teensy/loader.html
- 2. Run Teensy Loader
- 3. File Menu: Open Hex
- 4. Choose amx.YYYY-MM-DD.sha\_hash.hex (It may say file is too big...ignore)
  - 1. The filename has the compile date and the corresponding Github identifier.
  - 2. Example: amx.2018-05-15.0ab629877e8285277072ea8cb49febae28cdd648.hex
- 5. Remove microSD card from AMX
- Connect microUSB cable to the AMX board
- 7. Turn AMX power switch to on
- Short the two pads to force reprogramming. This should cause the firmware to upload.



Connect these two pads briefly with a wire to force reprogramming