EMERGENCY PROCEDURES		
	SMOKE OR FIRE AT THE COCKPIT OR CARGO CABIN 2 SMOKE EVACUATION 2	
GENERAL	LAVATORY SMOKE/FIRE 3 LANDING WITH ABNORMAL LND GEAR CONFIG	
	FORCED LANDING 4 DITCHING 5	
ON GROUND EMERGENCIES	ELECTRICAL SMOKE OR FIRE ON 7 GROUND 7	
ENVIRONMENTAL	AIR CONDITIONING 8 RAPID DEPRESSURIZATION 9	
CONTROL	LOSS OF PRESSURIZATION 10 DOOR UNLOCKED 11	
ELECTRICAL	ELECTRICAL SMOKE OR FIRE IN FLIGHT 12	
ICE AND RAIN PROTECTION	WINDSHIELD 13 HEATING	

GENERAL

SMOKE OR FIRE AT THE COCKPIT OR CARGO CABIN

1. Oxygen mask ON / 100% ALL

CAUTION

The oxygen masks must be adjusted correctly while the pressurized oxygen supply is used. Any leak will cause a considerable oxygen supply duration decrease as well as the temperature decrease of oxygen flowing from the mask.

2.	Passenger/Therapeutic oxygen manual shutoff valveA.R.	LM
3.	Assist passengers to don oxygen masksCHECK	LM
4.	Crew statusREPORT	ALL
5.	Cockpit door	2
6.	Passengers signs ACKNOWLEDGE	LM
7.	Pressurization mode selectorMAN	2
8.	Cockpit notificationRECEIVE	LM

SMOKE EVACUATION

1.	Pressurization Mode selectorMAN	2
2.	Cockpit notificationRECEIVE	LM
3.	Loose articles SECURED / STOWED	ALL
4.	Safety harnessFIT / LOCK	LM

5.	Passengers seatedENSURE	LM
6.	HeadphonesADJUST	LM
7.	Cabin reportNOTIFY	LM
8.	Cockpit doorOPEN	2
9.	Cargo doorOPEN	LM
	CAUTION	
	Before opening the cargo door, the loadmaster must fit his safety harness/parachute.	
10.	Re-establish normal conditions when the smoke has been evacuated.	
LA	VATORY SMOKE / FIRE	
1.	Cockpit door	2/LM
2.	Extinguish the fire with portable extinguisher	LM/2
3.	Apply <e.p2> "SMOKE EVACUATION" if necessary.</e.p2>	
4.	Whether or not smoke has dissipated, if it cannot be visually verified that the fire has been extinguished, prepare for landing immediately.	
LA	NDING WITH ABNORMAL LANDING GEAR	
CC	ONFIGURATION	
1.	Cockpit notificationRECEIVE	LM
2.	Crew briefingRECEIVE	2/LM
3.	Landing gear conditionCONFIRM	1/2
4.	Loose articles SECURED / STOWED	ALL
5.	Move the centre of gravity (if required).	
6.	Safety harness FIT / LOCK	ALL EP-3

C.L.Q.R.H. C-295M-VT01

Before entering the circuit:

7. Passengers signs ACKNOWLEDGE	LM
8. Crew oxygen	2
9. Emergency and entrance lights ACKNOWLEDGE	LM
10. Cabin reportNOTIFY	LM
11. "BEFORE ENTERING THE CIRCUIT" normal procedurePERFORM	ALL
Before landing:	
12. "BEFORE LANDING" normal procedurePERFORM At 150 ft:	1/2
13. "Brace for impact"ORDER	2/LM
With aircraft stopped:	
14. Evacuation orderRECEIVE	LM
15. Leave the aircraft	ALL

FORCED LANDING

Preparation (if time enough):

NOTE

Wherever possible, all passengers must sit together leaving no spaces in between each other and at the forward part of the cargo cabin.

1.	Cockpit notificationRECEIVE	LM
2.	ATCNOTIFY	2
3.	PressurizationADJUST	2
4.	Oxygen CLOSE / OFF	2

DI	rching	
16.	Leave the aircraft	ALL
15.	Portable ELTREMOVE	LM/2
14.	Evacuation orderRECEIVE	LM
Upo	on contact and after the aircraft has stopped:	
13.	"Brace for impact"ORDER	2/LM
lmn	ninent contact:	
12.	Last ATC message TRANSMIT	2
11.	Passengers signs ACKNOWLEDGE	LM
App	roach:	
10.	Final memory actions	ALL
9.	Cabin reportNOTIFY	LM
8.	Emergency and entrance lights ACKNOWLEDGE	LM
7.	Safety harnessFIT / LOCK	ALL
6.	Survival equipment	ALL
5.	Loose articles	ALL

Preparation (if time enough):

NOTE

Wherever possible, all passengers must sit together leaving no spaces in between each other and at the forward part of the cargo cabin.

1.	Cockpit notification	RECEIVE	LM
2.	ATC	NOTIFY	2
3.	Pressurization	ADJUST	2

C.L.Q.R.H. C-295M-VT01

4.	Oxygen CLOSE / OFF	2
5.	Loose articles SECURED / STOWED	ALL
6.	Survival equipmentPREPARED	ALL
7.	Life jacketsDON / ADJUST	ALL
8.	Safety harnessFIT / LOCK	ALL
9.	Emergency and entrance lights ACKNOWLEDGE	LM
10.	Cabin reportNOTIFY	LM
11.	Final memory actionsREVIEW	ALL
Арј	proach:	
12.	Passengers signs ACKNOWLEDGE	LM
13.	Last ATC message TRANSMIT	2
lmr	ninent ditching:	
14.	"Brace for impact"ORDER	2/LM
	"Brace for impact" ORDER on contact and after the aircraft has stopped:	2/LM
	on contact and after the aircraft has stopped:	2/LM
	on contact and after the aircraft has stopped: CAUTION	2/LM
	on contact and after the aircraft has stopped:	2/LM
Up	on contact and after the aircraft has stopped: CAUTION	2/LM
<i>Up</i> :	CAUTION Do not open any doors if (even partially) under water.	
<i>Up</i> :	CAUTION Do not open any doors if (even partially) under water. Evacuation order	LM
<i>Up</i> :	CAUTION Do not open any doors if (even partially) under water. Evacuation order	LM 2/LM
<i>Up</i> :	CAUTION Do not open any doors if (even partially) under water. Evacuation order	LM 2/LM
15. 16. 17.	CAUTION Do not open any doors if (even partially) under water. Evacuation order	LM 2/LM

ON GROUND EMERGENCIES

ELECTRICAL SMOKE OR FIRE ON GROUND

- 1. Cockpit alertRECEIVE LM
- 2. Apply <E.P.-7> "GROUND EVACUATION" if necessary.

GROUND EVACUATION

WARNING

Do not approach the main wheel area when extreme temperatures due to excessive braking are suspected. All personnel other than the fire department should evacuate the immediate area. The area on both sides of the wheel will be cleared of personnel and equipment for at least 300 feet. If conditions require personnel to be close to any overheated wheel or tire assembly, the approach should only be from the fore or aft of the wheel area.

1.	Cockpit alert	RECEIVE	LM
2.	Emergency lights	ACKNOWLEDGE	LM
3.	Ramp	A.R.	2
4.	Evacuation order	RECEIVE	LM
5.	Leave the aircraft		ALL

EP-8

Revision 1

ENVIRONMENTAL CONTROL

AIR CONDITIONING SMOKE

1. Oxygen mask ON / 100% ALL

CAUTION

The oxygen masks must be adjusted correctly while the pressurized oxygen supply is used. Any leak will cause a considerable oxygen supply duration decrease as well as the temperature decrease of oxygen flowing from the mask.

as the temperature decrease of oxygen flowing from the mask.	
2. Crew statusREPORT	ALL
3. Cockpit notificationRECEIVE	LM
4. Corresponding bleed switch OFF	2
A. If the smoke decreases or does not increase (after 2 minutes	<u>):</u>
If necessary, apply <e.p2> "SMOKE EVACUATION". (END) B. If the smoke continues to increase:</e.p2>	
5. Bleed switch previously turned offON	2
6. Other bleed switchOFF	2
B.1. If the smoke decreases or does not increase (after 2 minu	ıtes):
The smoke was coming from the disconnected pac necessary, apply <e.p2> "SMOKE EVACUATION". (END)</e.p2>	
B.2. If the smoke continues to increase:	
7. Bleed switch previously turned offON	2

- 8. Prepare for landing ALL
- 9. If necessary, apply <E.P.-2> "SMOKE FVACUATION"

RAPID DEPRESSURIZATION

A. If flying altitude is over 15000 ft:

1. Oxygen mask......ON / 100% ALL

CAUTION

The oxygen masks must be adjusted correctly while the pressurized oxygen supply is used. Any leak will cause a considerable oxygen supply duration decrease as well as the temperature decrease of oxygen flowing from the mask

- 2. Assist passengers to don oxygen masks CHECK LM
- 3. Passenger/Therapeutic oxygen shutoff valve....... OPEN
- 4. Passengers seated......ENSURE LM
- 5. Crew statusREPORT ALL
- 6. Apply part B.
- B. If flying altitude is below 15000 ft:
 - 1. Passengers signs ACKNOWLEDGE LM
 - 2. Cockpit notificationRECEIVE LM

CAUTION

The technical crew must use oxygen while the cabin altitude is above 10000 ft. The loadmaster will supply oxygen to those passengers requiring it.

I M

LOSS OF PRESSURIZATION

Oxygen mask ON / 100% CAUTION The oxygen masks must be adjusted correctly while the pressurized oxygen supply is used. Any leak will cause a considerable oxygen supply duration decrease as well as the temperature decrease of oxygen flowing from the mask 2. Assist passengers to don oxygen masks.......CHECK I M 3. Passenger/Therapeutic oxygen shutoff valve OPEN I M Passengers seated ENSURE I M 4. 5. Crew status......REPORT ALL Passengers signs ACKNOWLEDGE 6. I M Notification of the situation RECEIVE 7. I M 8. Descent INITIATE CAUTION Technical crew must use oxygen while the cabin is above 10000 ft. The loadmaster will supply oxygen to those passengers requiring it. 9. Pressurization RESET 2 A. Pressurization panel "FAULT" light off: (END)

2

EP-10 Revision 1

B. Pressurization panel "FAULT" light on:

DOOR UNLOCKED

. Passengers signs ACKNOWLEDGE	LM
A. If the crew door/ramp door light is on:	
 The aircraft will depressurize automatically. Apply <e.p9> "RAPID DEPRESSURIZATION" and prepare for landing. (END)</e.p9> 	
B. If the emergency door/paratroops door light is on:	
When aircraft levelled and stabilized:	
2. Safety harness / parachuteFIT	LM
3. Door closedCHECK	LM
B.1. If the light goes off:	
4. Continue flight normally. (END)	
B.2. If the light remains on, or both door and locking device car be checked:	<u>ınot</u>
4. Cabin differential pressure MAINTAIN POSITIVE	2
Assess whether it is advisable to keep flying or land at the nearest suitable airport	1

ELECTRICAL

ELECTRICAL SMOKE OR FIRE IN FLIGHT

1.	Oxygen mask ON / 100%	ALL	
	CAUTION		
	The oxygen masks must be adjusted correctly while the pressurized oxygen supply is used. Any leak will cause a considerable oxygen supply duration decrease as well as the temperature decrease of oxygen flowing from the mask.		
2.	Assist passengers to don oxygen masksCHECK	LM	
3.	Passenger/Therapeutic oxygen shutoff valve OPEN	LM	
4.	Passengers seatedENSURE	LM	
5.	Crew statusREPORT	ALL	
Α	. If the smoke or fire signs go out:		
	Leave the battery and generator off for the rest of the flight (END)	2	
(END)			
B. If the smoke or fire signs persist:			
	6. Prepare for landing	ALL	
	7. Apply <e.p2> "SMOKE OR FIRE AT THE COCKPIT OR CARGO CABIN".</e.p2>		
	8. If necessary, apply <e.p2> "SMOKE EVACUATION".</e.p2>		

ICE AND RAIN PROTECTION

WINDSHIELD HEATING

While at approach phase:			
1. Vision through the glassesCHECK	ALL		
A. If the vision is acceptable:			
(END)			
B. If the vision is not acceptable:			
2. Cockpit notificationRECEIVE	LM		
3. AircraftDEPRESSURIZE	2		
When differential pressure is zero:			
4 Cocknit door CLOSE	2/I M		

C.L.Q.R.H. C-295M-VT01

Intentionally Left Blank