



ReactiveFix when broken

Machine runs until failure



PreventiveRepair regularly

Machine is regularly stopped for scheduled maintenance activities



Predictive

Repair when it is about to break

Machine is constantly monitored so that it is stopped for maintenance only when failure is imminent