## Alarm Help - MV SERIES -



ALARM ADDRESS	A5.3	ALARM NO.	1127
ALARM TEXT	SPDL NOT ORIENT.		
Related Signal			
CAUSE	Spindle not orientation while performs M25 / M26 / M27 Code •		
ACTION	Operating M19 in MDI mode in advance •		